Software version: V3.4.0 Document version: V3.4.0 Original instructions(English)

User manual (V3.4.0)



P3020



Table of Contents

1	PART 1. Safety Manual9
1.1	Manual Indication Conventions9
1.2	Safety Symbols9
1.3	Precautions11
1.3.1	General Instructions11
1.3.2	Precautions for Use12
1.4	Product Usage and Risk Assessment14
1.4.1	Product Usage14
1.4.2	Risk Assessment
1.5	Robot Mode and State15
1.5.1	Mode of Robot16
1.5.2	Status and Flange LED Color for Each Mode17
1.6	Product Warranty and Responsibility21
1.6.1	Scope of Warranty21
1.6.2	Restrictions and Exceptions of Warranty21
1.6.3	Transfer22
1.6.4	Contact
1.7	Safety Function22
1.7.1	Safety-rated Stop Subfunction
1.7.2	Safety-rated Stop Function
1.7.3	Safety-rated Monitoring Function
1.7.4	Safety-rated I/O29
1.8	Safety Function Settings31
1.8.1	Safety Signal I/O33
1.8.2	Safety Stop Modes
1.8.3	Nudge40
1.8.4	Zone
1.8.5	Space Limit41
1.8.6	Robot Limits
1.9	Other Safety Measures44
1.10	Legal Notice44

1.10.1	Validity and Responsibility44
1.10.2	Disclaimer45
1.11	Potential Risks45
1.12	Declaration and Certification46
1.12.1	Europe Machinery Directive Attestation of Conformity46
1.12.2	Europe EMC Directive Attestation of Conformity
1.12.3	U.S. NRTL Certification (US, CANADA)50
1.12.4	Functional Safety certification
1.12.5	Voluntary Safety Confirmation Declaration (KCs)54
1.13	Stop Distance and Stop Time55
1.13.1	Measurement Methods and Conditions55
1.13.2	P3020 Stop Category57
1.14	Upper/Lower Threshold Range and Default Value of Safety Parameters 60
1.14.1	P302060
2 I	PART 2. Starting up the Robot62
2.1	Journey Map62
2.1.1	Step 1. Robot Installation62
2.1.2	Step 2. Tool Installation and I/O Testing
2.2	Robot Installation 164
2.2.1	Remove packing64
2.2.2	Connect cable to the controller
2.2.3	Fix the robot base65
2.3	
	Robot Installation 267
2.3.1	Robot Installation 2
2.3.1 2.3.2	
	Connecting Power to Controller67
2.3.2	Connecting Power to Controller
2.3.2 2.4	Connecting Power to Controller
2.3.2 2.4 2.4.1	Connecting Power to Controller
2.3.2 2.4 2.4.1 2.4.2	Connecting Power to Controller
2.3.2 2.4 2.4.1 2.4.2 2.4.3	Connecting Power to Controller
2.3.2 2.4 2.4.1 2.4.2 2.4.3 2.4.4	Connecting Power to Controller
2.3.2 2.4 2.4.1 2.4.2 2.4.3 2.4.4 2.5	Connecting Power to Controller

Connect wires	74
Power on the system	75
Test controller and flange I/O	75
PART 3. Installation Manual	77
Cautions during Installation	77
Lifting points for transport and installation	77
Product Introduction	78
Robot system configuration and description	78
Nameplate and Label	85
Product Specifications, General	86
Robot Specifications	88
Robot operating space	88
Max. Payload within operating space	88
Tool Center Point (TCP)	90
Basic specifications	90
Axis Specifications	91
Installation Environment	93
Installation Location Check	93
Robot Work Area Check	93
Hardware Installation	95
Ready to install the robot	95
Connecting the system	98
Connecting the Robot and Tool	102
Power on/off the controller	104
Power on	104
Power off	104
PART 4. Interface	106
Flange I/O	106
Schematic Diagram	106
Flange Digital Output Specifications	109
Flange Digital Input Specifications	110
Flange Analog Input Specifications	111

4.2	Controller I/O Connection	112
4.2.1		
4.2.2	, , , , , , , , , , , , , , , , , , , ,	
4.2.3	, , , , , , , , , , , , , , , , , , , ,	
4.2.4	3. 3	
4.2.5	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
4.2.6	Setting the Terminal Block for Voltage Input (TBSI)	128
4.3	Network Connection	129
4.3.1	Connecting External Devices	130
4.3.2	Setting up and using extended protocols	134
4.3.3	Setting ModbusTCP Slave	139
4.3.4	Using General Purpose Register(GPR)	140
_		
5	PART 5. Robot Management	142
5.1	Transportation	142
5.1.1	Caution during Transportation	142
5.1.2	Pose for Robot Transportation	142
5.1.3	Package specifications	142
5.2	Maintenance	143
5.3	Disposal and Environment	143
6	PART 6. DART-Platform Manual	144
6.1	Power on/off the system	144
6.1.1	When using the teach pendant	144
6.2	Overview of Program's Screen Layout	145
6.2.1	Overview of Home Screen	147
6.2.2	Overview of header	148
6.2.3	Overview of Footer	150
6.3	What is a robot?	152
6.3.1	Functional Limits of each Robot Series	152
6.3.2	Functional Limits of force monitoring for each Robot Series	153
6.3.3	Overview of Singularity	155
6.3.4	Overview of Euler Angle	157
6.4	Overview of Servo On	160

6.5	Backdrive Module
6.6	Recovery Module
6.6.1	Using Software Recovery Mode165
6.6.2	Using Pack/Unpack167
6.7	Robot Parameters Module
6.7.1	Robot Settings
6.7.2	Tool Settings
6.7.3	Safety Settings
6.7.4	Safety setting Review
6.8	Remote Control Module
6.8.1	Configuration Items
6.8.2	Remote Control Mode Operation Steps
6.8.3	Remote Control Mode
6.9	Task Editor Module248
6.9.1	Overview of Robot Motion Properties of the Task Editor253
6.9.2	Overview of the Basic Concepts behind the Task Editor Move Command 259
6.9.3	Overview of the Concept of Compliance/Force Control of the Task Editor Command 263
6.9.4	Try Compliance command samples
6.9.5	Try force command samples
6.9.6	Overview of Sub/Call Sub
6.9.7	SubTask/Call SubTask
6.9.8	Commands
6.9.9	Debug Player
6.9.10	Function of Operator Intervention
6.9.11	Signal Commands312
6.10	Status Module
6.10.1	Status Module Screen layout 319
6.10.2	I/O Overview
6.10.3	Slave Monitoring
6.11	Logs module 327
6.12	Store Module 330
6.12.1	Activate or deactivate modules
6.13	Settings Module
6.13.1	System Information

6.13.2	Setting language
6.13.3	Password settings and changes
6.13.4	Configure in the Network section
6.13.5	Setting the Robot
6.13.6	Robot Update and Restore
6.13.7	Managing Data
6.13.8	Notification Position Settings
6.13.9	Module update
6.14	Jog Plus Module
6.14.1	Jog Panel
6.14.2	Move Panel
6.14.3	Align Panel
_	
7	Appendix 376
7.1	Appendix
-	
7.1	Appendix. System specifications 376
7.1 7.1.1	Appendix. System specifications
7.1 7.1.1 7.1.2	Appendix. System specifications
7.1 7.1.1 7.1.2 7.1.3	Appendix. System specifications
7.1 7.1.1 7.1.2 7.1.3 7.2	Appendix. System specifications
7.1 7.1.1 7.1.2 7.1.3 7.2 7.2.1	Appendix. System specifications
7.1 7.1.1 7.1.2 7.1.3 7.2 7.2.1 7.3	Appendix. System specifications

Preface

Thank you for choosing this Doosan Robotics product. Before installing the product, please read this manual completely and follow the instructions for each installation process provided herein. The contents of this manual are accurate as of the date that they are written, and product-related information may be modified without prior notice to the user.

Copyright

The copyright of this manual and all intellectual property rights contained herein are held by Doosan Robotics. Therefore, using, copying, or distributing any part of this manual without receiving written permission from Doosan Robotics is strictly prohibited. In the event of abuse to or modification for use of any patent, the user will be fully responsible for the consequences.

While the information in this manual is reliable, Doosan Robotics will not be held responsible for any loss or damage that occurs due to errors or typos. The contents of this manual may be modified according to product improvements without prior notification.

Details on updates to the manual can be found on the Robot LAB website (https://robotlab.doosanrobotics.com/).

© Doosan Robotics Inc., All rights reserved

• Open Source Software License Information (OSS)

The software installed in this product was developed based on free/open source software.

Details on licensing of free/open source software license can be found on the OSS use page on the Doosan Robotics website (www.doosanrobotics.com/kr/oss/license¹).

For related inquires, contact the Marketing Department of Doosan Robotics (marketing.robotics@doosan.com²).

^{1.} https://www.doosanrobotics.com/kr/oss/license

 $^{2.\} mailto: marketing.robotics@doosan.com$

1 PART 1. Safety Manual

The Safety Manual provides the safety information that the user must be familiar with before installing or using the robot. All robots contain hazards from high voltages, electricity, collisions, etc. Therefore, in order to minimize the risk of injuries and mechanical damage, one must observe the basic safety cautions while operating the robot and using related parts. To protect user safety and prevent property loss, make sure to read and follow the instructions carefully. The contents of the manual and specifications of the product may change for product and performance improvements.

1.1 Manual Indication Conventions

To communicate safety precautions related to the use of the product, the following symbols are indicated in this manual.

Symbol	Name	Description
⊗ Danger	Danger	Failure to observe instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator.
▲ Warning	Warning	Failure to observe instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator.
A Caution	Caution	Failure to observe instructions with this symbol may result in product damage or cause injury to the operator.
Note	Note	This is additional information to help the user.

1.2 Safety Symbols

Among the symbols used in this manual, symbols related to user safety are as follows:

Symbol	Description
⊗ Danger	This symbol means that immediate hazards can occur due to electrical conditions such as high voltage. Failure to observe instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator.

Symbol Description This symbol means that immediate hazards can occur. Failure to observe Danger instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator. This symbol means that potentially dangerous situations can occur due to Warning electrical conditions such as high voltage. Failure to observe instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator. This symbol means potentially dangerous situations can occur. Failure to Warning observe instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator. This symbol means dangerous situations can occur due to overheating. Caution Failure to observe instructions with this symbol may result in serious accidents that could result in death or serious injury to the operator. The product may become damaged or the operator may suffer injury. Caution

1.3 Precautions

1.3.1 General Instructions

This chapter describes general danger and warning items related to operating the robot.



Warning



• If the robot is installed with electrical devices, install the robot referring to the Installation Manual.



Warning



- If a device is installed on the tool during robot installation, make sure to use appropriate bolts.
- Suitable safety measures, such as safety fences, must be implemented to protect the staff and robot during installation.
- Never operate a damaged robot.
- Make sure to connect safety protection equipment with a safety interface. If such equipment is connected to a general interface, the integrity of safety functions may not be guaranteed.
- If the robot collides with an external object, a significant impact may be generated. The impact the robot receives is proportionate to the kinetic energy, so higher speeds and high payload can generate large impacts. Make sure to maintain a safe speed and payload during operation in collaborative spaces.
- If the robot axis must be rotated when the robot is not operated, it can be rotated at a torque greater than 400 Nm.
- Modifying the robot without prior approval may cause critical breakdowns and accidents.



Caution



• Operating the robot and controller for an extended period of time generates heat. Do not touch the robot with bare hands after operating for an extended period of time. Before performing work that requires touching the robot, such as tool installation, leave the robot for more than 1 hour after turning off the power of the control unit to cool down the robot.



Caution

- 11 -



- Do not expose the robot to powerful magnetic fields. It may cause damage to the robot.
- If the power plug is disconnected or the power is shut off during robot and controller operation, robot and controller failure can occur.
- Do not use the controller being laid. After opening the cover, the cover may be inadvertently closed during work, resulting in hand jam, so stand it up to perform the operation.

1.3.2 Precautions for Use



Danger



- Do not operate the robot if the robot is abnormal. The user may be injured.
- Do not put fingers inside the controller with power supplied. Live cables are connected, which may lead to electrocution or injury.
- Never modify the robot. Doosan Robots is not responsible for for any issues that occur due to unauthorized modification.
- Do not come into contact with or touch the robot while the robot is operating. The robot may collide with it and cause it to fail or cause injury.



Warning



- Make sure to read and understand the manuals for all equipment installed.
- To prevent accidents by getting caught by the robot, do not wear loose clothing or accessories when operating the robot. Tie long hair to prevent accidents with hair getting caught by the robot.
- Before operating the robot, comprehensive risk assessment must be performed.
- Safety-related parameters must be determined through the comprehensive risk assessment, and safety parameter settings and the operation of safety functions must be verified before operating the robot.
- Before starting robot operation(Jogging, handguiding, running task program, etc.), make sure that the actual payload and installation are correct and that the actual pose of robot is identical to the pose on screen.
- Nudge and Hand-guiding must only be used if risk assessment approves its use.
- If an error occurs on the controller or the teach pendant, activate the emergency stop function, identify the cause of the error, find the error code on the log screen and contact the supplier.

- Make sure to become completely familiar with the robot user manual prior to operating the robot.
- If the teaching pendant warns the user of a critical error, immediately engage the emergency stop switch, identify the cause of the error, resolve the error and then resume robot operation. If the critical error cannot be resolved, contact the sales agent or robot supplier.
- Direct teaching must only be performed in safe environments. Do not operate the robot if there are sharp edges or jamming near the tool and its surroundings.
- Make sure you enter the correct inputs for the tool (length, weight, center of gravity, etc.) before using the direct teaching function. If information is entered that is different from the actual tool's specifications, it may cause errors or malfunction of the direct teaching function.
- To ensure user safety, joints may operate at a certain speed or higher, or the maximum speed of the TCP may be limited during direct teaching. If the limit is exceeded, the protective stop function activates.
- Enable/disable the direct teaching function when the robot has completely stopped. If the direct teaching function is enabled/disabled during robot operation, malfunctions may occur.



Caution



- Take caution of the robot's movement when using the teach pendant. Failure to do so may lead to colliding with the robot, resulting in damage to the robot or injury to the individual.
- Collision with an object generates considerable kinetic energy, leading to dangerous situations. This energy is proportionate to the speed and payload. (Kinetic Energy = 1/2 Mass x Speed^2)
- Combining different machines may increase existing risks or create new risks. When a robot is integrated into a system, perform risk assessment of the entire system.
- If different safety levels and emergency stop performance levels are required, always select the higher level.
- If a machine that can cause damage to the robot is integrated, it is recommended to individually test all functions and robot programs.
- It is recommended to test the robot program by designating temporary waypoints outside another machine's workspace. Doosan Robotics is not responsible for damages that occur due to programming error or robot malfunctioning, as well as damage to the equipment.
- If the power plug is disconnected or the power is shut off during robot and controller operation, robot and controller failure can occur.
- For information about additional modules, refer to corresponding manuals.

1.4 Product Usage and Risk Assessment

1.4.1 Product Usage

This is an industrial product designed specifically for purposes of transferring and assembling objects by attaching components to products using tools, and it must be operated in the conditions specified in its specifications.

This product features special safety functions designed for the purpose of collaborating with human operators, and it operates with human operators without specific boundaries. Conduct work with the system only when all applications, including the tool, workpiece, boundary and other equipment, are confirmed to have no harm.

The following uses are considered inappropriate because they exceed the boundaries of the product's intended purpose. Doosan Robotics will not be held responsible for any damage and malfunctioning of the robot, property losses and injuries to users due to such inappropriate uses.

- Use in an environment with potential explosions
- Use in application related to medicine and human lives
- Use in transporting humans and animals
- Use without risk assessment
- Use in locations where performance and operation environment specifications are not met
- Use in environments with insufficient safety functions
- Use of the robot as a step to stand on
- Use under conditions beyond the IEC International Standard for Electromagnetic Compatibility in Industrial Environments

1.4.2 Risk Assessment

One of the most important factors for system integrators is risk assessment. Risk assessment is a legal requirement in most countries. In addition, the safety assessment of the robot installation depends on the way the robot integrates into the entire system, so the robot itself cannot be used for risk assessment.

In order to proceed with the risk assessment of the robot, the administrator who configures the entire system must install and operate the robot in accordance with the guidelines of ISO12100 and ISO10218-2. In addition, the administrator can refer to the technical specification ISO/TS 15066.

Risk assessment must consider the overall work process in terms of the overall life cycle of the robot application. Key objectives of risk assessment are as follows:

- Robot setting and work teaching for robot operation
- Troubleshooting and maintenance
- Proper robot installation

Before supplying power to the robot arm, make sure to perform a risk assessment. Setting appropriate safety settings and identifying the need for additional emergency stop buttons and other protective measures are parts of risk assessment.

Identifying appropriate safety settings is a critical aspect of developing a collaborative robot application. For more information, refer to the corresponding chapter of the manual.

Some safety functions are designed specifically for collaborative robot applications. These functions can be set up through safety function settings, and they are optimized for responding to specific risks identified through the risk assessment performed by the integrator.

The safety functions of the collaborative robot can be set up in the safety setting menu, and they offer the following features:

- Force and power limitation: Limits the stopping force and pressure of the robot in case of collisions between the robot and a worker
- Momentum limitation: Limits the energy and impact load by reducing the speed of the robot when a collision between the robot and a worker occurs
- Joint position and TCP limitation: Limits robot movement to prevent moving towards specific body parts of users such as the neck or head
- TCP and tool pose limitation: Limits certain areas or characteristics of a tool and workpiece to minimize related risks (i.e., limits the movement of sharp edges of workpieces aimed at users)
- Speed limitation: Limits robot movement to stay at low speed in order to secure time for the user to avoid a collision before a collision between the robot and a worker occurs

Applying appropriate safety settings is considered to be the same as fixing the robot to a specific location and connecting it to a safety-related I/O. For example, setting password protection can prevent unauthorized safety setting changes by individuals not approved by the system integrator.

Key items to note when performing risk assessment of the collaborative robot application are as follows:

- Severity of individual potential collisions
- Probability of individual potential collision occurrence
- Probability of individual potential collision avoidance

If the robot is installed on a non-collaborative robot application that cannot sufficiently remove risks using its internal safety functions (e.g., use of dangerous tool), the system integrator must decide to install additional protection devices during risk assessment (e.g., use of protection devices capable of protecting the integrator during installation and programming).

1.5 Robot Mode and State

The operating modes of the robot include manual mode, in which the robot is driven by user intervention, and automatic mode, in which the robot is driven without user intervention.

1.5.1 Mode of Robot

Manual Mode

This is the mode in which the robot operates according to direct user control. The robot only operates when a button related to an action is pressed, and releasing the button results in stopping the corresponding action.

- In Manual Mode, the TCP movement speed is limited to less than 250 mm/s according to the Robot Safety Regulations. However, when handguiding, the limits set in **Robot Parameter > Safety Settings > Robot Limits** are applied.
- If risk assessment results indicate that a 3-position Enable Switch is necessary, the 3-position Enable
 Switch can be connected in Robot Parameter> Safety Settings > Safety I/O. In this case, the Enable
 Switch must be set in the center position to allow the robot to operate in Manual Mode and to turn on the
 servo.

In Manual Mode, it is possible to configure robot peripherals in **Robot Parameters** or to program robot tasks in **Task Editor**, and if the robot cannot be operated normally for reasons such as the robot exceeding the safety threshold, the Recovery function can be performed to restore normal operation.

Automatic Mode

This is the mode in which the robot operates without direct user control. The robot will execute the programmed task or predefined sequence with a simple operation command and without additional user input.

Task Editor can verify the programmed task in virtual mode, execute it in actual operation, and perform robot tool weight and automatic weight center measurement functions.

• If risk assessment results indicate that a 3-position Enable Switch is necessary, the 3-position Enable Switch can be connected in the **Robot Parameter > Safety Settings > Robot Limits** setting. In this case, the Enable Switch must be set in the center position to play or start, or resume Automatic Mode and to turn on the servo.

Other Mode

Unlike normal modes such as manual mode and automatic mode, this is exceptional mode.

This mode includes special states such as controller booting, initializing and states related to Backdrive at which you can push robot by hand without drive power.

1.5.2 Status and Flange LED Color for Each Mode

Manual Mode

Mode	Status		Description	Flange and/ or base LED
Manual	Manual Standby		 This is the default status of teaching. Robot Parameter and Task Editor can be used to configure the work condition or perform task programming. It monitors the stop status with Safe Operating Stop (SOS). 	Blue
		Manual Jogging	The jog function is used to operate the robot.	Blue Flashing
		Manual Handgui ding	The manipulator can be operated directly by hand.	Light blue flashing
		covery andby	 Recovery in progress. All safety functions except for axis and TCP speed monitoring are disabled during recovery. It monitors the stop status with Safe Operating Stop (SOS). 	Yellow Flashing
		Recovery Jogging	 The jogs of each axis can be used to correct the exceeded safety threshold. 	Yellow Flashing
		Recovery Handgui ding	The manipulator can be moved directly by hand to correct the exceeded safety threshold.	Yellow Flashing

Mode	Status	Description	Flange and/ or base LED
	Interrupted	 Protective Stop is activated by a Protective Stop input or exceeding the safety threshold. It monitors the stop status with Safe Operating Stop (SOS). A yellow protective stop pop-up appears. After the cause of the protective stop is removed, pressing the Reset button will switch the robot status to Manual Standby and the pop-up will disappear. If the exceeded safety limit cannot be released without moving the robot, it can be released by pressing the Recovery button to enter safety recovery mode and moving the robot. If it is not possible to release the protective stop input from the protective device, pressing the Safety I/O button can cancel the protective stop input setting to release it. 	Yellow
	Servo Off	 The servo is turned off due to an emergency stop or Protective Stop input, or exceeding the safety threshold. It is identical to Safe Torque Off (STO). The servo can only be turned on when the cause of the emergency stop or protective stop has been cleared. If the exceeded safety limit cannot be released without moving the robot, it can be released by turning on the servo in the safety recovery mode screen and moving the robot. If it is not possible to release the protective stop input from the protective device, canceling the protective stop input setting in the Safety I/O setting menu releases it. 	

Automatic Mode

Mode	Status	Description	Flange and/or base LED
Automati c	Auto Standby	 Within the workspace, the UI of the Teach Pendant is on the real mode launch screen. Press the Execute button to execute the task program. White is displayed for a single work area and green is displayed for a collaborative work area. 	White / Green

Mode	Status		Description	Flange and/or base LED	
	Aut Rui	to nning	 The task program is being executed. White is displayed for a single work area, green is displayed for a collaborative work area, and white and yellow are displayed in turn for a priority work area. 	White Flashing / Green Flashing White&yellow Flashing in turn	
	HGC (Handguide Control) Standby		 The Handguiding command is executed during task program execution. The system waits until the user presses the "Handguiding" button. It monitors the stop status with Safe Operating Stop (SOS). 	Light blue	
	HG Rui	GC nning	 The robot pose can be changed by pressing the Handguiding button. After the robot stops 3 times, if the HGC End & Resume signal is input via Safety IO, it switches to Auto Running and the task 	Light blue flashing	
	Auto-me	easure	 The state of automatically measuring the center of gravity position of the end effector. Be careful as the robot's safety monitoring function is disabled. 	Yellow Flashing	
	Interrup	oted	 Protective Stop is activated by a Protective Stop input or exceeding the safety threshold. It monitors the stop status with Safe Operating Stop (SOS). A yellow protective stop pop-up appears. After the cause of the protective stop is removed, pressing the Reset button will switch the robot status to Manual Standby and the pop-up will disappear. If the exceeded safety limit cannot be released without moving the robot, it can be released by pressing the Recovery button to enter safety recovery mode and moving the robot. If it is not possible to release the protective stop input from the protective device, pressing the Safety I/O button can cancel the protective stop input setting to release it. 	Yellow	

- 19 -

Mode	Status	Description	Flange and/or base LED
	Servo Off	 The servo is turned off due to an emergency stop or Protective Stop input, or exceeding the safety threshold. It is identical to Safe Torque Off (STO). The servo can only be turned on when the cause of the emergency stop or protective stop has been cleared. If the exceeded safety limit cannot be released without moving the robot, it can be released by turning on the servo in the safety recovery mode screen and moving the robot. If it is not possible to release the protective stop input from the protective device, canceling the protective stop input setting in the Safety I/O setting menu releases it. 	

Other Mode

Mode	Status	Description	Flange and/or base LED
-	Backdrive Hold	 The brakes on all 6 axes are engaged, locking out unpowered operation. 	Yellow Flashing
	Backdrive Release	 Brake Release has been selected, causing 1 or more joints to be released. Be careful that if you leave the robot without the brakes re-engaged, the axis will not become fixed and will fall. 	Yellow Flashing
	Backdrive Servo Off	 Servo turned off due to an emergency stop or joint speed limit exceeded. It is identical to Safe Torque Off (STO). 	
	Initializing	This is the process of booting up the controller and initializing the robot.	Red flashing

1.6 Product Warranty and Responsibility

Doosan Robotics (hereinafter referred to as "Doosan" or "Manufacturer") offers a restricted warranty as stipulated in this warranty certificate for all robot systems (collectively "robot") and parts of the system (excluding parts that are exceptions or restricted according to the terms and conditions below) sold through Doosan or official sales agents. The warranty stipulated by this warranty certificate is a restricted warranty, and it is the only warranty provided by the Manufacturer. All warranty items shall be handled according to the conditions listed below.

1.6.1 Scope of Warranty

The material and manufacturing defects of each robot and its parts (collectively, "Doosan Products") are subject to the warranty provided by the Manufacturer. This warranty is only offered to the end user (hereinafter referred to as "Customer"). The warranty period is 1 year starting from the date when the robot was installed.

The scope of this warranty limits the Manufacturer's only responsibility for all Doosan products and the Customer's only remedy to the repair or replacement of defective Doosan products.

Doosan does not compensate any or all financial, operation or productions losses, any or all indirect losses such as damage to other equipment, and any or all deliberate, special or consequential losses that occur due to defects of Doosan Products.

1.6.2 Restrictions and Exceptions of Warranty

To maintain the warranty, thorough maintenance procedures stipulated by the Manufacturer must be observed and recorded. This warranty is voided if the Manufacturer determines that the user failed to observe the following stipulated procedures.

- If a Doosan Product is inappropriately handled or used by the user
- If parts or S/W not provided by Doosan are installed
- If a Doosan Product is incorrectly repaired or maintained by an unofficial repair technician or unauthorized individuals
- If the user modified a Doosan Product without prior approval from the Manufacturer
- If a Doosan Product was used for non-industrial or personal purposes
- If the life cycle of consumables has ended
- If the warranty claim is made after the warranty period
- If the breakdown is caused by natural disasters (fire, flood, abnormal power, etc.)

This warranty does not apply to damages caused by external circumstances the Manufacturer does not have any control over such as theft, intentional destruction, fire, natural disasters, war or act of terrorism.

Notwithstanding the exceptions or restrictions of this warranty, this warranty does not include any warranties where a Doosan Product satisfies the buyer's production standards or miscellaneous requirements, or operates without any errors or without any interruption. The Manufacturer does not assume responsibility for any uses

by the buyer, and the Manufacturer does not assume any responsibility for defects other than repair or replacement such as defects in design, production, operation and performance.

1.6.3 Transfer

This warranty is included in the warranty period, and if the Doosan robot is sold to a different individual through a private transaction, the warranty can also be transferred. However, the warranty is only valid if the Manufacturer is notified of this transaction, and the warranty period is still in effect. The assignee of this warranty must observe all conditions stipulated in this warranty.

1.6.4 Contact

marketing.robotics@doosan.com3

1.7 Safety Function

Users/system integrators can make use of the various safety functions, including safety-rated stop function, monitoring function and interface function, to protect operators and machines, and can also connect other machines and safety/protection equipment.

Each safety-rated stop function, monitoring function and interface function satisfy Category 3, Performance Level d(PL d) defined by ISO 13849-1 and Hardware Fault Tolerance 1, Safety Integrity Level 2(SIL 2) defined by IEC 62061.

The joint-level operated safety functions of Doosan Robotics uses the safety functions described in IEC 61800-5-2.



Note

- Work cells must be set using the safety functions and interface according to the risk assessment performed on the corresponding robot application by the system integrator, and refer to this manual for information required for this.
- If the safety systems of the robot detect system defects, such as hardware defects including emergency stop circuit shortage, position sensor damage or control communication error, Stop Category 0 is immediately initiated.
- Meanwhile, if the safety systems of the robot detect violations during safety monitoring, such as pressing the emergency stop switch, protective stop signal input, detection of external impact, or physical parameters (robot/TCP position, speed, momentum) exceeding set parameters, the system stops the robot using the mode set as the stop mode setting in the safety setting menu. (Selects Stop Category 0, 1 or 2)
- For information on the time and stopping distance until the robot comes to a full stop from the moment the above error or violation occurs, refer to Stop Distance and Stop Time(p. 55). This time must be considered as part of the risk assessment performed by the system integrator.

^{3.} mailto:marketing.robotics@doosan.com

- In special cases (collision detection, TCP Force Violation), a Safety Stop Mode that stops the robot after accepting the external force for 0.25 seconds after event occurrence can be used to avoid clamping situations where limbs are jammed between the fixated jig/workpiece and the robot. (RS1 Stop Mode)
- The safety setting menu can set various safety functions to limit the movement of joints, robot and TCP. TCP means the location of the output flange center point added by the TCP offset.

1.7.1 Safety-rated Stop Subfunction

Safety-rated stop subfunction is used to stop the robot when Safety-Rated Monitoring Function(p. 26) detects limit violation, when a stop signal is received from the dedicated input terminal of (3.4.0-en_US) Safety-Rated Stop Function(p. 25), or when a stop signal is received from the configurable input terminal of Safety-rated I/O (p. 29)set as one of the Safety-rated Stop Subfuctions.



Note

- PFHd (Probability of a dangerous Failure per Hour): The probability of dangerous failures of safety-related system/subsystem per hour
- PL (Performance Level): The performance level of safety-related components (SRP/CS) of control system according to ISO 13849-1
- · SIL (Safety integrity level): The safety integrity level of safety-related electronic control systems (SRECS or SCS) according to IEC 62061
- Stop Category: The category of stop functions defined by IEC 60204-1

	Safety Function	Description	PFHd	PL, SIL
1	STO (Safe Torque Off) & SBC (Safe Brake Control)	It is the safety stop function corresponding to Stop Category 0, and it immediately cuts motor power to all joint modules. With motor power down, the axis will continue to rotate due to inertia, so the brakes must be operated simultaneously to stop with frictional force of the brake. • As the motor power is cut off, the robot can be operated after releasing the stop function and setting the Servo On. • For more information about servo on methods, refer to Overview of Servo On(p. 160). • The robot brake is used for maintaining the current pose when driving force is lost (i.e., power off, etc.) not for deceleration. Frequently using STO can result in brake wear or decelerator durability loss, so it is recommended to use SS1 unless necessary.	2.87E-8 /h	PL e Cat. 4 SIL 3

	Safety Function	Description	PFHd	PL, SIL
2	SS1 (Safe Stop 1)	 This is the safety stop equivalent of Stop Category 1, which decelerates all joints to the maximum possible to stop, then cuts the power to the motor and engages the brake to keep it stationary. If the predefined deceleration does not occur normally during stopping, it is switched to STO stop. Power is cut off after deceleration, and like STO, the robot can be operated after releasing the stop function and setting the Servo On. For more information about servo on methods, refer to Overview of Servo On(p. 160). 	1.78E-7 /h	PL d Cat. 3 SIL 2
3	SS2 (Safe Stop 2)	 This is the safety stop equivalent of Stop Category 2, which decelerates all joints to the maximum possible to stop, then switches it to the stop status monitoring function. If the predefined deceleration does not occur normally during stopping, it is switched to STO stop. All joints are stopped with maximum deceleration by a Stop Mode corresponding to Stop Category 2, and SOS (Safe Operating Stop) is engaged. 	1.78E-7 /h	PL d Cat. 3 SIL 2
4	Reflex Stop (RS1)	It is the safety stop function corresponding to Stop Category 2, and it utilizes Floating Reaction (a function to comply with the external force for a moment after the collision is detected) to respond to external force, and Safe Operating Stop (SOS) is engaged. • If excessive location, change in direction or speed is detected during Floating Reaction, or if deceleration is not done appropriately during stopping, STO stop is engaged.	1.93E-7 /h	PL d Cat. 3 SIL 2

1.7.2 Safety-rated Stop Function


	Safety Function	Safety Function Trigger Condition Triggering Event	Intended Action Intended result	PFHd	PL, SIL
1	Emergency Stop	If the Emergency Stop switch connected to the TBSFT EM terminal is pressed If the Emergency Stop switch of the teach pendant is pressed	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO or SS1	2.87E-8 /h	PL e Cat. 4 SIL 3
2	Protective Stop	In case the protective equipment connected to the PR terminal of TBSFT is activated,	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO, SS1, or SS2	1,78E-7 /h	PL d Cat. 3 SIL 2

• How to resume work after a protective stop

If the tool center point (TCP) of the robot is within the Collaborative Zone and the Nudge function is enabled, the user can apply force to the robot directly (Nudge) to resume work. For more information, refer to Setting the Collaborative Zone(p. 226) and Nudge(p. 231).

Emergency Stop

The Emergency Stop button is available to stop the system in case of an emergency. In emergency situations, press the Emergency Stop button in the top right corner of the teach pendant to immediately stop the system.





Note

- Emergency stops should be used as a complementary protective measure, not as a safeguard.
- The safety stop mode for the emergency stop is set to Safe Stop 1 (SS1) by default.
- Additional Emergency Stop buttons can be installed if deemed necessary as a result of evaluating the risk to the robot application.
- The Emergency Stop button must comply with IEC 60947-5-5.
- If an emergency stop triggered through the port set in Safety I/O, the button capable of accessing the screen for Safety Input setting at the bottom of the emergency stop popup window is enabled.

Protective Stop

The robot also features Protective Stop function which can stop the robot using pressure sensitive protective equipment, such as safety matts, or electro-sensitive protective equipment, such as light curtain laser scanners.

For more information about connecting protective devices, refer to Setting the Terminal Block for Contact Input (TBSFT)(p. 126) and Configuring Configurable Digital I/O (TBCI1 - 4,TBCO1 - 4)(p. 118).

1.7.3 Safety-rated Monitoring Function

Doosan robots provide safety-rated monitoring functions that can be used as a risk reduction measure through risk assessment. The threshold detected by each monitoring function can be configured in the Robot Parameter > Safety Settings > Robot Limits.

Note

- Safety limits is the condition where the safety-rated monitoring function triggers the stop function. When stop is completed, the position of the robot and force applied externally may differ from the configured safety limit.
- PFHd (Probability of a dangerous Failure per Hour): The probability of dangerous safety-related system/subsystem failures occurring in an hour
- PL (Performance Level): The performance level of safety-related components (SRP/CS) of control system according to ISO 13849-1
- SIL (Safety integrity level): The safety integrity level of safety-related electronic control systems (SRECS or SCS) according to IEC 62061

	Safety Function	Safety Function Trigger Condition	Intended Action	PFHd	PL, SIL
	runction	Condition			
1	SOS (Safe Operating Stop)	The current position is maintained with power supplied to the motor and the brake disengaged (Servo ON state). If the angle of one axis exceeds a certain angle when stopped	STO	1.78E-7 /h	PL d Cat. 3 SIL 2
2	SLP (Joint Angle Limit)	If any of the axis angles exceed the configured limit	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO, SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2
3	SLS (Joint Speed Limit)	If any of the axis speeds exceed the configured limit	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2
4	SLT (Joint Torque Limit)	If the torque applied to each axis exceeds the predefined limit	Emergency Stop is engaged according to the configured safety stop mode. • STO	1.93E-7 /h	PL d Cat. 3 SIL 2

	Safety Function	Safety Function Trigger Condition	Intended Action	PFHd	PL, SIL
5	Collision Detection	If any of the torques applied to each axis exceed the limit for configured collision detection sensitivity	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, SS2, or RS1 • Stop Mode for Collaborative Zone and Standalone Zone can be set individually.	1.93E-7 /h	PL d Cat. 3 SIL 2
6	TCP/Robot Position Limit	When the TCP or robot (including Tool Shape) deviates from or encroaches the range set in the space limit,	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO, SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2
7	TCP Orientation Limit	If the difference between the set direction and the TCP orientation exceeds the configured threshold within the Tool Orientation Limit Zone,	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2
8	TCP Speed Limit	If the TCP speed exceeds the configured threshold	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2
9	TCP Force Limit	If the external force applied to the TCP exceeds the configured limit	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, SS2, or RS1 • Stop Mode for Collaborative Zone and Standalone Zone can be set individually.	1.93E-7 /h	PL d Cat. 3 SIL 2

	Safety Function	Safety Function Trigger Condition	Intended Action	PFHd	PL, SIL
10	Robot Momentum Limit	If the momentum of the robot exceeds the configured limit	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2
11	Mechanical Power Limit	If the mechanical power of the robot exceeds the configured threshold,	Emergency Stop is engaged according to the configured Safety Stop Mode. • STO(Except for H/P Series), SS1, or SS2	1.78E-7 /h	PL d Cat. 3 SIL 2

1.7.4 Safety-rated I/O

Doosan robots provide a safety rated input interface for connecting protective devices, emergency stop switches, activation switches and control devices from safety protection devices. It also provides a safe rated output interface that can output mode and status information of the robot as well as whether the TCP is in various types of safe zones.



- PFHd (Probability of a dangerous Failure per Hour): The probability of dangerous failures of safety-related system/subsystem per hour
- PL (Performance Level): The performance level of safety-related components (SRP/CS) of control system according to ISO 13849-1
- · SIL (Safety integrity level): The safety integrity level of safety-related electronic control systems (SRECS or SCS) according to IEC 62061

	Safety Function	Description	PFHd	PL, SIL
1	Safety IO	A duplexed interface for safety related signal input and output If the input signals do not match or if duplexed output signal feedbacks do not match, it stops the robot and displays an error message.	4.04E-8 /h	PL d Cat. 3 SIL 2

It is the safety-rated input and output, and it offers following functions: For more information, refer to Safety Signal I/O(p. 33).

Safety Input	Safety Output
Emergency Stop (L), Emergency Stop - No Loopback (L),	Emergency Stop (L), Emergency Stop - excl. No Loopback Input (L),
Protective Stop (L), Protective Stop - STO (L), Protective Stop - SS1 (L), Protective Stop - SS2 (L),	Safe Torque Off (L), Safe Operating Stop (L), Abnormal (L), Normal Speed (L), Reduced Speed (L),
Protective Stop (L) - Auto Reset & Resume (R), Interlock Reset (R), Reduced Speed Activation(L),	Auto Mode (L), Manaul Mode (L), Remote Control Mode (L), Standalone Zone (L), Collaborative Zone (L)
3-Pos Enable Switch (H), Handguiding Enable Switch (H), Remote Control Enable (H),	High Priority Zone (L), Tool Orientation Limit Zone (L), Designated Zone (L)
Safety Zone Dynamic Enable (H), Safety Zone Dynamic Enable (L), HGC End & Task Resume (R)	

1.8 Safety Function Settings

	Classification	Safety Settings	Description
1	Basic/Universal Settings	World Coordinates Setting(p. 173)	A coordinate system representing the robot and workpiece can be set.
		Robot Limits Setting(p. 195)	The universal safety limit for joints and robot/TCP safety-rated monitoring functions can be set.
		Safety Signal I/O Setting(p. 195)	Configurable digital I/O ports can be set as safety signal I/Os.
		Safety Stop Modes(p. 195)	The Stop Mode can be set when the Emergency Stop or Protective Stop is activated, or when the safety-rated monitoring function detects limit violation.
		Nudge(p. 231)	Parameters related to the nudge function, which is capable of resetting Protective Stop or resuming auto operation of the robot can be set when specific conditional are met.
2	Tool and Robot Pose	Tool Weight Setting(p. 185)	The workpiece payload, which acts as the basis for control and safety functions, can be set.
		Tool Shape Setting(p. 185)	Robot tool shapes, which are used in space limit and self-collision prevention functions, can be set.
		Mount (Robot Installation Pose) Setting(p. 170)	The robot installation pose can be set.
3	Space Limit	Space Limit Setting(p. 226)	The robot/TCP position limit function can be activated.

	Classification	Safety Settings	Description
4	Zone	Setting the Collaborative Zone(p. 226)	It is the zone which can be set for collaborative work between robot and operator. • Nudge or hand guiding control (HGC) functions can only be performed in the Collaborative Zone. • The task speed and joint speed can be decelerated automatically by setting deceleration rate, and the collision detection sensitivity, TCP force limit, TCP
			 speed limit and Safety Stop Mode are overridden within the Zone. Zones that are not set as the Collaborative Zone are treated as Standalone Zone of the robot.
		Setting the Crushing Prevention Zone(p. 226)	The robot work position and space around obstacles can be set to reduce the risk of limbs jamming between robots and obstacles.
			 The robot TCP speed, collision sensitivity and safety stop mode are fixed at 200 mm/s or less, 100% and RS1 respectively, and the TCP force limit is overridden within the Zone. It is treated as the Collaborative Zone.
		Setting the Collision Sensitivity Reduction Zone(p. 226)	Just like the case where force must be applied via contact with the workpiece, collision detection and TCP force limit safety functions can be disabled (Muting) or can be used to ease off the limit.
			 Unlike other zones, the collision detection sensitivity and TCP force limit can be set lower and higher than the universal limit respectively in the Collision Sensitivity Reduction Zone. It is treated as a High Priority Zone.
		Setting the Tool Orientation Limit Zone(p. 226)	This can be used to reduce risks related to the direction of the workpiece or tool of the robot.
			 If the tool center point (TCP) is positioned within the Zone, the TCP Orientation Limit safety function is activated.

Classification	Safety Settings	Description
	Setting the custom zone(p. 226)	Safety limits can be used differently by zones depending on the necessity of robot application.
		 The selected safety limits is overridden within the Zone. Properties of Collaborative Zone or High Priority Zone can be granted.

1.8.1 Safety Signal I/O

This function is used to input/output safety-related signals to the redundant terminals. If any of the safety input/output signals are detected to have a different redundant signal, it determines an open circuit or hardware failure and stops the robot in STO stop mode. Safety Signal I/O can be set in **Robot Parameters > Safety Settings > Safety I/O**.

Safety Input Setting

Signal Name	Description
Emergency Stop (L)	This is used for the purpose of receiving an Emergency Stop signal from the robot device or connecting an Emergency Stop Switch additionally installed around the robot. • High: Normal operation • Low: This will cause the robot to stop according to the Safety Stop Mode of Emergency Stop set in the Safety Stop Mode.
Emergency Stop - No Loopback (L)	This is used for the purpose of receiving an Emergency Stop signal from the robot device or connecting an Emergency Stop Switch additionally installed around the robot. This signal does not enable the "Emergency Stop – excl. No Loopback Input" safety output. No Loopback Input' No safe output is enabled. • High: Normal operation • Low: This will cause the robot to stop according to the Safety Stop Mode of Emergency Stop set in the Safety Stop Mode.
Protective Stop (L)	It can be used in conjunction with Safeguarding Devices such as safety mats, light curtains, laser scanners, etc. • High: Normal operation • Low: This will cause the robot to stop according to the Safety Stop Mode of Protective Stop set in the Safety Stop Mode.

- 33 -

Signal Name	Description
Protective Stop - STO (L)	 High: Normal operation Low: It immediately cuts off the power to the motor and activates the brakes to force the robot to stop.
Protective Stop - SS1 (L)	 High: Normal operation Low: After a control stop, it cuts off the power to the motor and activates the brakes.
Protective Stop - SS2 (L)	 High: Normal operation Low: After a control stop, Safe Operating Stop
Protective Stop (L) - Auto Reset & Resume (R)	Unlike Protective Stop this signal can reset the Interrupted state and automatically resume operation. This enables automatic restart after Safety-rated Monitored Stop as described in ISO TS 15066.
	 Low: It follows Protective Stop - SS2. Rising (Low to High): Operation is automatically resumed without manual reset or resume.
	 Warning Automatically resuming operation without direct intervention may be dangerous. A comprehensive risk assessment must be performed to ensure that it is safe to use this signal.
Interlock Reset (R)	This is used to reset a state changed to Interrupted by Protective Stop. • Rising (Low to High): This allows the interlock to be reset and returned to normal standby.
Reduced Speed Activation (L)	 High: Operates the robot at the normal speed set in the task. Low: It operates the robot at a speed proportionately reduced from the speed set in the task. The reduction ratio can be adjusted using the Speed Reduction Ratio slide bar. When a signal is detected within the Collaborative Zone the robot operates (more slowly) according to the smaller Speed Reduction Ratio between the main Speed Reduction Ratio and the collaborative zone Speed Reduction Ratio.
3 Pos Enable Switch (H)	A work permission signal used when connecting the operation permission device to the 3-position switch. • High: Jog / servo ON available in Manual Mode Play/Resume/servo on available in Automatic Mode • Low: Jog / servo on unavailable in Manual Mode Play/Resume/servo on unavailable in Automatic Mode.

Signal Name	Description
Handguiding Enable Switch (H)	A work permission signal used when connecting the operation permission device to the handguiding enable switch. • High: Hand-guiding available • Low: Hand-guiding unavailable
HGC End & Resume (R)	When the handguiding command is executed in automatic mode, the task program stops. A signal used to resume the execution of the task program after the user has executed the handguiding control. • Rising (Low to High): The execution of the task program resumes after the HandGuiding Control is performed.
Safety Zone Dynamic Enable (H)	 This can be used to dynamically enable or disable a safe space limit or zone. This signal is only available if Dynamic Zone Enable is set when setting up space limit and zone. High: This enables space limits/zones that have been temporarily enabled or disabled by this signal. Low: This disables space limits, zones that have been temporarily enabled or disabled by this signal.
Safety Zone Dynamic Enable (L)	 This can be used to dynamically enable or disable a safe space limit or zone. This signal is only available if Dynamic Zone Enable is set when setting up space limit and zone. High: This disables any space limit/zone that were temporarily enabled or disabled by this signal. Low: This enables space limits/zones that have been temporarily enabled or disabled by this signal.
Remote Control Enable (L)	This is used to enable Remote Control Mode. • High: Enables the Remote Control Mode • Low: Disables the Remote Control Mode



- Low active safety input signals allocated at SI1 & SI2 or SI3 & SI4 on TBSI are test-pulse tolerant.
- One test pulse with a maximum duration of 1 ms is allowed every 20 ms.

Suspension of Protective Stop Signals

In robot teaching, recovery, and hand-guided control situations, the operator approaching to the robot may be intended task.

The **Suspension of Protective Stop Signals** function is provided for the protective device not to prevent these intended task.



Warning

Do conduct a comprehensive risk assessment to confirm that using this function is safe

The suspension of the protective stop related signals can be set per robot state group.

The protective stop related signal input is ignored when the robot is in the state included in the unchecked state group.

When the robot enters the automatic states, this function is terminated and the protective stop related signals are all activated.

The following are the protective stop related signals that can be suspended.

- TBSFT PR
- TBCI Protective Stop (L)
- TBCI Protective Stop STO (L)
- TBCI Protective Stop SS1 (L)
- TBCI Protective Stop SS2 (L)
- TBCI Protective Stop (L) Auto Reset & Resume (R)

The following are the state groups that the protective stop related signals can be suspended and the states they contain.

- MANUAL Group- Manual Standby, Manual Jogging, Manual Handguiding
- RECOVERY Group- Recovery Standby, Recovery Jogging, Recovery Handguiding
- HGC Group- HGC Standby, HGC Running

Safety Output Setting

Signal Name	Description
Emergency Stop (L)	Used to notify robot peripherals that an Emergency Stop is required in the following situations.
	- When the Emergency Stop button on a robot accessory is pressed (teach pendant, smart pendant or emergency stop button box)
	- When an E-stop signal is input to a dedicated safety input terminal
	- When an Emergency Stop (L) signal is input from a configurable input terminal to the Safety Input
	- When an Emergency Stop – No Loopback(L) signal is input from a configurable input terminal to the Safety Input
	 High: Normal operation Low: Emergency stop required
Emergency Stop - excl. No Loopback	Used to notify robot peripherals that an Emergency Stop is required in the following situations.
Input (L)	- When the Emergency Stop button on a robot accessory is pressed (teach pendant, smart pendant or emergency stop button box)
	- When an Emergency Stop (L) signal is input from a configurable input terminal to the Safety Input
	- When an Emergency Stop – No Loopback(L) signal is input from a configurable input terminal to the Safety Input
	Except when the signal is Emergency Stop – No Loopback (L) on a configurable Safety Input.
	With this signal, deadlock can be avoided because the Emergency Stop signal is not sent back to the peripheral that sent the Emergency Stop signal.
	 High: Normal operation Low: Emergency stop required
Safe Torque Off (L)	 High: The robot is not servo off, and not in emergency stop state. Low: The robot is servo off and in emergency stop state.
Safe Operating Stop (L)	 High: The robot is not in the Standby State. Low: The robot is in the Standby State and Standstill monitoring is enabled.
Abnormal (L)	 High: The robot is not in an Interrupted, Recovery, or Auto Measure state. Low: The robot is in either Interrupted, Recovery, or Auto Measure state.
Normal Speed (L)	 High: The robot is operating at a reduced speed due to an external Reduced Speed Activation safety input signal. Low: Robot operating at normal speed

Signal Name	Description
Reduced Speed (L)	 High: Robot operating at normal speed Low: The robot is operating at a reduced speed due to an external Reduced Speed Activation safety input signal.
Auto Mode (L)	 High: The robot is not currently in Auto Mode. Low: The robot is currently in Auto Mode
Manual Mode (L)	 High: The robot is not currently in Manual Mode. Low: The robot is currently in Manual Mode.
Remote Control Mode (L)	 High: The robot is not currently in Remote Control Mode. Low: The robot is currently in Remote Control Mode.
Standalone Zone (L)	 High: The robot's TCP is located in one of the Collaborative Zones. Low: The robot's TCP is not in any Collaborative Zone.
Collaborative Zone (L)	 High: The robot's TCP is not in any Collaborative Zone. Low: The robot's TCP is located in one of the Collaborative Zones.
High Priority Zone (L)	 High: The robot's TCP is not located in any Collision Sensitivity Reduction Zone and the High Priority Zone option is not checked on the Custom Zone. Low: The robot's TCP is located in one of the Collision Sensitivity Reduction Zones or the High Priority Zone option is checked on the Custom Zone.
Tool Orientation Limit Zone (L)	 High: The robot's TCP is not located in any Tool Orientation Limit Zone. Low: The robot's TCP is located in one of the Tool Orientation Limit Zones.
Designated Zone (L)	This is used to check whether the Tool Center Point (TCP) is located within the user-defined zone. The Designated Zone signal defined in the Safety Output settings screen can be selected on the Zone settings screen. • High : TCP is not within any zone associated with a Designated Zone Safety Output. • Low : TCP is in the zone associated with a Designated Zone Safety Output.

1.8.2 Safety Stop Modes

The safety-rated monitoring function can detect limit violations and set the Stop mode used when stopping the robot.

• For more information about Stop Mode, refer to Safety-rated Stop Subfunction(p. 23).

Safety Stop Modes can be set in **Robot Parameter > Safety Settings > Safety Stop Modes**. For more information about each item, refer to Safety-Rated Monitoring Function(p. 26).

	Safety Stop Mode	Description
1	Emergency Stop	It sets the Stop Mode when the Emergency Stop button of the teach pendent or the additionally installed external device is activated. (Only STO or SS1 can be selected.)
2	Protective Stop	It sets the Stop Mode when the externally connected protective equipment is activated.
3	Joint Angle Limit Violation	It sets the Stop Mode when the angle of each joint exceeds the set limit range.
4	Joint Speed Limit Violation	It sets the Stop Mode when the angle joint speed of each joint exceeds the set limit range.
5	Collision Detection	It sets the Stop Mode when the external force applied to the axis exceeds the set limit range. Stop modes for Collaborative Zone and Standalone Zone can be set individually. In addition to STO , SS1 and SS2 , RS1 can be set to the stop mode.
6	TCP/Robot Position Limit Violation	It sets the Stop Mode activated when the tool center point (TCP) and robot position violate the Space Limit of the Robot set in the Workcell Manager . It also determines whether the TCP is within the Safety Zone (Collaborative Zone , Crushing Prevention Zone , Collision Sensitivity Reduction Zone , Tool Orientation Limit Zone , or Custom Zone).
7	TCP Orientation Limit Violation	It sets the Stop Mode when the tool center point (TCP) orientation within the TCP Orientation Limit Zone exceeds the angle limit range set by the Robot through the Workcell Manager .
8	TCP Speed Limit Violation	It sets the Stop Mode when the speed of the tool center point (TCP) exceeds the set limit range.
9	TCP Force Limit Violation	It sets the Stop Mode when the external force applied to the tool center point (TCP) exceeds the set limit range. Stop modes for Collaborative Zone and Standalone Zone can be set individually. In addition to STO, SS1 and SS2, RS1 can be set as the Stop Mode.
10	Momentum Limit Violation	It sets the Stop Mode when the robot momentum exceeds the set limit.

	Safety Stop Mode	Description
11	Mechanical Power Limit Violation	It sets the Stop Mode when the mechanical power of the robot exceeds the set limit.

1.8.3 Nudge

If the robot is stopped by Safety Stop Mode SS2 or RS1 within a Collaborative Zone, the Interrupted state can be reset and task can be resumed with Nudge input. Nudge option can be enabled on user defined sections.

To set Nudge, select the **Nudge** item from the **Robot Workcell**. With nudge input, the force to be recognized (nudge force) and the standby time from nudge recognition and until the resuming the work (delay time) can be entered additionally.

The range of force to be detected by nudge input is 10.00 to 50.00 N for the M series and 15.00 to 50.00 N for the H series (P series).



Warning

Nudge must only be used only if approved through comprehensive risk assessment.

1.8.4 Zone

Depending on the application, certain spaces may require different safety limits to be applied than the global safety limits specified in the Robot Limits Setting. It is possible to set a separate safety limit only in the designated section using the section setting function. Overridable safety limits are designated depending on the section type.

- Setting the Collaborative Zone(p. 226)
- Setting the Crushing Prevention Zone(p. 226)
- Setting the Collision Sensitivity Reduction Zone(p. 226)
- Setting the Tool Orientation Limit Zone(p. 226)
- Setting the custom zone(p. 226)

The Valid Space setting makes it possible to specify whether the overridden safety limit applies inside or outside the section.

The **Zone Margin** setting makes it possible to easily specify how the volume is scaled relative to the specified coordinates.

Safety Limits overridden in a **zone** include the following priorities:

- If a Zone is set and some Safety Limits are overridden, those Safety Limits override over the global Safety Limits.
- Safety Limits overridden in a High Priority Zone override over Safety Limits overridden in a nonprioritized zone.
- If there are multiple Safety Limits for a type of safety function at a particular TCP location, the most restrictive Safety Limit in the nested zone takes precedence.
- Because High Priority Zones are nested, if there are multiple safety limits for a type of safety function at a particular TCP location, the least restrictive Safety Limit overrides.



Warning

High Priority Zones override other zones and global robot limit settings. If multiple High Priority Zones are nested, the safety function overrides the least restrictive safety limit. For safety reasons, High **Priority Zones** should be the minimum possible size.

Select **Dynamic Zone Enable** to enable/disable the zone based on the input signals from the designated safety I/O port. If the input is not enabled, the corresponding **Space Limit** will become disabled, and the robot operates as if the corresponding **Space Limit** is not present

1.8.5 Space Limit

In addition to the robot's joint angle limit of Robot Limits(p. 195), the robot can limit the operating space on orthogonal coordinates. If the robot or TCP violates the Space Limit during auto operation or manual mode, it will stop according to the Safety Stop Mode settings. When the robot or TCP reaches the boundary of the Space **Limit** during direct teaching using hand guiding, a repelling force can be felt.

By selecting the Inspection Point, it is possible to select whether the Space Limit will target the entire robot body or only the TCP.

By selecting the Valid Space, it is possible to select whether the Inspection Point will not violate or not exceed a designated space.

It is possible to easily designate an expanded volume from designated coordinates using **Zone Margin**.

Select **Dynamic Zone Enable** to enable/disable the zone based on the input signals from the designated safety I/O port. If the input is not enabled, the corresponding **Space Limit** will become disabled, and the robot operates as if the corresponding **Space Limit** is not present

1.8.6 Robot Limits

In Robot Limits, universal safety limits of various safety functions related with robots can be set as Normal Mode and Reduced Mode.

If each robot parameter exceeds the configured safety limit, the robot activates Protective Stop. Robot limits can be set in Robot Parameter > Safety Settings > Robot Limits.



Note

- Robot can be operated after removing the cause of Protective Stop and after deactivating Protective Stop by resetting.
- If the cause of the Protective Stop by safety functions cannot be removed, Safety Recovery Mode helps for restoration to Normal Operation because there is no Protective Stop by safety functions.



Caution

The safety limit is the condition in which the safety-rated monitoring function determines whether to activate robot stop or not. When stop is completed, the position of the robot and force applied externally may differ from the configured safety limit.

TCP/Robot

It limits various physical parameters related to the TCP/robot. This safety feature can be used for power and force limited operation modes.

- TCP Force: It sets the force limit applied from the TCP of the robot end. It can be used for purposes of detecting unintended external forces.
- Mechanical Power: It sets the limit of the robot's mechanical power. Mechanical power is proportionate to the robot torque and speed.
- TCP Speed: It sets the speed limit of the TCP of the robot end. It can be used for speed and gap monitoring operation mode.
- Momentum: It sets the robot momentum limit. Momentum is proportionate to speed and weight, and the impact is the same as the physical amount.
- Collision Sensitivity: It sets the sensitivity of the collision detection function which determines whether to continue work or activate Protective Stop with the torque detected in each robot axis. If the sensitivity is 100%, it detects collisions by external forces very sensitively, and it seldom detects collision if the sensitivity is 1%.



Note

If the robot has stopped due to collision detection, the cause is one of the followings:

- 1. TCP force limit violation
- 2. Collision detection violation

Joint angle speed

It sets the maximum rotation speed of each axis. The limit can be set for each axis.



Note

- The joint angle speed is set to the maximum value as a default.
- In general, certain axis speed is not set differently among each other.

Joint angle

It sets the maximum operating angle of each axis. The limit can be set for each axis.

- All axes are capable of +/- 360 degree rotation, but the joint angle value is set to a limit in Normal Mode as a default.
- If the robot is installed on the ground, it is recommended to set the operation range of the axis No.2 to +/-95 degrees to prevent the collision.
- If the robot is installed on a cylindrical pillar or if you deal with a workpiece close to the robot base, the joint angle limit can be modified to allow a wider operating range.



Adding Workcell Items in the Zone allows a separate safety limit to be set for designated zones. Safety limits which are capable of overriding are designated depending on the zone type. For more information, refer to the following link.

- Setting the Collaborative Zone(p. 226)
- Setting the Crushing Prevention Zone(p. 226)
- Setting the Collision Sensitivity Reduction Zone(p. 226)
- Setting the Tool Orientation Limit Zone(p. 226)
- Setting the custom zone(p. 226)

1.9 Other Safety Measures

For user safety and robot safety recovery, we provide a Safety Recovery mode and an Unpowered Operation mode.

- **Safety Recovery Mode**: If there is an error with a continuing safety violation or if a robot needs to be packed for transportation, the user can use the Safety Recovery Mode to configure the position and angle of the robot. For more information on Safety Recovery mode, see the Recovery module(p. 164).
- **Unpowered Operation**: This function controls the joints of the robot by external force by releasing only the brake with the power to the motor cut off. This function is used when Safety Recovery Mode or Handguiding is not able to return the robot to a normal status. With the Unpowered Operation mode, the brake of each joint can be engaged or disengaged by the user. For more information on unpowered operation, see Using the Backdrive Module(p. 161).

1.10 Legal Notice

1.10.1 Validity and Responsibility

This manual does not provide information about the design, installation and operation methods of robot applications integrated with other system. In addition, this manual does not provide information that may influence the safety of the integrated system.

The system administrator must install the robot in a way that observes various safety requirements according to the related national standards and regulations. In addition, the staff in charge of integrating and managing the robot in a system must ensure that all related national safety legislation and regulations are observed. The entity or user of the final system in which the robot is integrated has the following responsibilities, and such responsibilities are not limited to the items listed below.

- Risk assessment of the system with the robot integrated
- Installation and removal of safety devices according to the outcome of the risk assessment performed
- Confirmation of whether the system is properly designed, set up and installed
- Establishment of system operation and instructions
- Management of suitable safety settings in the software
- Prevention of users modifying safety devices
- Validity check of design and installation of integrated system
- Indication of contact information or important notifications related to use and safety
- Provision of technical documents including various manuals
- Provision of information on standards and legislation applied: http://www.doosanrobotics.com/

Compliance with the safety requirements in this manual does not mean all risks can be prevented.

1.10.2 Disclaimer

Doosan Robotics continues to upgrade product reliability and performance, and Doosan Robotics has the right to upgrade the product without notification. Doosan Robotics endeavors to ensure that all contents in this manual are accurate. However, it does not assume responsibility for errors or missing information.

1.11 Potential Risks

- Jamming fingers between the manipulator base and mount
- Jamming limbs between the Link 1 and Link 2 (between Joint 3 (J3) and Upper Link)
- Jamming limbs between Joint 1 and Joint 2 (J1 and J2) and Joint 5 and Joint 6 (J5 and J6)
- Penetration of skin by sharp edges or surfaces of the tool
- Penetration of skin by sharp edges or surfaces of objects in the operating space of the robot
- Contusion caused by robot movement
- Bone fracturing due to movement between heavy payload and hard surface
- Accidents that occur due to loosening of bolts securing the robot flange or tool
- Object falls from the tool due to inappropriate grip or sudden power shortage
- Accidents that occur due to mistaking an emergency stop button of different equipment
- Errors that occur due to unauthorized safety parameter modification

1.12 Declaration and Certification

1.12.1 Europe Machinery Directive Attestation of Conformity

٠

•

•



Attestation

No. M7 004249 0092 Rev. 00

Holder of Attestation: Doosan Robotics Inc.

79, Saneop-ro 156beon-gil, Gwonseon-gu Suwon-si, Gyeonggi-do 16648 REPUBLIC OF KOREA

Product: Industrial Robot

(Manipulator & Controller)

Model(s): Manipulator: P3020

Controller: CS-11, CS-11P

Parameters: Manipulator

Rated payload: Degree of freedom: 5 axis Weight: 83 kg

Controller CS-11 CS-11P

Rated input voltage: 100-240 V a.c., 1 Phase 100-240 V a.c., 1 Phase 50/60 Hz

Rated frequency: 50/60 Hz Rated input current: 10 A 10 A Weight: 9.8 kg 21.7 kg

EN ISO 10218-1:2011 EN ISO 12100:2010 Tested according to: EN 60204-1:2018

This Attestation of Conformity is issued on a voluntary basis according to Council Directive 2006/42/EC relating to machinery. It confirms that the listed equipment (partly completed machine) complies with the requirements set in article 13 of the directive and is based on the technical specifications applicable at the time of issuance. It refers only to the particular sample submitted for conformity assessment. For details see: www.tuvsud.com/ps-cert

MAEB01159625 Test report no.:

2025-03-13 Date.

(Ro-Hyun Park)

This Attestation does not replace the regulatory EU Declaration of Conformity (DoC) and does not allow for CE marking. Partly completed machines are designated to be assembled in a machine, which complies with the requirements set in the Machinery Directive 2006/42/EC and for which a Declaration of Conformity according to Annex II A of the Machinery Directive 2006/42/EC needs to be drawn up

TÜV SÜD Product Service GmbH • Ridlerstraße 65 • 80339 Munich • Germany

•

٠

1.12.2 Europe EMC Directive Attestation of Conformity



Attestation of Conformity

No. E8A 004249 0091 Rev. 00

Holder of Attestation: Doosan Robotics Inc

79, Saneop-ro 156beon-gil, Gwonseon-gu

Suwon-si, Gyeonggi-do 16648 REPUBLIC OF KOREA

Name of Object: Industrial Robot

(Manipulator & Controller)

Model(s): Manipulator: P3020

Controller: CS-11

Description of

Object:

Rated input voltage: 100-240 V a.c., 1 Phase

Rated input frequency: 50/60 Hz

Tested EN 61000-6-2:2005 EN IEC 61000-6-2:2019 EN 61000-6-2:2019 EN 61000-6-2:2019

EN 61000-6-4:2007/A1:2011 EN IEC 61000-6-4:2019 EN 61000-3-2:2014 EN 61000-3-3:2013

This Attestation of Conformity is issued on a voluntary basis according to the Directive 2014/30/EU relating to electromagnetic compatibility. It confirms that the listed apparatus complies with the principal protection requirements of the directive and is based on the technical specifications applicable at the time of issuance. It refers only to the particular sample submitted for conformity assessment. For details see: www.tuvsud.com/ps-cert

Test report no.: CPSC01458224

Date, 2024-12-23

(Yong-Tae Yu)

Page 1 of 1

This Attestation does not replace the regulatory EU Declaration of Conformity (DoC) and does not allow for CE marking. After preparation of the necessary documentation and establishing compliance to requirements of all applicable directives, the manufacturer may sign a DoC and apply the CE marking. The DoC is issued under the sole responsibility of the manufacturer.

TÜV SÜD Product Service GmbH • Ridlerstraße 65 • 80339 Munich • Germany

٠



Attestation of Conformity

No. E8A 004249 0090 Rev. 00

Holder of Attestation: Doosan Robotics Inc

79, Saneop-ro 156beon-gil, Gwonseon-gu

Suwon-si, Gyeonggi-do 16648 REPUBLIC OF KOREA

Name of Object: **Industrial Robot**

(Manipulator & Controller)

Model(s): Manipulator: P3020

Controller: CS-11P

Description of

Rated input voltage:

100-240 V a.c., 1 Phase

Rated input frequency: 50/60 Hz

Object: Tested according to:

EN 61000-6-2:2005 EN IEC 61000-6-2:2019

EN 61000-6-4:2019 EN 61000-6-4:2011 EN 1EC 61000-6-4:2019 EN 61000-3-2:2014 EN 61000-3-3:2013

This Attestation of Conformity is issued on a voluntary basis according to the Directive 2014/30/EU relating to electromagnetic compatibility. It confirms that the listed apparatus complies with the principal protection requirements of the directive and is based on the technical specifications applicable at the time of issuance. It refers only to the particular sample submitted for conformity assessment. For details see: www.tuvsud.com/ps-cert

CPSC01456824 Test report no.:

Date. 2024-12-13

This Attestation does not replace the regulatory EU Declaration of Conformity (DoC) and does not allow for CE marking. After preparation of the necessary documentation and establishing compliance to requirements of all applicable directives, the manufacturer may sign a DoC and apply the CE marking. The DoC is issued under the sole responsibility of the manufacturer.

TÜV SÜD Product Service GmbH • Ridlerstraße 65 • 80339 Munich • Germany

◆ CEPTUФUKAT ◆ CERTIFICADO ◆ CERTIFICAT

CERTIFICATE ◆ 黥

ZERTIFIKAT

1.12.3 U.S. NRTL Certification (US, CANADA)

SHA NRTL





CERTIFICATE

No. U8 004249 0093 Rev. 00

Holder of Certificate: Doosan Robotics Inc

79, Saneop-ro 156beon-gil, Gwonseon-gu Suwon-si, Gyeonggi-do 16648 REPUBLIC OF KOREA

Certification Mark:



Product: Industrial Robot

(Manipulator & Controller)

This product was voluntarily tested to the relevant safety requirements referenced on this certificate. It can be marked with the certification mark above. The mark must not be altered in any way. This product certification system operated by TÜV SÜD America Inc. most closely resembles system 3 as defined in ISO/IEC 17067. Certification is based on the TÜV SÜD "Testing, Certification, Validation and Verification Regulations (TCVVR)". TÜV SÜD America Inc. is an OSHA recognized NRTL for USA and a Standards Council of Canada ISO/IEC 17065 accredited Certification body for Canada.

Test report no.: MAEA07159425

Date, 2025-02-06

(Ro-Hyun Park)

of 2 TUV®

TÜV SÜD America, Inc. • 401 Edgewater Place Suite #500 • Wakefield • MA 01880 • USA

User manual (V3.4.0)







CERTIFICATE

No. U8 004249 0093 Rev. 00

Model(s): Manipulator: P3020 Controller: CS-11, CS-11P

UL 1740:2018/R:2023-08 CSA Z434:2014/U1:2017-02 Tested according to:

Parameters:

Manipulator

Rated payload: 30 kg Degree of freedom: 5 axis Weight: 83 kg

CS-11 100-240 V a.c., 1 Phase Controller CS-11P

Rated input voltage: 100-240 V a.c., 1 Phase

Rated frequency: Rated input current: 50/60 Hz 50/60 Hz 10 A 10 A Weight: 9.8 kg 21.7 kg

Page 2 of 2

TÜV SÜD America, Inc. • 401 Edgewater Place Suite #500 • Wakefield • MA 01880 • USA

TUV®

CERTIFICADO CEPTUФИКАТ CERTIFICATE

1.12.4 Functional Safety certification





CERTIFICATE

No. Z10 004249 0080 Rev. 00

Holder of Certificate: Doosan Robotics Inc

79, Saneop-ro 156beon-gil, Gwonseon-gu Suwon-si, Gyeonggi-do 16648 REPUBLIC OF KOREA

Certification Mark:



Product: Robot Safety Unit

The product was tested on a voluntary basis and complies with the essential requirements. The certification mark shown above can be affixed on the product. It is not permitted to alter the certification mark in any way. In addition the certification holder must not transfer the certificate to third parties. This certificate is valid until the listed date, unless it is cancelled earlier. All applicable requirements of the Testing, Certification, Validation and Verification Regulations of TÜV SÜD Group have to be complied. For details see: www.tuvsud.com/ps-cert

Test report no.: DG102165T

Valid until: 2029-03-03

Date, 2024-03-15

(Gert Effenberger)

ge 1 of 2

TÜV SÜD Product Service GmbH • Certification Body • Ridlerstraße 65 • 80339 Munich • Germany

TÜV[®]



CERTIFICATE

No. Z10 004249 0080 Rev. 00

Suitable for: ISO TS 15066:2016, ISO 10218-1:2011 Parameters:

Safety functions:

SIL3, PL e, CAT4 STO, SBC, Emergency Stop:

SS1, SS2, SOS, SLP, SLS, SLT, Protective Stop, TCP/Robot Position Limit, TCP Orientation Limit, TCP Speed Limit, TCP Force Limit, Robot Momentum Limit, Robot Power Limit, Collision Detection, Safety I/O, Reflex Stop: SIL2, PL d, CAT3

Safety I/O input	Safety I/O output
Emergency Stop,	Emergency Stop,
Emergency Stop – No Loopback,	Emergency Stop - excl. No Loopback
Protective Stop,	Input,
Protective Stop - STO,	Safe Torque Off,
Protective Stop – SS1,	Safe Operating Stop,
Protective Stop - SS2,	Abnormal,
Protective Stop - Auto Reset & Resume,	Normal Speed,
Interlock Reset,	Reduced Speed,
Reduced Speed Activation,	Auto Mode,
3-Pos Enable Switch,	Manual Mode,
Handguiding Enable Switch,	Remote Control Mode,
Remote Control Enable,	Standalone Zone,
Safety Zone Dynamic Enable,	Collaborative Zone,
HGC End & Task Resume	High Priority Zone,
	Tool Orientation Limit Zone,
	Designated Zone
2	The state of the s

IEC 61508-1:2010 Tested IEC 61508-2:2010 IEC 61508-3:2010 according to: IEC 61800-5-2:2016 ISO 13849-1:2023

IEC 62061:2021 IEC 61000-6-7:2014

Model(s): Safety Controller for Single & Multi-powered Robot

Page 2 of 2 TÜV SÜD Product Service GmbH • Certification Body • Ridlerstraße 65 • 80339 Munich • Germany

1.12.5 Voluntary Safety Confirmation Declaration (KCs)




자율안전확인 신고증명서

자육아전인	증대상 기계 · 기구		산업용로봇	
	소재지	(16648) 경기도 수	입시 권서구 사언로1	156버긴 79(고생동)
신청인	사업자등록번호	257-88-00128	대표자 성명	류정훈,박인원
	사업장명	두산로보틱스(주)	사업장관리번호	257-88-001280

「산업안전보건법」 제89조제1항 및 같은 법 시행규칙 제120조제3항에 따라 자율안전확인 신고증명서를 발급합니다.

2025년 02월 04일



1.13 Stop Distance and Stop Time

1.13.1 Measurement Methods and Conditions

- Stop distance is the angle traveled from the moment a stop signal is generated to the moment all manipulator stop operation.
- Stop time is the time from the moment a stop signal is generated to the moment all manipulator stop
- Stop distance and stop time data are provided for Joint 1, Joint 2 and Joint 3, which have large travel distances.
- The movement of an overlapping axis can cause a longer stop distance.
- Stop distance and stop time data are defined according to KS B ISO 10218-1:2011 Declaration and Certification(p. 46).

Stop Category

	Stop Category	Description
1	Stop Category 0	The stop distance and stop time of Joint 1 (Base), Joint 2 (Shoulder) and Joint 3 (Elbow) are measured at maximum speed, stretch level and load. The axes of Joint 2 and Joint 3 are parallel to each other, so an impact caused by forced stop on one part may cause a slip on the other side. The angle deviation is also measured.
2	Stop Category 1	The stop distance and stop time of Joint 1 (Base) and Joint 2 (Shoulder) are measured at 33%, 66% and 100% of the maximum speed, stretch level and load, respectively. The stop distance and stop time of Joint 3 (elbow) is measured at 33%, 66% and 100% of maximum speed and load. The stretch level during Joint 3 measurement is locked at maximum because of the lower arm length and completely flat wrist.

Measurement Poses and Conditions

Joint 1 measurement is performed with the rotating axis perpendicular to the ground and during horizontal movement.

Joint 2 and Joint 3 measurements are performed with the rotating axis parallel to the ground and when the robot is stopped in a downward movement vertical to the ground.



1 Note

The measurements are the result of the worst case. Measurement may vary according to circumstances

1.13.2 P3020 Stop Category

P3020 Stop Category 0

Joint 1

Extension=100%, Speed=100%, Payload=100%

	Stopping distance (rad)	Stopping time (ms)
Axis 1	0.451	435

Joint 2

Extension=100%, Speed=100%, Payload=100%

	Stopping distance (rad)	Stopping time (ms)
Axis 2	0.385	624
Axis 3	0.00430	

Joint 3


Extension=100%, Speed=100%, Payload=100%


	Stopping distance (rad)	Stopping time (ms)
Axis 2	0.0192	132
Axis 3	0.0993	

P3020 Stop Category 1


Stop Distance and Stop Time of Joint 1 (Base)

Stop Distance at Max. Load (rad)	Stop Time at Max. Load (ms)
----------------------------------	-----------------------------







Stop Distance and Stop Time of Joint 2 (Shoulder)



Stop Distance and Stop Time of Joint 3 (Elbow)

	Stop Distance at Max. Stretch Level (rad)	Stop Time at Max. Stretch Level (ms)	
--	---	--------------------------------------	--





For P3020, Stop Distance and Stop Time are not affected by payload and extension.

1.14 Upper/Lower Threshold Range and Default Value of Safety Parameters

1.14.1 P3020

Parameters		Normal		Reduced			Toleranc e	
		Min	Max	Default	Min	Max	Default	(+/-)
Joint Angle Limits	J1 (degree)	-360	360	-360~36 0	-360	360	-360~360	3/-3
	J2 (degree)	-125	125	-95~95	-125	125	-95~95	3/-3
	J3 (degree)	-160	160	-145~14 5	-160	160	-145~145	3/-3
	J4 (degree)	-	-	-	-	-	-	-
	J5 (degree)	-360	360	-135~13 5	-360	360	-135~135	3/-3
	J6 (degree)	-360	360	-360~36 0	-360	360	-360~360	3/-3
Joint Speed Limits	J1 (degree/ s)	0	100	100	0	100	100	10
	J2 (degree/ s)	0	80	80	0	80	80	10
	J3 (degree/ s)	0	80	80	0	80	80	10
	J4 (degree/ s)	-	-	-	-	-	-	-

	J5 (degree/ s)	0	200	200	0	200	200	10
	J6 (degree/ s)	0	360	360	0	360	360	10
Robot/TCP Limits	Force (N)	0	1800	280	0	1800	140	-
	Power (W)	0	1800	1200	0	1800	600	-
	Speed (mm/s)	0	4500	3000	0	4500	2250	-
	Moment um (kgm/s)	0	400	200	0	400	122	-
	Collision Detectio n Sensitivi ty (%)	1	100	75	-	-	-	-
Safety I/O	Speed Reducti on Ratio (%)	-	-	-	1	100	20	-

2 PART 2. Starting up the Robot

From Starting Up the Robot, the user can learn the overall process from robot installation to robot operation.

Step 1. Robot Installation: Install the robot and connect the controller and teach pendant. In this step, you can learn how to install and initially start up the Doosan Robotics robot.



Caution

- Before installing the robot, make sure to read and follow Cautions during Installation(p. 77) and Installation Environment(p. 93).
- For more information about robot installation, refer to PART 3. Installation Manual.(p. 77)

Step 2. Tool Installation and I/O Testing: Install the tool and test the I/O signal.

2.1 Journey Map

The journey map lists the process from the installation of Doosan Robotics robot to actual operation in sequential order. Refer to each guide item to begin using the robot.

2.1.1 Step 1. Robot Installation

	Classification	Work	Mandatory Work	Difficulty	Time (Minutes)
1	Robot Installation	Remove packing	•	EASY	3
2		Connect cable to the controller	•	EASY	1
3		Fix the robot base	•	EASY	3
4		Connect controller to robot	•	EASY	1
5		Connecting Power to Controller	•	EASY	1
6		Position controller	•	EASY	1
7	Initial start Up	Power on the controller	•	EASY	3

	Classification	Work	Mandatory Work	Difficulty	Time (Minutes)
8		Disengage emergency stop button	•	EASY	1
9		Disengage packaging pose	•	EASY	3
10		Servo Off	•	EASY	1

2.1.2 Step 2. Tool Installation and I/O Testing

	Classification	Work	Mandatory Work	Difficulty	Time (Minutes)
1	Tool Installation	Installing the tool	•	EASY	5
2	I/O Testing	Power off the system	•	EASY	1
3		Connect wires	•	NORMAL	10
4		Power on the system	•	EASY	1
5		Test controller and flange I/O	•	NORMAL	10


2.2 Robot Installation 1

2.2.1 Remove packing

MANDATORY EASY 3 MIN

Upon purchasing the Doosan Robotics robot, two boxes containing the robot and controller will be delivered. Remove the packing and check the contents. For more information about the components, refer to Component List(p. 78).

- 1. The manipulator is contained in the larger box.
- 2. The controller and teach pendant are contained in the smaller box.



Caution

- To ensure safety during delivery, all products are wrapped and packed using solid protective materials, so take caution when removing them from the box.
- When removing the product from the box, take caution not to damage to products due to falling.


2.2.2 Connect cable to the controller

MANDATORY EASY 1 MIN

Connect the teach pendant and robot cable to the controller.

1. Connect the teach pendant cable to the corresponding connections on the controller until it clicks and please make sure that the cable is plugged in tightly.

2. Connect the opposite end of the robot cable to the corresponding connection of the controller until it clicks and please make sure that the cable is plugged in tightly.



Caution

- When connecting the cable, check the shape of the connection before connecting it so that the pin does not bend.
- If the noise generated by electromagnetic waves causes issues, it is necessary to install a ferrite core to ensure normal operation. For more information about the ferrite core installation location, refer to the followings:
 - Connecting Manipulator to Controller(p. 98)
 - Connect Controller to Teach Pendant(p. 98)

2.2.3 Fix the robot base



When fixing the robot base and when installing a tool on the tool flange, the following additional components are required:

- M8 hexagonal wrench bolt 4
- Φ5 place marker 2

Use M8 bolts in the four 9.0 mm holes on the manipulator base to fix the robot. For more information, refer to Fixing the Robot(p. 95).

- It is recommended to use tightening torque of 20 Nm to tighten the bolts. Use washers (spring-flat) to prevent loosening by vibration.
- Use two Φ5 place marker pins to accurately install the robot in a fixed location.

1 Note

- M/A/H/E/P Ground Tap Fastening Guide
- 1. Ground tap added to Robot Base ('23 December related design change approval completed: ECO00371_Robot Base Ground Bolt Fastening Part Added)
- 2. Ground bolt is not included, users can prepare and fasten it themselves as needed
- 3. Ground bolt specifications: M4X4L
- 4. Guide text example: All robots of Doosan Robotics are provided with an external ground tap. If grounding is required depending on the usage environment, you can connect the ground wire using the M4X4L bolt. The ground tap is located near the ground label.
- 5. Ground label



2.3 Robot Installation 2

2.3.1 Connecting Power to Controller

MANDATORY EASY 1 MIN

To supply power to the controller, connect the power cable of the controller to a standard IEC power outlet.

- Please make sure the robot is properly grounded after connecting the power cables (Electrical Ground Connections).
- Establish a common ground for all equipment in the system with unused bolts related to the ground symbol inside the controller. The ground conductor must satisfy the maximum current rating of the system.
- For more information, refer to Connecting Power to Controller.(p. 98)

The power supply must satisfy minimum requirements such as ground and circuit breakers. The electrical specifications of the included AC controller are as follows:

Parameter	Specifications
Input Voltage	100 – 240 VAC
Input Power Fuse (@100-240V)	15 A
Input Frequency	47 – 63 Hz

2.3.2 Position controller

MANDATORY EASY 1 MIN

When installing the controller on the floor, secure at least 50 mm of space on each side of the controller to enable ventilation.



Caution


• Please ensure that the cables have curvatures greater than the minimum curvature radius. For more information, refer to Placing the Cable(p. 95).

2.4 Initial start Up

2.4.1 Power on the controller



1. Press the power switch at the bottom of the controller. The power for systems such as the robot, controller and teach pendant is turned on.



2. Press and hold the power button (Fig. 2) until the teach pendant screen powers up The teach pendant LED (Fig. 1) and flange LED (Fig. 3) will blink red until the robot controller connects to the network.



• For more information about equipment other than the teach pendant, refer to System Power on/off(p. 144).




LED positions of each Doosan Robotics robot series are as follows:

- A: Flange LED
- B: Axis 1 LED



2.4.2 Disengage emergency stop button



After robot installation and after the initial system boot up, a warning popup is displayed as the emergency stop button of the teach pendant is pressed. The emergency stop button must be disengaged in order to operate the robot.


• Twist the emergency stop button clockwise to disengage the emergency stop state.

2.4.3 Disengage packaging pose

MANDATORY EASY 3 MIN

The robot is in its packaging pose to allow easy transportation or packaging. To use the robot, it is necessary to disengage the packaging pose. As the robot maintains a pose that exceeds the Joint Angle Limit when in packaging pose, it is impossible to set Servo On status due to safety limit violation. The robot LED is illuminated red in this state.






	Items	Description
1	Model Name	The name of the connected robot model appears.
2	Pack/Unpack	Either Pack or Unpack can be selected.
3	Packaging Pose/joint Limit	The pose and joint limit values appear.
4	Speed Ratio	The speed of the pack or unpack mode can be adjusted via a slider or input.

The process of configuring the packaging pose is as follows:


1. Tap the **Recovery** menu in the **header pane**.



2. Select the **Packaging Mode** tab.



3. Tap the **Servo On to Start Recovery** button to enable packaging mode.




- 4. The robot automatically moves to the set packaging pose.
 - The **Pack** button allows you to put the robot in the Pack position and the **Unpack** button allows you to put the robot in the Default Home Position.

2.4.4 Servo Off



Servo on status is the status where the robot is ready with power supplied to robot joints to modify the robot pose.

Press Servo Off button to cut off power supplied to the robot joints and stop the robot. For more information, refer to Overview of Servo On(p. 160).




2.5 Installing the tool

MANDATORY EASY 5 MIN

Use four M6 bolts to fix the tool on the tool flange.

- It is recommended to use tightening torque of 9 Nm to tighten the bolts.
- Use a $\Phi 6$ place marker pin to accurately install the robot in a fixed location.
- **1** Note
- For more information about the tool flange, refer to Connecting the Robot and Tool(p. 102).
- The way tools are combined can vary from tool to tool. For more information about tool installation, refer to the manual provided by the tool manufacturer.



No.	Items
1	Tools
2	Bracket
3	Cable
4	Tool flange


2.6 I/O Testing

2.6.1 Power off the system

MANDATORY EASY 1 MIN

Press the shutdown button on the teach pendant or press and hold the power button on the upper left of the teach pendant for 2 seconds to turn off the system.

- 1. The shutdown popup is displayed on the screen.
- 2. Press the OK button on the shutdown popup to properly shutdown the system.



Caution

- Press and hold the power button for more than 4 seconds to force system shutdown.
- Forced shutdown may cause robot and controller failure.

2.6.2 Connect wires

MANDATORY NORMAL 10 MIN

Connect the necessary cables to the flange I/O connectors after the tool is fixed. The pin map of the flange I/O must be checked.

- When power is supplied to the robot, the fifth terminal of each connector always outputs 24V.
- For more information, refer to Flange I/O(p. 106).

Caution

- Make sure to cut off the robot's power when connecting the tool and gripper.
- Make sure to configure tool and gripper measures to prevent workpieces falling from the tool when the robot power is cut off.




To control/monitor the robot using an external device, connect the controller I/O or connect to a network, such as Modbus TCP, PROFITNET or EtherNet/IP.

- For more information, refer to Controller I/O Connection(p. 112).
- For more information, refer to Network Connection(p. 129).

2.6.3 Power on the system




Turn the system power on again. Press and hold the power button until the teach pendant screen powers up.



2.6.4 Test controller and flange I/O

MANDATORY NORMAL 10 MIN

The teach pendant features a function capable of testing the operation of the tool connected to the flange I/O.



The following tests can be performed through **Status > I/O Overview** or **I/O Test** of the teach pendant screen. For more information, refer to each item.

- Controller Digital Input(p. 321)
- Controller Digital Output(p. 321)
- Controller Analog Input(p. 321)
- Controller Analog Output(p. 321)

3 PART 3. Installation Manual

The Installation Manual describes the installation methods and specifications of the robot and controller.

3.1 Cautions during Installation




Warning



- Industrial robot's must be installed with careful consideration given to the inspection standards defined by the Regulations and Safety Inspection of the Occupational Safety and Health Standard Announcement (if the robot is subject to inspection).
- Secure sufficient space before installing the controller. Installing the robot in a place where sufficient space is not secured may result in damage to the robot or injury to the user.
- When connecting the power plug and power cable to the product, do not touch them with wet hands. This may cause electrocution or injury. Please use the tool center position information provided as the maximum payload of the robot within the work area may vary depending on the center of gravity distance.
- Safety devices to be used in connection with the controller must be connected to the safety contact input terminal or the configurable digital IO set as Safety IO (input/output) using dual signals. When connected to a standard IO or connected to a single signal, the prescribed safety level cannot be achieved.
- The operating handle of the power disconnect should be installed so that it is easily accessible, considering that it depends on the location where the plug is connected and the environment in which the robot is installed.
- In the case of the In the case of the P series, it is possible to use only the floor standard, and to prevent safety accidents, be sure to refer to the "P Series Handling Guide" in Appendix F provided in consideration of the dead load of the robot during installation.

3.1.1 Lifting points for transport and installation


- When relocating the robot to an installation location, please carry it by lifting the shaded area described below. In order to prevent accidents, be sure to check the local or national weight standards during material handling and carry them in accordance with the guidelines.
- Please be careful of the accidents caused by falling while carrying the robot.




3.2 Product Introduction

3.2.1 Robot system configuration and description


Component List





Name of each part and Functions


Manipulator



Name of each part


No.	Name	No.	Name
1	Base	6	Link2
2	J1	7	J5
3	J2	8	J6
4	Link1	9	Tool Flange
5	J3		


Key Features




No.	Items	Description
1	Cockpit	[Optional] Operation buttons for direct teaching and operation
2	Tool Flange	Area to install tools.
3	Flange I/O	I/O port for tool control. (Digital input 3ch, output 3ch)
4	LED	Displays the robot status with different colors. For more information about robot status, refer to the Status and Flange LED Color for Each Mode(p. 17).
5	Connec tor	Used for supplying power to and communication of the robot.

Controller








No.	Items	Description
1	I/O connection terminal (internal)	It can be connected with other robots' controllers or peripherals.
2	Network connection terminal	Used for connecting to the network connection terminal inside the controller to use Laptops, TCP/IP devices, and and Modbus equipment.
3	Power connection terminal/ switch	Used for connecting the mains power of the controller to turn it on or off. For more information, refer to Power on/off the system(p. 144).
4	USB connection terminal	Used to store logs created while the robot is operating in the USB storage, or export and import tasks.
5	Manipulator cable connection terminal	Used for connecting the manipulator cable to the controller.

No.	Items	Description
6	Teach pendant cable connection terminal	Used for connecting the teach pendant cable to the controller.



If you choose an optional controller, check the user manual in the appendix to connect before use.

Teach pendant




No.	Items	Description
1	Power Button	 Used to turn ON/OFF the main power of the teach pendant. For more information, refer to Power on/off the system(p. 144).
2	Power LED	 When power is applied, the LED will start flashing red, and will remain solid red once booting is complete.
3	Emergency stop button	• In case of an emergency, press the button to stop robot operation.
4	Hand-Guiding button (3PE 3 Position Enable Switch)	 Press and hold the button to move the robot freely into a desired pose. If you press the button with strong force, the hand guide mode will be switched to OFF.



- If the teach pendant needs to be protected and mounted during operation, the soft cover supplied by us makes it safer and easier to use.
- New TP (TP-02) added function: Hand Guide dual function
 - The existing TP (TP-01) cannot be used in the integrated controller. (Pin Map changed due to 3PE Switch)
 - The new TP (TP-02) can be used in the existing controller, but the LED is changed to a single color (red) and displayed, and additional functions cannot be used.


System Configuration



No.	Name	Description
1	Teach pendant	This device manages the entire system and is capable of teaching the robot specific poses or making settings related to the manipulators and controllers.
2	Controller	It controls the robot's movement according to the pose or movement set by the teach pendant. It features various I/O ports that allow the connection and use of various equipment and devices.
3	Manipulator	It is an industrial collaborative robot that can perform transport or assembly tasks with various tools.
A	Command/ Monitoring	
В	Power Supply/ Network	

3.2.2 Nameplate and Label

Be careful not to remove or damage labels attached to the robot and controller.







Note

If you have selected an optional controller, the attachment location may be different, so please check the user manual in the appendix


3.2.3 Product Specifications, General

P Series	Technical Data
P3020	Refer to P3020(p. 376)

3.3 Robot Specifications

3.3.1 Robot operating space

P3020



3.3.2 Max. Payload within operating space

The maximum payload of the robot within its operating space changes according to the distance from the center of gravity. Payload per distance is as follows:




Note

This load diagram assumes a small tool load volume. Tools with a larger volume will have greater limitations in payload above the tool's center of gravity compared to a tool with an equal weight but smaller volume, and in such cases, vibration may occur.

P3020






Allowed Moment and Inertia

The allowed moment and inertia for the J4-J6 robot are as follows:

Model Name	J4		J5		J6	
	Allowed Moment	Inertia	Allowed Moment	Inertia	Allowed Moment	Inertia
P3020	-	-	55 Nm	3.1 kgm²	36 Nm	2.0 kgm²

3.3.3 Tool Center Point (TCP)

Refer to the figure below for TCP.



3.3.4 Basic specifications

Model Name	P3020
Weight	83 kg
Payload within Work Radius	30 kg
Max. Work Radius	1900 mm
Number of Axes	5
Max. TCP Speed	Over 1 m/s
Position Repeatability (ISO 9283)	±0.1 mm
Protection Rating	IP 54
Noise	< 65 dB
Installation Direction	Floor Only
Controller and Teaching Pendant	Doosan Controller & Teach Pendant

Model Name	P3020
Vibration and Acceleration	10≤f<57Hz - 0.075mm amplitude 57≤f≤150Hz – 1G
Impact	Max Amplitude: 50m/s(5G) • * Time: 30ms, Pulse: 3 of 3 (X,Y,Z)
Operating Temperature	0 °C ~45 °C (273K to 318K)
Storage Temperature	-5 °C ~50 °C (268K to 323K)
Humidity	20% ~ 80%

3.3.5 Axis Specifications

Model Name	P3020	
Operating Angle		
J1	±360° (TP:±360°)	
J2	±125° (TP:±95°)	
J3	±160° (TP:±135°)	
J4	-	
J5	±360° (TP:±135°)	
J6	±360° (TP:±360°)	
Max. Speed per Axis (rated payload operation)		
J1	100 °/s	
J2	80 °/s	
J3	80 °/s	

Model Name	P3020
J4	-
J5	200 °/s
J6	360 °/s

3.4 Installation Environment

When you install the robot, you need to make sure it has enough space to move. Check the operating space of the robot to ensure that the robot does not collide with external elements.

3.4.1 Installation Location Check

When you install the robot, you need to make sure it has enough space to move. Check the robot's work area to make sure it does not collide with external objects.

- Install the robot on a firm, even surface.
- Install the robot in a location with no water leakage and constant temperature and humidity.
- Check whether there are flammable and explosive materials near the installation location.




Caution



• Installing the robot in locations other than the recommended locations may result in reduced robot performance and product life.

3.4.2 Robot Work Area Check

Secure installation space considering the work area of the robot. The work area varies according to the robot model.



Caution

The grayed areas in the figure are areas where the robot has difficulty performing work. Within this area, the speed of tools is low but the speed of joints is high, so it becomes difficult to perform risk assessment in this area because the robot operates inefficiently. Therefore, it is not recommended to operate the tool passing through the cylindrical section on the top and bottom of the base.

3.5 Hardware Installation

Install the robot, controller and teach pendant, the key components of the system in the work area, and supply power to them before operating the robot. The instruction for installing each element is as follows:


3.5.1 Ready to install the robot

Fixing the Robot

Use M8 bolts in the four 9.0 mm holes on the manipulator base to fix the robot.

- It is recommended to use tightening torque of 20 Nm to tighten the bolts. Use washers (spring-flat) to prevent loosening by vibration.
- Use two Φ5 place marker pins to accurately install the robot in a fixed location.

The manipulator base drawing and four M8 bolts are used (P Series), Unit [mm]



Warning


- Tighten the bolts all the way to prevent loosening during manipulator operation.
- Install the manipulator base on a solid surface that can withstand the load generated during operation (10 times the maximum torque and five times the weight of the robot).

- The robot will interpret manipulator base vibration as a collision and engage the emergency stop. Therefore, for installation locations that automatically shift position, do not install the robot base in a location with high movement acceleration.
- Mount the manipulator arm in a specific location using appropriate methods. The mounting surface must be solid.
- The manipulator will be damaged if it comes in contact with water for an extended period of time. Do not operate the robot in conditions where it can get wet or under water.

Placing the Cable

Please ensure that the cables have curvatures greater than the minimum curvature radius. The minimum curvature radius of each cable is as follows:

Cable	Minimum curvature radius (R)	
Teach pendant cable	120 mm	
Robot cable	120 mm	




Caution

- Ensure that the curvature radius between the teach pendant cable and teach pendant connector is greater than the minimum curvature radius.
- If the curvature radius is smaller than the minimum curvature radius, cable disconnection or product damage may occur.

• In environments where electromagnetic noise can occur, proper cable installation must be taken to prevent malfunctions.

3.5.2 Connecting the system

Connecting Manipulator to Controller



Description

- Connect the manipulator cable to the controller, place a securing ring
 - Connect the manipulator connection cable to the corresponding connections on the controller and install the snap ring to prevent the cable from becoming loose.
- Connecting the manipulator connection cable's opposite end to the controller
 - Connect the other end of the manipulator connection cable to the corresponding connection of the controller until it clicks and please make sure that the cable is plugged in tightly.

Caution


- Do not disconnect the manipulator cable while the robot is turned on. This may cause the robot to malfunction.
- Do not attempt any modifications or extensions to the manipulator cable.
- When installing the controller on the floor, secure at least 50 mm of clearance on each side to ensure adequate ventilation.
- Be sure to properly lock the connectors before turning on the controller.



Note

• When configuring the system, it is recommended that a noise reducer be installed to prevent noise effects and malfunction of the system.

• If the controller is affected by the noise generated by electromagnetic waves, it is recommended that ferrite cores be installed on both ends of the manipulator cable to ensure normal operation. The installation locations are as follows:



Connect Controller to Teach Pendant




Caution

- When connecting the cable, check the shape of the connection before connecting it so that the pin does not bend.
- When using the Teach Pendant hanging on the wall or controller, be careful not to trip over the connecting cables.
- Be careful not to allow the controller, Teach Pendant or cable to come in contact with water.
- Avoid installing the controller or Teach Pendant in a dusty or wet environment.
- The controller and Teach Pendant must not be exposed to a dusty environment that exceeds the IP20 rating. Be especially careful in environments with conductive dust.



Note

- When configuring the system, it is recommended that a noise reducer be installed to prevent noise effects and malfunction of the system.
- If it is affected by noise generated by electromagnetic waves, it is recommended that ferrite cores be installed on the connection parts of the Teach Pendant cable to ensure normal operation. The installation locations are as follows:



Connecting Power to Controller

To supply power to the controller, connect the power cable of the controller to a standard IEC power outlet.

- When connecting, use a cable with a standard power plug that matches the outlet of country of use.
- Push the plug completely into the corresponding connection of the controller to prevent the cable from becoming loose. Connect the standard IEC C14 plug under the controller to the corresponding IEC C13 cord.



Caution

- Please make sure the robot is properly grounded after connecting the power cables (Electrical Ground Connections). Establish a common ground for all equipment in the system with unused bolts related to the ground symbol inside the controller. The ground conductor must satisfy the maximum current rating of the system.
- Protect the input power of the controller using a circuit breaker.
- Do not attempt any modifications or extensions to the power cable. It can cause fire or controller breakdown.
- Make sure that all cables are properly connected before supplying power to the controller. Always use the original cable included in the product package.




Note

- When configuring the system, it is recommended to install a power switch capable of turning all devices off at once.
- The power supply must satisfy minimum requirements such as ground and circuit breakers. The electrical specifications are as follows: (For optional controllers, refer to their respective appendix.)

Parameter	Specifications
Input Voltage	100 – 240 VAC
Input Power Fuse (@100-240V)	15 A
Input Frequency	47 – 63 Hz

3.5.3 Connecting the Robot and Tool



No.	Item
1	Tool
2	Bracket
3	Cable
4	Tool flange


- 1. Use four M6 bolts to secure the tool on the tool flange.
 - It is recommended to use tightening torque of 9 Nm to tighten the bolts.
 - Use a $\Phi 6$ place marker pin to accurately install the robot in a fixed location.
- 2. Connect the necessary cables to the flange I/O connectors after the tool is secured.



Note

Methods of securing the tool may vary according to the tool. For more information about tool installation, refer to the manual provided by the tool manufacturer.

Tool output flange, ISO 9409-1-50-4-M6



3.6 Power on/off the controller


3.6.1 Power on

A power switch is installed at the bottom of the controller to shut down power. Press the power switch at the bottom of the controller.

• The power for systems such as the robot, controller and teach pendant is turned on.

3.6.2 Power off


When cleaning or disassembling the robot and controller for maintenance, be sure to press the power switch to turn off the power.



4 PART 4. Interface

4.1 Flange I/O

The end flange cover of the robot has two M8 spec 8-pin connectors, and refer to the figure below for the location and shape.




The connector supplies power and control signals necessary to operate the gripper or sensors embedded within specific robot tools. The following are sample industrial cables (equivalent cables can be used):

- Phoenix contact 1404178, male (Straight)
- Phoenix contact 1404182, male (Right Angle)

4.1.1 Schematic Diagram

The pin map of each connector is as follows:



I/O functions provided through X1 and X2 connectors are different from each other, and refer to the table below for detailed I/O settings.

X1 Setting

No	Signal type	Description
1	Digital Input 1	PNP (Source Type, default)
2	Digital Output 1	set to either PNP (Source Type, default) or NPN (Sink Type)
3	Digital Output 2	set to either PNP (Source Type, default) or NPN (Sink Type)
4	Analog Input 1 / RS-485 +	set to either Voltage (0-10V) or Current (4-20mA, default) /
5	Power	Set the internal power supply to +24V (default), +12V or 0V
6	Analog Input 2 / RS-485 -	set to either Voltage (0-10V) or Current (4-20mA, default) /
7	Digital Input 2	PNP (Source Type, default)
8	GND	

X2 Setting

No	Signal type	Description
1	Digital Input 3	PNP (Source Type, default)
2	Digital Output 3	set to either PNP (Source Type, default) or NPN (Sink Type)
3	Digital Output 4	set to either PNP (Source Type, default) or NPN (Sink Type)
4	Analog Input 3 / RS-485 +	set to either Voltage (0-10V) or Current (4-20mA, default) / Max 1M baud rate
5	Power	Set the internal power supply to +24V (default), +12V or 0V
6	Analog Input 4 / RS-485 -	set to either Voltage (0-10V) or Current (4-20mA, default) / Max 1M baud rate
7	Digital Input 4	PNP (Source Type, default)
8	GND	

The flange input/output (I/O) initial power is set to 24V and can be set to 0V or 12V.

Refer to the table below for detailed power specifications during I/O connection.

Parameter	Min	Туре	Max	Unit
Supply voltage (12V mode)	11.4	12	12.6	V
Supply voltage (24V mode)	22.8	24	25.2	V
Supply current	-	-	3	А



Warning

- Set up the tool and gripper so that they do not cause any hazards when pt cause any hazards when power is cut off.
 - (e.g., workpiece falling from the tool)
- The No. 5 terminal of each connector outputs 24V at all times while power is supplied to the robot, so make sure to cut the power supply to the robot when setting up the tool and gripper.


4.1.2 Flange Digital Output Specifications

Flange digital output is a PNP specification, and photo coupler output is set up in the output.

The corresponding output channel becomes +24V when digital output is activated. When digital output is disabled, the state of the corresponding output channel is open (floating).

The electrical specifications of the digital output are as follows:

Parameter	Min	Туре	Max	Unit
Voltage when driving 10mA	23	-	-	V
Voltage when driving 50mA	22.8	-	23.7	V
Current when driving	0	-	50	mA



The setting has been changed as follows since April 11, 2024

Digital Ou Outputs support two differefferent modes:

Mode	Active	Inactive
PNP (Source Type, default)	High	Open
NPN (Sink Type)	Low	Open

The flange input/output (I/O) initial power is set to 24V and can be set to 0V or 12V.

The corresponding output channel becomes ++12V or ++24V when digital output is activated.

When digital output is disabled, the state of the corresponding output channel is open (floating).

The electrical specifications of the digital output are as follows:

Parameter	Min	Туре	Max	Unit
Voltage when driving 12V mode	11.4	12	12.6	V
Voltage when driving 24V mode	22.8	24	25.2	V
Current when driving	0	-	50	mA

Caution

- Digital output is not subject to current limitation. Ignoring the specifications presented above during operation may cause permanent damage to the product.
- The figure below is an example of a digital output setup, so refer to it while connecting the tool
- Make sure to disconnect the power from the robot when setting up the circuit.

4.1.3 Flange Digital Input Specifications

Flange digital input features a photo coupler input.


The current based on 24V input is limited to 5mA by internal resistance.

The electrical specifications of the digital input are as follows:

Parameter	Min	Туре	Max	Unit
Input voltage	0	-	26	V
Logical high	4.4	-	-	V
Logical low	0	-	0.7	V
Input resistance	-	4.4k	-	Ω

Caution

- The figure below is an example of a digital input setup, so refer to it while connecting an input device.
- Make sure to disconnect the power from the robot when setting up the circuit.



4.1.4 Flange Analog Input Specifications

Receives voltage or current signals from external devices.

Analog Input can be set to voltage (0-10V) or current (4-20mA).

The electrical specifications are shown below.


Parameter	Min	Туре	Max	Unit
Input voltage in voltage mode	0	-	10	V
Input current in current mode	4	-	20	mA
Resolution	-	12	-	bit

4.2 Controller I/O Connection

The controller I/O terminals can be used to connect external equipment other than manipulators and teach pendant to the controller. In addition to safety devices such as emergency stop switch, light curtain, and safety mats, various peripherals required to configure a robot work cell, such as pneumatic solenoid valves, relays, PLCs, and conveyor belt encoders can be connected.

The controller I/O is organized as follows.

- Terminal Block for Safety Contact Input (TBSFT): for connecting devices required for emergency stopping and protective stopping
- Digital I/O Power Terminal Block (TBPWR)
- Configurable Digital I/O Block (TBCI1- 4, TBCO1- 4): for connecting peripherals required for robot operation
- Analog I/O Terminal Block (TBAIO)
- Terminal Block for Encoder Input (TBEN1, TBEN2)
- Safety Input Terminal Block (TBSI): Used to directly connect safety sensors that generate OSSD signals to the controller safety signals (OSSDs are typically used with safety sensors and light curtains or as safety control outputs).





Caution

- To prevent the risk of damage and malfunction to the product, be sure to turn off the power when connecting terminals to the controller I/O.
- If the product is damaged or damaged due to the user carelessness, it does not compensate in Doosan Robotics.
- When turning off the power to the controller, be sure to turn off the external power source as well.

4.2.1 Setting Analog I/O Terminal (TBAIO)

The controller has two analog I/O terminals that can be set to voltage mode or current mode. It can output voltage/current through an external device operated using analog I/O or receive signals from sensors outputting analog voltage/current.

To ensure maximum input accuracy, observe the following:

- Use shielded or twisted pair cables.
- Connect the cable shield to the ground terminal inside the controller.
- Current signals are relatively less sensitive to interference, so use devices operating in current mode for analog I/O terminals. Current/voltage input modes can be set with the software.

The electrical specifications of the analog I/O terminal are as follows:


Terminal	Parameter	Specifications	
Current mode analog input	[AIX-GND]	Voltage	-
	[AIX-GND]	Current	4 - 20 mA
	[AIX-GND]	Resistance	
	[AIX-GND]	Resolution	12 bit
Voltage mode analog input	[AIX-GND]	Voltage	0 - 10 V
	[AIX-GND]	Current	-
	[AIX-GND]	Resistance	1M ohm
	[AIX-GND]	Resolution	12 bit
Current mode analog output	[AOx-GND]	Voltage	-
	[AOx-GND]	Current	4 - 20 mA
	[AOx-GND]	Resistance	50M ohm
	[AOx-GND]	Resolution	16 bit
Voltage mode analog output	[AOx-GND]	Voltage	0 - 10 V

Terminal	erminal		Specifications
	[AOx-GND]	Current	-
	[AOx-GND]	Resistance	1 ohm
	[AOx-GND]	Resolution	16 bit

Voltage/current input

It receives voltage or current signals from an external device between the Alx terminal of the TBAIO terminal block and the GND terminal. If the output of the device is a voltage signal, it receives a signal of 0-10Vdc. If the output of the device is a current signal, it receives a signal of 4-20mA.


• Depending on the output signal (voltage/current) of the device, it is necessary to set the controller analog input as "Voltage" or "Current" on the teach pendant.



Voltage/current output

It supplies voltage or current signals to an external device between the AOx terminal of TBAIO terminal block and GND terminal. If the input of the device is voltage signal, it supplies a signal of 0-10Vdc. If the input of the device is current signal, it supplies a signal of 4-20mA.

• Depending on the input signal (voltage/current) of the device, it is necessary to set the controller analog output as "Voltage" or "Current" on the teach pendant.



4.2.2 Setting Encoder Input Terminal (TBEN1, TBEN2)


The controller provides two TBEN terminals that allow the input of external encoders. They support A, B and Z phases as inputs, and perform counts based on 12Vdc. In addition, phase S can be used as a start sensor for the conveyor.

To ensure maximum input accuracy, observe the following:


- Use shielded, twisted pair cables to reduce noise.
- Connect the cable shield to the ground terminal inside the controller.
- In the case of S phase inputs, connect a pull-up or pull-down resistance according to the sensor type(NPN/PNP) to prevent floating.

The figure below shows a sample encoder and sensor configuration, so refer to it while establishing connections.


Connecting Incremental Encoder A, B, Z phase



Connecting NPN Sensor




Connecting PNP Sensor



4.2.3 Configuring Configurable Digital I/O (TBCI1 - 4,TBCO1 - 4)

The controller is configured with 16 digital inputs and 16 digital outputs. The digital I/Os shown in the figure below can be connected to peripherals required for robot control, or can be set as redundant Safety IOs to be used as safety signal I/O purposes.



The electrical specifications of the configurable digital I/O are as follows:

Terminal		Parameter	Specifications
Digital Output	[Oxx]	Voltage	0 - 24 V
	[Oxx]	Current	0 - 1 A
	[Oxx]	Voltage drop	0 - 1 V
	[Oxx]	Leakage current	0 - 0.1 mA.
Digital inputs	[lxx]	Voltage	0 - 30 V
	[lxx]	OFF Range	0 - 5 V
	[lxx]	ON Range	11 - 30 V
	[lxx]	Current	2–15 mA


Caution

• The VIO (IO 24V) and GIO (IO GND) terminals, which can be used as power supplies for digital I/ O, are separated from the other power supplies, VCC (24V) and GND, on the safety I/O circuit. Use caution, as the diagnostic functions of the robot will detect errors and cut off the power to the robot if the internal power supply is connected as a digital I/O power supply through the Terminal Block for Digital I/O Power (TBPWR) or if the 24V power is not supplied to the VIO and GIO terminals through an external power supply, the configurable digital I/O will not operate.

When configurable digital I/O is used as a general digital I/O, it can be used in various ways such as operating low-current equipment such as solenoid valves for voltage or exchanging signals with PLC systems or peripherals. The following is how to use the configurable digital I/O:


If dry contact input is received

This is a method of connecting a switch or contact between the VIO terminal of terminal blocks TBCI1-TBCI4 and Ixx terminals. The output of the external device only acts on the open/close of the contact through the relay, so it is electrically insulated from external devices.



If wet contact input is received


It receives voltage-type signals from external devices. If the output of the target device is source type, it receives a voltage of 24V/0V as input. If the output of the target device is sink type, a relay can be added to receive voltage of 24V/0V as input. Because voltage input requires a reference, the external devices and the external power supply must be connected to a common ground.



If a simple load is operated


It is a method of connecting loads between Oxx terminals of TBCO1-TBCO4 terminal blocks and the GIO terminal. Each terminal is capable of outputting a maximum of 1A, but the overall current may be limited according to the calorific value and load.

If digital I/O power (VIO/GIO) is supplied through the internal power supply as in the factory default setting, up to 2A of VIO current can be used. If a total current greater than 2A is required, remove the connection between the digital I/O power supply (VIO/GIO) of the Terminal Block for Digital I/O Power (TBPWR) and the internal power supply (VCC/GND) and connect an external power supply.




If a negative common & sink type input device is connected

When connecting the output of the digital IO to a sink-type input device, connect the Oxx terminals of TBCO1 - TBCO4 terminal blocks to the input terminal of the external device, and connect GIO to the negative common of the external device to establish a common ground.



If a positive common & source type input device is connected

Connect a relay between the Oxx terminal of TBCO1-TBCO4 terminal blocks and the GIO terminal to supply input signals as contacts to the external device. If necessary, an external power supply can be connected to the external device.



Caution

- The operation of the general digital IO devices can be interrupted at any time by cutting off the power to the controller, detecting errors by self-diagnosis, and settings of the task program. Therefore, perform a risk assessment before configuring the robot work cell and be sure to implement additional safety measures if additional risks, such as falling of the workpiece, stopping, negligence of the digital input due to digital outputs being switched off or synchronization errors due to misunderstanding, are foreseen.
- The general digital I/O is a single connection type I/O and any short circuits or breakdown can result in the loss of safety functions, so it cannot be used for safety purposes. If the connection of a safety device or safety-related signal I/O is required, be sure to set the corresponding terminal as redundant Safety I/O on the teach pendant.


When configurable digital IO is used as Safety IO

001 & 002, ..., 015 & 016, I01 & I02, .. I15 & I16, can use identical safety signals to form a dual safety I/O.


The dedicated input terminal of the Safety Contact Output Terminal (TBSFT) can only connect a dry contact signal, but the input set as Safety IO can connect both contact-type (dry contact) and voltage-type (wet contact) signals. The output set to Safety I/O outputs voltage, but if necessary, a relay can be added externally to configure a contact type output.

The following is an example of connecting a safety device for operation.

Connect a contact type (Dry Contact) signal emergency switch as a safety input terminal




• Connect a voltage type (Wet Contact) signal light curtain as a safety input terminal (common ground)




4.2.4 Configuring the Digital I/O Power Terminal (TBPWR)

VIO and GIO are power sources used for the digital I/O of the safety controller located in the front of the controller, and are separated from VCC24V and GND supplied by SMPS inside the controller. If the user uses a current of 2A or less for the configurable digital I/O and does not require insulation between the connected I/O device and controller, the internal power supply of the controller can be used as the I/O power supply, as shown in the figure below. (factory default setting)



If a current greater than 2A is required, it is necessary to connect a separate external power source (24V) to the VIO and GIO terminals.



When the VIO power is supplied, the "IOPW (green)" LED on top of the TBPWR block lights up.



Caution

When turning off the power for the controller, be sure to turn off the external power source (SMPS).



Note

• If a current greater than 2A is connected to VCC and GND of TBPWR, the fuse in front of the terminal power output shorts to ensure the safety of the internal system of the controller connected to the same SMPS.


• If a current greater than 2A is required for the configurable digital I/O, be sure to connect additional external power source (24V) to VIO and GIO.

4.2.5 Setting the Terminal Block for Contact Input (TBSFT)

The safety I/O of the controller consists of redundant dedicated contact input terminals for connecting safety devices. These terminals are categorized into two groups depending on their use.

- Two pairs of External Emergency Contact In on the bottom: Used to connect devices required for emergency stopping such as external emergency switch.
- Two pairs of Protective Device Contact In on the top: Used to connect devices for protective stopping such as light curtain and safety mat.

If this is used without an external safety device connected, connect each contact input as follows:



The external safety device signal recognized by the #safety controller# depending on the normally closed contact status, where all four contact inputs are normally closed, is as follows:

Contact Status	EM1 contact	EM2 contact	PR1 contact	PR2 contact
Close	Normal	Normal	Normal	Normal
Open	Emergency Stop	Emergency Stop	Protective Stop	Protective Stop



Warning

• Never connect a safety signal to a regular PLCs that is not a safety PLCs. Failure to do so may cause improper operation of the Safety Stop function, resulting in severe injury or death to the user.

• If any of the contacts are open, the robot will stop operation according to the safety stop mode setting, and the LED on the right side of the TBSFT lights up. EMGA (Red), EMGB (Red), PRDA (Yellow), PRDB (Yellow)



- EMGA: Emergency Stop Channel A (EM1) LED
- EMGB: Emergency Stop Channel B (EM2) LED
- PRDA: Protective Stop Channel A (PR1) LED
- PRDB: Protective Stop Channel B (PR2) LED



Caution


• To check for connection losses and connection shortages, this terminal must be connected to devices that output a safety signal as contacts. To connect a peripheral device that outputs a safety signal as a voltage to the Safety Controller, refer to Configuring Configurable Digital I/O (TBCI1 - 4, TBCO1 - 4)(p. 118).

4.2.6 Setting the Terminal Block for Voltage Input (TBSI)

The Safety Controller provides dedicated safety inputs (SI1, SI2, SI3, SI4) to connect safety signals with test pulses.

The Protective Device has the output to send the signal to a machine such as a robot when it detects a hazadous situation.

The Protective Device may also include a test pulse in the signal to verify that the output function of this signal is working properly, in which case this dedicated safety input can be used.





Note

Each port of the TBSI terminal accepts a maximum of one test pulse of 1ms every 20ms. The test pulses are allowed only for the Low active signal (normally High and switches to Low when an event occurs) among the Safety Input signals.


4.3 Network Connection

You can use laptops, TCP/IP equipment, Modbus equipment, etc. by connecting them to the network connection terminal in the controller.

Connect a cable to a dedicated port, depending on your network use.

- WAN: Connecting external Internet
- LAN: Connecting peripherals using TCP/IP or Modbus protocol

Plug the cable into the network connection terminal shown in the figure below to connect the network.



Caution

The LAN4 port is intended to connect to the internal controller, so do not connect any other equipment arbitrarily.

4.3.1 Connecting External Devices

Connecting External Devices - Vision Sensor

The robot can be connected with a vision sensor (2D camera for object position measurement), and vision sensor measurements can be transferred to the robot through a network to link with commands of the robot.

Vision Sensor Setting

• Communication Connection Setting

Connect the LAN ports of the devices and apply TCP/IP communication to transfer vision sensor measurements to the robot. (refer to Network Connection(p. 129)) Set the IP address of the vision sensor to TCP/IP 192.168.137.xxx band to allow TCP/IP communication.

Vision Work Setting

To perform object position measurement, it is necessary to have an image input and vision teaching of the target object using the vision sensor. Refer to the dedicated vision work setting program provided by the vision sensor manufacturer.

• Measurement Data Format Setting

To use vision sensor measurement data in robot work, it is necessary to perform vision-robot coordinates calibration, and this must be performed before initiating work using the vision sensor setting program. The vision sensor measurement data must be transferred using the following format settings:

Format	pos	,	х	,	у	,	angle	,	var1	,	var2	,		
--------	-----	---	---	---	---	---	-------	---	------	---	------	---	--	--

- 1. pos: Separator indicating the start of measurement data (prefix)
- 2. x: X coordinate value of the object measured using vision sensor
- 3. y: Y coordinate value of the object measured using vision sensor
- 4. angle: Rotation angle value of the object measured using vision sensor
- 5. **Var1 ... varN**: Information measured using vision sensor (e.g., object dimension / defect check value) Example) pos,254.5,-38.1,45.3,1,50.1 (description: x=254.5, y=-38.1, angle=145.3, var1=1, var2=50.1)

Robot Program Setting

When the physical communication connection between the vision sensor and robot and vision sensor setting are completed, a program must be set to allow the vision sensor and robot program to be linked. It is possible to connect/communication/control functions of the external vision sensor using Doosan Robot Language (DRL), and it is possible to set up the program in the Task Writer.

Details and comprehensive examples of Doosan Robot Language (DRL) on external vision sensor functions are provided in the Programming manual.

Connecting External Device – DART Platform

The DART Platform is a software that runs on a Windows OS-based desktop or laptop. Once the controller and Desktop/Laptop are connected through the LAN Port, all functions of the teach pendant are available from the time the DART Platform is executed. At this time, the following setup procedure is required to connect with subcontrollers within the controller.

IP Address Search and Connection Setting

• Communication Connection Setting


When the DART Platform is executed after connecting the laptop to the LAN port of the controller, the controller IP address, the version information of the sub-controller and the robot serial number required for establishing a connection are automatically searched.

If the search fails, press the Refresh button to refresh or tap Enter IP Manually to manually enter the IP of the controller.


Selecting the serial number of the robot to be connected and pressing the Connect button establishes a connection between the DART Platform and the sub-controller and allows the robot to be operated normally.

If there is an issue with the connection, try the procedure below, but if this issue is persistent, contact the sales or service staff for assistance.

If the search results for connectable controller IP address, sub-controller version information, and robot serial number are not displayed: Press the Refresh button to search again and try to connect again according to the procedure above.



Then, if you see the Transfer Control page as shown below, tap the Forced Withdraw button to attempt to connect with the Platform.



4.3.2 Setting up and using extended protocols

Expanded Protocol - PROFINET IO Device(pnio device) Setup

The robot controllers of Doosan Robotics support the PROFITNET IO Device (Slave) function, which allows data modification after reading the Parameters of the robot from an external device (PROFINET IO Controller/ Master). (E.g., Robot parameter Monitoring, General Purpose Register(bit, Int, Float) – Using General Purpose Register (GPR)(p. 140))

Note) for more information about PROFINET, please visit http://www.profibus.com

Expanded Protocol - EtherNet/IP Adapter(EIP adapter) Setup

The robot controllers of Doosan Robotics support the EtherNet/IP Adapter (Slave) function, which allows data modification after reading the Parameters of the robot from an external device (EtherNet/IP Scanner / Master). (E.g., Robot parameter Monitoring, General Purpose Register(bit, Int, Float) – Using General Purpose Register (GPR)(p. 140))

Note 1) For more information about EtherNet/IP, refer to www.odva.org.

Note 2) the initial default IP is 192.168.137.50. After that, you can change the controller IP depending on the use of the PLC control application.

Using Expanded Protocol

The PROFINET IO Device (PNIO device) and EtherNet/IP Adapter (EIP adapter) functions start together at controller startup, and are in connection standby state with the Master device. Therefore, in order to use the function, it is necessary to connect and set up the Master. Each Master device has different characteristics, so it is necessary to check them.



Note

The following are descriptions of the implementation characteristics of general functions for Industrial Ethernet.

- The Industrial Ethernet function of Doosan Robotics controllers does not use a separate ASIC, but implements its function based on TCP/IP, so it does not support real-time performance.
- Data output to external devices has identical markings (PNIO, EIP), but data input to the robot
 only has identical structures and does not link. Therefore, data output from the PNIO controller
 does not synchronize with output data from the EIP scanner.
- For the I/O table of PNIO and EIP, please refer to a separate document (or attachment).


EtherNet/IP Full GPR map

EtherNet/IP Full GPR map is available that supports different types of I/O in the robot.

- Bit I/O GPR 24ea
- Integer I/O GPR 50ea
- Float I/O GPR 50ea

From the left menu of the Settings module, select PLC to go to the below screen. (Please refer to Configure in the Network section(p. 342))

In the image below, item 3 is Full GPR map, and the setting is saved only after saving and rebooting.



ProfiNet Slot


For network optimization, only interested slots can use the ability to perform Transaction.

- Slot#1: Robot State (T2O)
- Slot#2: Robot Error Code (T2O)
- Slot#3: Joint (T2O)
- Slot#4: Task (T2O)
- Slot#5: Bit GPR (T2O)
- Slot#6: Int GPR (T2O)

- Slot#7: Float GPR (T2O)
- Slot#8: I/O Control (O2T)
- Slot#9: Bit GPR (O2T)
- Slot#10: Int GPR (O2T)
- Slot#11: Float GPR (O2T)

From the left menu of the Settings module, select PLC and select the ProfiNet tab to see the screen below. (Please refer to Configure in the Network section(p. 342))

You can use the check box at the center to select only the slots that the user is interested in, and the settings are saved only after saving and rebooting.



Robot Error Code Information

In an environment without TP (HMI), user can check the error code information of the robot through PLC. (Please refer to Configure in the Network section(p. 342))

EtherNet/IP



Note

EtherNet/IP reflects up to **two** error codes due to the transaction limit (500 bytes).

Byte Offset	Description
36	Major & Minor (Error Code#1) • Upper 2bytes: Major • Lower 2bytes: Minor
40	Year & Month & Day & Hour (Error Code#1) • Uppest 1byte: Year • Upper 1byte: Month • Lower 1byte: Day • Lowest 1byte: Hour
44	Minute & Second & Milli-second (Error Code#1) • Uppest 1byte: Minute • Upper 1byte: Second • Lower 2bytes: Milli-second
48	Major & Minor (Error Code#2) • Upper 2bytes: Major • Lower 2bytes: Minor
52	Year & Month & Day & Hour (Error Code#2) • Uppest 1byte: Year • Upper 1byte: Month • Lower 1byte: Day • Lowest 1byte: Hour
56	Minute & Second & Milli-second (Error Code#2) • Uppest 1byte: Minute • Upper 1byte: Second • Lower 2bytes: Milli-second

ProfiNet: Slot#2

Byte Offset	Description
0	Major & Minor (Error Code#1) • Upper 2bytes: Major • Lower 2bytes: Minor

Byte Offset	Description
4	Year & Month & Day & Hour (Error Code#1) • Uppest 1byte: Year • Upper 1byte: Month • Lower 1byte: Day • Lowest 1byte: Hour
8	Minute & Second & Milli-second (Error Code#1) • Uppest 1byte: Minute • Upper 1byte: Second • Lower 2bytes: Milli-second
12	Major & Minor (Error Code#2) • Upper 2bytes: Major • Lower 2bytes: Minor
16	Year & Month & Day & Hour (Error Code#2) • Uppest 1byte: Year • Upper 1byte: Month • Lower 1byte: Day • Lowest 1byte: Hour
20	Minute & Second & Milli-second (Error Code#2) • Uppest 1byte: Minute • Upper 1byte: Second • Lower 2bytes: Milli-second
24	Major & Minor (Error Code#3) • Upper 2bytes: Major • Lower 2bytes: Minor
28	Year & Month & Day & Hour (Error Code#3) • Uppest 1byte: Year • Upper 1byte: Month • Lower 1byte: Day • Lowest 1byte: Hour
32	Minute & Second & Milli-second (Error Code#3) • Uppest 1byte: Minute • Upper 1byte: Second • Lower 2bytes: Milli-second

4.3.3 Setting ModbusTCP Slave

Doosan Robotics' ModbusTCP Slave function supports robotic parameter monitoring and General Purpose Register(GPR) function (refer to Using the General Purpose Register(GPR)(p. 140)).

This function automatically starts when the robot controller boots up normally. Therefore, the user can use it after matching the Master IP of the robot controller with the same bandwidth.



1 Note

- The related I/O table is provided as a separate file.
- Please refer to the Programming Manual for DRL to use the GPR function.
- Unsupported Function Code
 - 0x07 Read Exception Status (Serial Line only)
 - 0x0F Write Multiple Coils
 - 0x10 Write Multiple registers
 - 0x11 Report Server ID (Serial Line only)

Robot Error Code Information

When it is difficult to check the error code of the robot, such as in an environment without TP (HMI), the robot's error code information can be obtained by communicating with the robot controller Modbus Slave function.

Address	Description
440	Major (Error Code#1)
441	Minor (Error Code#1)
442	Milli-second (Error Code#1)
443	Second & Minute (Error Code#1) • Upper 8bit: Second • Lower 8bit: Minute
444	Hour & Day (Error Code#1) • Upper 8bit: Hour • Lower 8bit: Day
445	Month & Year (Error Code#1) • Upper 8bit: Month • Lower 8bit: Year

Address	Description			
446	Major (Error Code#2)			
447	Minor (Error Code#2)			
448	Milli-second (Error Code#2)			
449	Second & Minute (Error Code#2) • Upper 8bit: Second • Lower 8bit: Minute			
450	Hour & Day (Error Code#2) • Upper 8bit: Hour • Lower 8bit: Day			
451	Month & Year (Error Code#2) • Upper 8bit: Month • Lower 8bit: Year			
452	Major (Error Code#3)			
453	Minor (Error Code#3)			
454	Milli-second (Error Code#3)			
455	Second & Minute (Error Code#3) • Upper 8bit: Second • Lower 8bit: Minute			
456	Hour & Day (Error Code#3) • Upper 8bit: Hour • Lower 8bit: Day			
457	Month & Year (Error Code#3) • Upper 8bit: Month • Lower 8bit: Year			

4.3.4 Using General Purpose Register(GPR)

The GPR function is the memory area of the pnio device, eip adapter, predefined for use by the user as needed. This feature allows users to send and receive user data between external devices and robots.

Note

The GPR functionality is provided only through the DRL, and the DRLs used are as follows. For more information on the DRL, please refer to the programming manual.

- set_output_register_bit(address, val)
- set_output_register_int(address, val)
- set_output_register_float(address, val)
- get_output_register_bit(address)
- get_output_register_int(address)
- get_output_register_float(address)
- get_input_register_bit(address)
- get_input_register_int(address)
- get_input_register_float(address)

5 PART 5. Robot Management

5.1 Transportation

5.1.1 Caution during Transportation

5.1.2 Pose for Robot Transportation

Set the following poses to transport the robot:

Model	J1	J2	J3	J4	J5	J6
P3020	0°	45°	135°	-	0°	0°

5.1.3 Package specifications

The box specifications for transport are as follows:

Model	Length	Width	Height
P3020	1100 mm	650 mm	1500 mm

5.2 Maintenance

System maintenance must be performed by Doosan Robotics or a company designated by Doosan Robotics. Maintenance is intended to keep the system operable or to return the system to an operable state in the event of a problem, and it includes repair work as well as system diagnosis of potential issues.

When maintenance work is completed, risk assessment must be performed to confirm whether the system satisfies required safety levels. Corresponding national and regional regulations must be observed during inspection, and all possibilities related to safety must be tested.

When performing work on the manipulator or controller, the following safety procedures and warnings must be observed.

- Maintain the safety settings of the software during maintenance work.
- If a particular part is defective, replace it with a new identical part or part approved by Doosan Robotics.
- The replaced part must be returned to Doosan Robotics.
- After completing the work, resume the safety function.
- Document the repair history of the robot system and manage related technical documents.
- Disconnect the power cable and make sure other power sources connected to the manipulator or controller do not supply power.
- Do not connect the system to a power source during maintenance.
- Check the ground connection before supplying power to the system.
- When disassembling the manipulator or controller parts, observe ESD regulations.
- Do not disassemble areas that supply power within the controller. Power supply areas may still be charged with high voltage (up to 600V) even after the controller is turned off.
- Take caution to prevent water or dust from entering the system during maintenance.

5.3 Disposal and Environment

- Doosan Robotics products comply with the Restriction of Hazardous Substances of Directive 2011/65/EU & Directive (EU)2015/863.
- Since this product contains industrial waste materials, improper disposal can cause environmental pollution. Therefore, never dispose of it with general industrial or household waste.
- When disposing all or part of the product, you must comply with the laws and regulations of the country concerned. For matters related to disposal, please contact the seller or Doosan Robotics.
- Sellers in Europe must register data applicable to the country of sale to EWRN (https://www.ewrn.org/national-registers) in accordance with the Directive 2012/19 EU Waste Electrical and Electronic Equipment (WEEE).

6 PART 6. DART-Platform Manual

6.1 Power on/off the system

6.1.1 When using the teach pendant

Press and hold the power button on the upper left of the teach pendant.




Note

If the system does not power up, check the power switch at the bottom of the controller. For more information, refer to Power on/off the controller(p. 104).

- The power for systems such as the robot, controller and teach pendant is turned on.
- Once the system is powered on, the LED indicator for the robot lights up.
- Press the shutdown button on the teach pendant or press and hold the power button on the upper left of the teach pendant for 2 seconds.
 - a. The shutdown popup is displayed on the screen.
 - b. Press the OK button on the shutdown popup to properly shutdown the system.







Caution


- Press and hold the power button for more than 4 seconds to force system shutdown.
- Forced shutdown may cause robot and controller failure.


6.2 Overview of Program's Screen Layout







6.2.1 Overview of Home Screen







6.2.2 Overview of header







6.2.3 Overview of Footer



	Items	Description
1	Servo switch	The servo can be turned on or off.
2	Backdrive	Run the Backdrive module.
3	Recovery	Recovery: Run the Recovery Module.

	Items	Description		
4	Favorite Modules	The favorite modules that you have set up in the Home module are displayed. * The Home module is always displayed.		
5	Favorite Modules Popup	You can display all favorite modules and change the order to Drag & Drop.		
6	Robot / Virtual switch	You can switch Robot ↔ Virtual mode. * It can only be used if the actual robot is connected.		
7	Quick Control	You can toggle pop-up that provide 3D Simulator, Jog, and Dashboard features.		
8	Program Control	Provides control buttons to play, pause, resume and stop DRL/task programs.		
9	Speed Control	The current robot speed information is displayed, and the speed change pop-up allows you to change the robot speed. Speed 1 100 100 %		

6.3 What is a robot?

6.3.1 Functional Limits of each Robot Series

The different robot series (A, As, E, M/H, P Series) limit the use of functions as follows:

- **Current-based**: Current of motor located on each joint is used.
- FTS-based: An FTS (force torque sensor) located on the end of the robot is used.
- JTS-based: JTS (joint torque sensorss) located on each joint is used.

Features	A/E Series (Current- based)	A Series S (Current, FTS-based)	M Series (JT S-based)	H Series (JTS- based)	P Series (JTS- based)
Direct Teaching • Free Motion	0	O (Current- based)	0	0	0
Direct Teaching • Restrained Motion	х	O (FTS based)	0	0	0
Collision Detection	0	O (Current- based)	0	0	0
Installation Pose Measurement	X	O (FTS based)	0	X(the robot can only be installed on the floor)	X(the robot can only be installed on the floor)
Tool Weight Measurement	X	O (FTS based)	0	0	0
Workpiece Weight Measurement	X	O (FTS based)	0	0	0
Nudge Function	X	Х	0	0	0

Features	A/E Series (Current- based)	A Series S (Current, FTS-based)	M Series (JT S-based)	H Series (JTS- based)	P Series (JTS- based)
Force Control	O (setting available only in three translation directions, excluding rotation)	O (FTS based)	0	O	0
Compliance Control	O (setting available only in three translation directions, excluding rotation)	O (FTS based)	0	O	0

6.3.2 Functional Limits of force monitoring for each Robot Series

The teach pendant and DART-Studio can be used to monitor force data. The DRL command (check_force_condition()) can also be used to externally monitor force data.

• If the palletizing mode is set to "ON": The same control/monitoring functions provided in the OFF state are available, except for H, P Series robots.

Features	A/E Series (Current -based)	A Series S (Current- based and FTS- based)	M Series (JTS- based)	H Series (JTS- based)	P Series (JTS- based)
Force control	O (setting available only in three translation directions, excluding rotation)	O (FTS-based)	O	O (If the palletizing mode is set to "ON": Force control output limited (Base Rx, Ry orientation) 1))	O (If the palletizing mode is set to "ON": Force control output limited (Base Rx, Ry orientation) 1))

Features	A/E Series (Current -based)	A Series S (Current- based and FTS- based)	M Series (JTS- based)	H Series (JTS- based)	P Series (JTS- based)
Compliance control	O (setting available only in three translation	O (FTS-based)	0	O (If the palletizing	O (If the palletizing
	directions, excluding rotation)			mode is set to "ON": Compliance control output limited (Base Rx, Ry orientation) 1)	mode is set to "ON": Compliance control output limited (Base Rx, Ry orientation) 1)
Force monitoring (Teach Pendant)	X	O (FTS-based)	O (Force value of "0" shown for the singularity section)	O (Force value of "0" shown for the singularity section)	O (Force value of "0" shown for the singularity section)
				O (If the palletizing mode is set to "ON": 4-Degree of Freedom provided for the base (x, y, z, Rz))	O (If the palletizing mode is set to "ON": 4-Degree of Freedom provided for the base (x, y, z, Rz))
Force monitoring (DART-Studio)	O (Force value of "0" shown for the singularity section)	O (FTS-based)	O (Force value of "0" shown for the singularity section)	O (Force value of "0" shown for the singularity section)	O (Force value of "0" shown for the singularity section)
				O (If the palletizing mode is set to "ON": 4-Degree of Freedom provided for the base (x, y, z, Rz))	O (If the palletizing mode is set to "ON": 4-Degree of Freedom provided for the base (x, y, z, Rz))


Features	A/E Series (Current -based)	A Series S (Current- based and FTS- based)	M Series (JTS- based)	H Series (JTS- based)	P Series (JTS- based)
Force monitoring (When using DRL commands:	O (Force value of "0" shown for the singularity section)	O (FTS-based)	O (Force value of "0" shown for the singularity section)	O (Force value of "0" shown for the singularity section)	O (Force value of "0" shown for the singularity section)
check_force_ condition())				O (If the palletizing mode is set to "ON": 4-Degree of Freedom provided for the base (x, y, z, Rz))	O (If the palletizing mode is set to "ON": 4-Degree of Freedom provided for the base (x, y, z, Rz))

Control output limit (Base Rx, Ry orientation): The force or compliance control values corresponding to the The force or compliance control values corresponding to the Base Rx, Ry orientation are not output. Entering the force or compliance control value of the relevant axis (Base Rx, Ry) will be ignored as "0".


6.3.3 Overview of Singularity

Singularity in a multi-joint robot refers to a position (or point in a multi-joint robot refers to a position (or point) where the robot has difficulty in calculating its next pose during moving. Multi-joint robots calculate each joint angle during movement based on the robot end.

For example, in Fig. 1 below, when the robot is moving to the red dot, the robot will not be able to determine whether to move its joints to set pose A or pose B as shown in Fig. 2. This position (or point) is called the singularity.



Near a singularity, robot movement is not fluid in terms of plane, point and line, robot end linear movement may not be maintained, and position error during control may increase. Singularity occurs in 3 cases as shown in the following figure, including when the robot joints form a line.



- 1. Wrist Singularity: When the robot wrist forms a line as Axis 5 approaches 0°
 - When compared to a human arm, Axes 4, 5 and 6 correspond to the wrist joint.
- 2. Shoulder Singularity: When Axes 1 and 6 are on the same line
 - When compared to a human arm, Axes 1 and 2 correspond to the shoulder joint.
- 3. Elbow Singularity: When the robot forms a line as Axis 3 approaches 0°
 - When compared to a human arm, Axis 3 corresponds to the elbow.

Caution

- Manual and automatic operations moving with joint rotation are not influenced by singularity.
 - Task movement, MoveL command, etc.
- Singularity only occurs during manual and automatic operation where the robot ends performing linear movement.
 - Joint movement, MoveJ commands, etc.
- In the singularity zone, force control or compliance control is unavailable.
- As the rotation speed of certain axes increase rapidly when a linear motion passes a singularity, it is possible for a Joint Speed Limit Violation or Joint Angle Limit Violation to occur.

How to avoid Singularity

Doosan Robotics robots provide options to avoid singularities during motion control. However, it is recommended to configure a task that does not create exceptions using joint movement commands such as MoveJ in singularity zones.

Here are the singularity avoidance options provided by Doosan Robot:

- Automatic avoidance: Performs motion by avoiding singularities. However, the robot motion may differ from the expected path.
- Path priority: Maintains path and speed, but may stop due to an error near a singularity.
- Variable speed: Maintains path, but decelerates near a singularity.


6.3.4 Overview of Euler Angle

Euler Angle is a way to express the angles of X, Y and Z axes, which are perpendicular among themselves in the object direction. A, B and C refer to the sequential rotation angles. Each robot manufacturer defines this A, B and C rotation order differently, such as **Rz-Ry-Rz**, **Rz-Ry-Rx** or **Rx-Ry-Rz**.


For example, **Rz-Ry-Rx**. Here, **Rz** means the rotation in Z-axis, **Ry** means the rotation in Y-axis and **Rx** means the rotation in X-axis. Rz can be expressed as angle A, Ry as angle B, and Rx as angle C to indicate the current rotating direction of an object. Note that once rotation is made in Z-axis direction from the coordinates, rotations will be made based on new coordinates.

This can be visualized with steps 1 to 4.


1. Assume there are coordinates (X, Y, Z).




2. Rz: Rotate by A degrees from the Z-axis.



3. Ry: Rotate by B degrees from the new Y-axis (Y') of the new coordinates (X', Y', Z') in step




4. Rx: Rotate by C degrees from the new X-axis (X'') of the new coordinates (X'', Y'', Z'') in step 3.



5. The new coordinates (Z"", Y"", X"" of step 4 refers to the current robot rotation when Euler Angles A, B and C are applied.

This can be easily visualized with one's right hand. Make the following pose with your right hand. This is called the Right-Hand Rule, and making the thumb (X-axis), index finger (Y-axis) and middle finger (Z-axis) to be perpendicular to each other will create coordinates consisting of X, Y and Z axes.




Then make the Right-Hand Rule Cartesian pose and make rotations Rz, Ry and Rx in sequential order.

- 1. Rz: Rotate the middle finger (Z-axis) by A degrees.
- 2. Ry: Rotate the index finger (Y-axis) by B degrees.
- 3. Rx: Rotate the thumb (X-axis) by C degrees.



Note

The + rotating direction of The + rotating direction of A, B and C is the direction of four fingers except the thumb, when the thumb is pointing at the + direction and the four fingers are clenched. This is called the Law of Clockwise Screw.



6.4 Overview of Servo On



Servo On refers to a standby state in which the robot arm can be driven by powering the joint. Servo off when an emergency stop button is pressed or a safety restriction is violated. In the servo off state, the joint is powered off and the robot arm cannot be driven and the **task editor**, **jog plus** associated with the robot arm drive is disabled in the main menu.


To switch from servo off to servo on, tap the Servo button on the left-hand side of the main menu at the bottom.

6.5 Backdrive Module

Backdrive cuts off power supplied to the motors, releasing only the brakes to allow the robot's joints to move under external force. This function is used when the robot cannot return to normal status with **Recovery** mode or Handguiding. With **Backdrive** mode, the user can engage or disengage the brake of each joint.



To access the Backdrive module, tap the Backdrive button located at the bottom.



	Items	Description
1	Start Backdrive Mode	This button allows you to run the Backdrive mode.
2	Exit Backdrive	This button allows you to exit the Backdrive module.
3	Joint Image	This is an image that describes the position of each joint.

	Items	Description
4	On/Off toggle button	You can choose whether to enable it for each joint.

The process of setting **Backdrive** mode is as follows:

- 1. Tap the **Status** button on the main menu **Backdrive** button.
 - If the **Backdrive** button is not enabled, pressing and releasing the Emergency Stop button or pressing the **Servo Off** button will enable it.
 - In the **servo-on** state, the following pop-up window appears and the servo is automatically disabled



- 2. Tap the **Start Backdrive Mode** button on the **Backdrive** screen.
 - The OFF/ON button is activated to release the brakes on each joint.



- 3. Set the brake of the joint to move as OFF (Release) and move the robot by applying force.
 - Due to the deceleration ratio of the decelerator inside the joint, the joint sagging speed due to the manipulator weight is not high, and movement speed when force is applied is also not high.
 - If the decelerator malfunctions or if joints move at a speed faster than a certain speed during zerogravity motion, the brakes of all joints are applied automatically to ensure safety.
- 4. Set the brake ON (Hold) when the position change is complete.
- 5. Tap the **Power** on the main menu to shut down the operating program, tap and hold the power button on the top of the teach pendant to shut down the system, and press it again to turn on the system.
 - Backdrive status is released and work can resume normally.



- Move each joint back to the normal work range individually in sequential order.
- If Backdrive mode is executed, the system must be rebooted to resume normal work again.

 Please be aware that temporary sagging may occur depending on the position of the axis during the **Backdrive** mode.

6.6 Recovery Module


Recovery Module: If there is an error with a continuing safety violation or if a robot needs to be packed for transportation, the user can use the Safety Recovery Mode to configure the position and angle of the robot.



To access the Recovery module, tap the Recovery button located at the bottom.


- **Software Recovery:** In Servo Off status, if a safety violation error situation caused by position-related safety violations, such as the robot exiting the operation area or violating prohibited areas, occurs or force is continuously applied when the robot is stopped due to colliding with a fixed object, **Servo On** or **Jog** cannot be set even when attempting to reset the robot to a normal state using the Jog or program. In such cases, **Software Recovery** mode is used to reset the robot to normal.
- **Packaging Mode**: For packaging and transporting the robot, the robot can be set to predefined values (which go beyond the normal operation angle limit) for transporting.

If the servo is enabled when the Recovery module is launched, the following pop-up appears and the servo is automatically turned off.



6.6.1 Using Software Recovery Mode

Software Recovery Mode



	Items	Description
1	Servo On to Start Recovery	This is a button to enable the servo before entering Recovery mode.
2	Exit Recovery	This button allows you to exit the Recovery module.
3	Header	This section allows you to select either Software Recovery mode or pack/unpack mode.
4	3D Simulation	This area allows you to preview a 3D simulation of the set values.
5	Warning Message	This explains the precautions.
6	Display Coordinates	This is where you can set the coordinate based on Base or World.

	Items	Description
7	Base/Tool Button	This is where you can set the value based on Base or Tool.
8	Joint/Task	This section allows you to enter the desired values to make the robot move.

To use the software recovery mode, follow these steps:


- 1. Tap the **Recovery menu** in the header pane. The Software Recovery screen appears automatically in the Recovery window.
- 2. Tap each joint button on the right side of the Software Recovery screen, and use ____, ___ buttons to set the position. Or press buttons of the cockpit to adjust the joint angle by direct teaching.
 - For definitions of the buttons in the cockpit, refer to Cockpit(p. 177)
 - Changes made to the setting are reflected on the simulation window on the left in real time.
- 3. When the setting is complete, tap the X button on the top left to close the window.



Caution

Software repair mode is not available when the joint angle limit is exceeded by 3 degrees.

6.6.2 Using Pack/Unpack




Menu

	Items	Description
1	Model Name	The name of the connected robot model appears.
2	Pack/Unpack	Either Pack or Unpack can be selected.
3	Packaging Pose/joint Limit	The pose and joint limit values appear.
4	Speed Ratio	The speed of the pack or unpack mode can be adjusted via a slider or input.

To configure the packaging mode, follow these steps:

1. Tap the **Recovery** menu in the **header pane**.



2. Select the **Packaging Mode** tab.




3. Tap the **Servo On to Start Recovery** button to enable packaging mode.



- 4. The robot automatically moves to the set packaging pose.
 - The **Pack** button allows you to put the robot in the Pack position and the **Unpack** button allows you to put the robot in the Default Home Position.

6.7 Robot Parameters Module



Menu

	Items	Description
1	Project name	This is where the project name is entered.
2	View More	Clicking this button will create a new file or import, save, or export an existing file.
3	Accordion menu	Clicking on an item will bring up a list of related menus.
4	Sub menu	You can enter each screen and function by clicking on the menus.
5	Lock icon	When the lock icon is seen, certain settings can be changed at the administrator level.



To use this module, the robot must be in Manual mode.


If you receive the following warning message, change the status of the robot to Manual mode.



6.7.1 Robot Settings

I/O Alias & Mount

I/O Alias




	Items	Description
1	Controller Digital I/O	The name of the controller digital I/O can be set individually.
2	Flange Digital I/O	The name of the flange digital I/O can be set individually.
3	Controller Analog I/O	The name of the controller analog I/O can be set individually.
4	Flange Analog Input	The name of the flange analog I/O can be set individually.

		Items	Description
į	5	I/O Name	The name can be up to 40 characters long.

Mount

The robot installation pose can be set in the robot installation pose (mount) menu. If the robot is installed on a flat surface, this step can be skipped.

The robot installation pose can be set in **Robot Parameters > Robot Settings > Mount**.




- The installation angle can be measured using the auto measure function. However, if the angle is less than 5 degrees, auto measure is unavailable.
- If the robot is installed on the ceiling or wall, the robot installation angle can be set with Y-axis and Z-axis rotations.
- As auto tool weight calculation is performed based on gravity, it is recommended to reset the tool weight once mount setting is done.



Caution

When setting the robot installation pose (mount), it is recommended to change the world coordinates as well. If the world coordinates are not changed, the robot pose on the robot simulator screen of the teach pendant is displayed as the robot being installed on the flat surface (basic).



	Items	Description
1	Lock Toggle Button	Used to lock the set value. The safety password is required for modifying the set value.
2	Use Mount	Button to enable the use of mount. Button is available after unlocking.
3	Auto Measure	This automates a commanded operation. The 3D Simulation next to it shows this movement.
4	Information Image	This is an image that tells you about the Mount.
5	Information Message	This is a message that tells you about the Auto Measure.
6	Increment/Decrement Button	This allows you to increment or decrement as much as desired.
7	Y-Axis Rotate Input Field	The Y-axis rotation angle can be entered directly.
8	Z-Axis Rotate Input Field	The Z-axis rotation angle can be entered directly.
9	Apply Button	This allows the set values to be applied.


Coordinates

World Coordinates

The world coordinates of the robot can be set from World Coordinates. In case the robot coordinate is the base coordinates, this step can be skipped.


World coordinates can be set in Robot Parameters > Robot Settings > World Coordinates.


- World coordinates are used when the robot base installation location is physically moved/rotated.
- Changing the world coordinates will apply the same move/rotation to the robot simulator screen.



Note

World coordinates can also be used even after the base location and angle are changed after robot teaching. If the coordinates of tasks created through robot teaching in the past are changed from BASE to WORLD, an offset corresponding to the move/rotation of world coordinates is applied to all motion coordinates.






	Items	Description
1	Lock Toggle Button	Used to lock the set value. The safety password is required for modifying the set value.
2	Information Image	This is an informative image required for the setting.
3	Information Message	This is an informative message required for the setting.
4	Mounting Pose	This section includes Mounting Pose values for A, B, and C.
5	Point, Line and Plane settings	This is where you can select and set the desired items among point, line and plane.
6	Teaching Guide	This is a guide for setting up point, line and plane.
7	Coordinates	This is where you can select the desired coordinate between Base and World.
8	Point 1 setting	This is where you can set the settings for each of the 6 axes, as well as Get Pose and Move To.
9	Apply Teaching Points button	This button allows you to enter the desired settings and apply them.

	Items	Description
10	World to Base Coordinates Reset	This button allows you to reset the World to Base Coordinates already entered.
11	World to Base Coordinates setting	This is where you can enter settings for the 6 axes.
12	Apply button	The setting value can be applied.

User Coordinates




	Items	Description
1	Add New	This button allows you to delete the selected User Coordinate. Up to 100 user coordinates can be added.
2	Delete	This button allows you to delete the selected User Coordinate.
3	Selected User Coordinates	This is a list of the User Coordinates added.

	Items	Description
4	User Coordinates Name	This is where you can set the names of the User Coordinates. A number from 101 to 200, with a maximum length of 40 characters, can be entered.
5	Point, Line and Plane settings	This is where you can set each point, line, and plane.
6	Information icon	A guide to User Coordinates is provided.
7	Coordinates	This is where you can select either Base or World as the basis for the desired value.
8	Point 1 setting	This is where you can enter values for each of the 6 axes of Point 1 and run Get Pose or Move To.
9	Apply Teaching Points	This button allows the desired values to be applied after they are entered.
10	User Coordinates	In the User Coordinates section, you can enter each of the desired values.
11	Save	This button allows the setting values to be saved.

Home Position & Cockpit

Home Position



	Items	Description
1	Default Position option	This is the section where you can select the Default Position option.
2	Default Position value	These are the values that correspond to the Default Position, all of which are 0.
3	Custom Position option	This allows you to select the Custom Position option.
4	Custom Position value	You can check the currently set Custom Position value and the current robot position.
5	Home Position	This button allows you to set the Default Position or the Custom Position you set as the Home Position.
6	Warning Message	A note of caution when setting this up.
7	Save	This button allows the setting values to be saved.

Warning

When a robot or joint of a robot is being swapped, Custom Home Position must be reset.

Cockpit


Direct teaching is used to hold the robot end with one's hands to push and pull the robot to the desired pose, and apply the pose to the currently selected motion. There are two direct teaching methods.

- Freedrive: Each joint moves in the direction the user applied force
- Constrained Motion: The robot end moves or rotates only in the direction set in the constrained motion even when force is applied from a random direction


Freedrive

When Button 1 is pressed, the Freedrive mode is activated, allowing the robot to be moved freely. Each joint moves in the direction the user applied force. The robot cannot be moved by hand once the button is released.

• During direct teaching, the robot LED blinks cyan.




Pressing the hand guide button on the back of the teach pendant will activate the Freedrive mode, just like pressing Button 1, and the robot can be moved freely.



Constrained Motion

When Button 2 and Button 3 are pressed, the robot end moves only in the direction matching the constraint condition even when force is applied from a random direction. The constraint condition can be set with 2 of 4 of the conditions in the following figure: Z-axis constrained, plane fix constrained, surface constrained and direction constrained.



Menu

	Items	Description
1	Cockpit Image	This is an image for Cockpit settings.
2	Reset	This button allows you to initialize the set values.
3	1 Button Setting	This is the section where you can select the function to be set for the button 1.
4	2 Button Setting	This is the section where you can select the function to be set for the button 2.
5	1+2 Buttons Setting	This is the section where you can select whether to enable clamping for the buttons 1+2.
6	Guide Image	An guiding image for Cockpit setting items.

Obtaining Cockpit Button Status


User can obtain information about whether the Cockpit Button is pressed or released.

The robot provides the function to control the Cockpit Button, allowing it to be utilized in various applications.

- The "Monitoring Data" in the communication API provides information on Cockpit Button.
- If you press the robot's Cockpit Button or vice versa, you can detect it through the DRL API.
- DRL API: get_cockpit_input (Please refer to the Programming Manual.)
 - Params: (int) index
 - Returns: (int) **1: Pressed** (The button is pressed), **0: Released** (The button isn't pressed)

I/O Settings

Normal I/O




	Items	Description
1	Normal Input	This is the section where you can set what to be entered.
2	Normal Output	This is the section where you can set what to be output.

	Items	Description
3	Port Component	The options listed in the drop-down menu are different for Input and Output.
		For Input, the options in the drop-down menu for each port are:
		Not used
		Power on (H)
		Power off (H)
		For Output, the options in the drop-down menu for each port are:
		Not Used Safe Torque Off (L)
		Safe Operating Stop (L)
		Normal Speed (L)
		Reduced Speed (L)
		Auto Mode (L)
		Manual Mode (L) Remote Control Mode (L)
		Standalone Zone (L)
		Collaborative Zone (L)
		High Priority Zone (L)
		Tool Orientation Limit Zone (L)
		Designated Zone (L)
		Task Operating (L)
		Robot In Motion (L)
		Mastering Alarm (L)
		Home Position (L)
		Deceleration - SS1 SS2 (L)
4	Save	It can apply the set values.

Flange I/O Setting

This menu can only be accessed when connecting to a robot installed new flange.



	Items	Description
1	Supply Voltage	 Provides the ability to set the supply voltage. You can select the voltage(0V(=Off) or 12V or 24V)
2	Digital Output Type	 Provides the function to set the digital output type for each X1 and X2 port. • In series A, only X1 port is supported in the digital output type item. • In series M/H, both X1 and X2 ports are supported in the digital output type item.


	Items	Description
3	Analog Input/RS485 Mode Setting	 Provides the ability to select Analog Input or RS485. In series A, only the X1 port is supported in the Analog Input/RS485 item. In series M/H, both X1 and X2 ports are supported in the Analog Input/RS485 item. When selecting Analog Input,, Baud Rate, Data Bit, Parity Bit, Stop Bit items are disabled When selecting RS485, You can choose from the following options Baud Rate: 19200, 38400, 57600, 115200(default), 1000000 bps Data Bit: 5, 6, 7, 8(default), 9 Bit Parity Bit: Odd, even, none(default) Stop Bit: 1(default), 2
4	End Effector Power Interlock	Provides a function to set the operation when Servo Off or Interrupted. • In series A, the Servo Off selection combo box is disabled.
5	Save	It can apply the set values.

6.7.2 Tool Settings

Tool Center Point


When configuring the tool center point (TCP), the position and rotation angle based on the flange coordinates must also be defined. ime, The distance from the default starting point of the flange coordinate to the toolcenter point (TCP) in the X, Y and Z directions cannot be set to be greater than 10000 mm. Also, note that Force Control, Compliance Control, and Direct Teaching-Point Fixation are only available when the converted lengths of X, Y, and Z ($L = \sqrt{X^2 + Y^2 + Z^2}$) are 300 mm or shorter.

If the tool center point (TCP) is configured using **Auto Calculate**, the calculation is made based only on the X, Y and Z positions, so it is necessary to enter the rotation angle. The rotation angle can be defined with RZ, RY, and RX and it based on the "Euler Z-Y-Z" rotation method.




The definitions of the coordinate axis expressed with x, y, z and coordinate axis expressed with X, Y, Z are as follows:

- Coordinate axis of "Flange Coordinate" (x, y, z): The coordinate axis direction of the "flange coordinate "defined at the end of the flange is identical to the robot coordinate when the robot joint angle of the robot is (0,0,0,0,0,0).
- Coordinate axis of the "TCP Coordinate" (X, Y, Z): This is set at the end or at the working point of the tool installed on the end of the flange. At this time, the rotation angle of the "TCP Coordinate" is defined based on the "Flange Coordinate" in the order of 1) to 3) of the following:



- 1. Rotate A degrees along the z axis of the flange coordinate.
- 2. Rotate B degrees along the y' axis of the coordinate rotated according to 1).
- 3. Rotate C degrees along the z" axis of the coordinate rotated according to 2).

Here are a few examples of configuring the TCP according to the method described above:




- [X, Y, Z, A, B, C] = [0, 0, 100, 0, 0, 0]: General Gripper with only a Z-direction offset (TCP Coord)
- [X, Y, Z, A, B, C] = [100, 0, 300, 180, -45, 0]: Left Gripper with 45-degree angle (TCP Coord. L)

• [X, Y, Z, A, B, C] = [-100, 0, 300, 0, -45, 0]: Right Gripper with 45-degree angle (TCP Coord. R)


Menu

	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	3D Simulation	This is where you can simulate the configured Tool Center Point.
3	Adding	This button allows you to add TCP.
4	Deleting	This button allows you to delete the selected TCP.
5	Save	This button allows the setting values to be saved.

When the settings are locked, the screen below is seen.



At this time, the selected TCP is seen in blue as shown below.



Tool Weight

You can set the weight of the tool mounted on the flange by adding a Tool Weight. Tool weight can be set by selecting **Robot Parameters > Tool Settings > Tool Weight**.

- The tool weight can be measured using the auto measure function.
- It is recommended to add tool weight for each tool with a workpiece. If the workpiece weight is too heavy, the robot may recognize the weight of the workpiece as external force. It is because the robot determines this external force as a collision and stops.
- When creating a task, change the weight according to the process to change the tool weight. For example, it is possible to configure a task to select the standard tool weight before picking up a workpiece, and select the tool weight with the workpiece after picking up a workpiece.


The activated tool weight Item can be set as the standard tool weight by pressing the set tool icon (on the top of the teach pendant.

• Set of the tool setting is the same as the set of Other Commands. **Set** command can be used when changing the Tool Weight while a task is being performed. For more information, refer to Task Editor Module(p. 248).



• Up to fifty different tool weights can be registered.

• In the case of M series, acceleration automatically adjustment function when the maximum tool weight exceeds the maximum tool weight.



	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Adding	This button allows you to add a new Tool Weight.
3	Deleting	This button allows you to delete a Tool Weight.
4	Tool Weight List	A list of the configured Tool Weights.
5	Tool Weight Name	This is where you can enter a name for the Tool Weight.

	Items	Description
6	Auto Measure Motion	This button allows you to run the automatic measurement.
7	Automatic Measurement	This button allows you to select an option and run an automatic measurement for it.
8	Motion Selection	You can select the desired Motion from the options.
9	Selection of the Use of Weight	You can choose whether to use weight. This selection box is disabled for E Series or A Series without FPT sensors.
10	Weight Input	This is where you can enter the desired weight.
11	Selection of the Use of Center of Gravity CX	The use of the center of gravity CX can be selected.
12	CX Input	CX can be entered.
13	Selection of the Use of Center of Gravity CY	The use of the center of gravity CY can be selected.
14	CY Input	CY can be entered.
15	Selection of the Use of Center of Gravity CZ	The use of the center of gravity CZ can be selected.
16	CZ Input	CZ can be entered.
17	Whether to Use Inertia	This checkbox allows you to choose whether to use inertia.
18	lxx Input	An lxx entry for inertia can be entered.
19	lyy Input	An lyy entry for inertia can be entered.
20	lzz Input	An Izz entry for inertia can be entered.
21	lxy Input	An lxy entry for inertia can be entered.
22	lyz Input	An lyz entry for inertia can be entered.

	Items	Description
23	lzx Input	An lzx entry for inertia can be entered.
24	Save	This button allows you to save the setting values.

Tool Shape

The shape of the tool installed on the flange can be set by adding a tool shape.

The Tool Shape can be set in **Robot Parameters module > Tool Settings > Tool Shape.** For more information, refer to Tool Shape(p. 185).

- The robot determines space limit violation status based on the TCP (Tool Center Point) of the robot end and the robot body. If the actual robot has a tool shape larger than the set TCP, a tool shape must be added to protect the workpiece and tool.
- Take caution as the zone the robot can maneuver will decrease if the tool shape is set too large.


The tool shape item is only available after it is registered (Confirmed) and the toggle switch is enabled. The activated tool shape Item can be set as the standard tool shape by pressing the set tool icon (@ Tool) on the top of the teach pendant.

• Set of the tool setting is the same as the set of Other Commands. **Set** command can be used when changing the Tool Shape while a task is being performed. For more information, refer to Task Editor Module(p. 248).




Note

Up to fifty different tool shapes can be registered.




	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	3D Simulation	This is where you can 3D Simulate the result of the configured Tool Shape.
3	Tool Shape Name	The name of the configured Tool.
4	Tool Shape Form	The shape of the configured Tool.
5	Editing Tool Shape	This button allows you to edit the configured Tool Shape.
6	Deleting Tool Shape	This button allows you to delete the selected Tool Shape.
7	Adding Tool Shape	A tool shape can be added.
8	Applying	This button allows you to apply the Tool Shape after setting it.



	Items	Description
1	Tool Shape	This indicates that this pane is a Tool Shape pop-up.
2	Entering a Name	This is a field where the name of the Tool Shape can be entered.
3	Cautionary Message	A note of caution when setting up
4	Add New Cuboid	This button allows you to add a cuboid.
5	Add New Sphere	This button allows you to add a sphere.
6	Add New Capsule	This button allows you to add a capsule.
7	Cancel	This button allows you to cancel the setting.
8	Confirm	This button allows you to confirm the setting.

Once the cube/sphere/capsule is added, the display is seen as below.



- 194 -

6.7.3 Safety Settings

This section walks you through the basic concepts for using Safety Settings.

The stop modes provided to ensure user safety are as follows:

- STO (Safe Torque Off): Stops Servo Off (motor power is immediately turned off)
- SS1 (Safe Stop 1): Servo Off after maximum deceleration stop
- SS2 (Safe Stop 2): Standby after maximum deceleration stop (pause)
- RS1: Upon collision, complies to the direction opposite of the collision and then enters standby (can only be set in Collision Detection/TCP Force Limit Violation)

Doosan Robotics robots have two types of safety stop functions. Emergency Stop is used for general emergency situations, and the robot can resume operation with Servo On after releasing the emergency stop. In case of Protective Stop, the robot can resume operation by resolving the cause of Protective Stop and releasing the stop.

- Emergency Stop: It sets the stop mode when the Emergency Stop button of the teach pendant or an additionally installed external device is activated
 - It activates when the Emergency Stop switch of the teach pendant or the one connected to the TBSFT EM terminal is pressed.
 - Only STO or SS1 can be selected.
- Protective Stop: It sets the stop mode when the externally connected protective equipment is activated
 - It activates when the protective equipment connected to the TBSFT PR terminal is activated.

For more information on the Safety Stop functions, refer to Safety Function(p. 22).

Press the Emergency Stop button on the teach pendant or activate the safety device connected to the Safety I/O to activate emergency stop. Safety devices can be connected to Emergency Stop or Protective Stop through Robot Parameters > Safety Settings > Safety I/O functions of the teach pendant screen.

- For more information about connecting a safety device to Safety I/O, refer to Controller I/O Connection(p. 112).
- For information on how to set the safety stop function for this connection in the program, refer to Safety Signal I/O(p. 33).


Robot limits and safety

Robot Limits Setting

In Robot Limits, various limits related to the robot can be set. These limits are used to ensure the robot operates safely within the set limits.

Robot limits can be set in **Robot Parameter > Safety Settings > Robot Limits**.

• For a detailed description of each limit, refer to Robot Limits(p. 42).




Robot Limits are largely divided into 3 categories. Each category includes the following screens and functions.

Menu


Nudge

	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	TCP/Robot	Large classification of robot limits.
3	Reset	Used to reset settings.
4	Force	Used to set the force.
5	Power	Used to set the power.
6	Speed	Used to set the speed.
7	Momentum	Used to set the momentum.
8	Collision	Used to set the collision.
9	Save	Used to save the applicable setting.



	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Joint Speed	Large classification of robot limits.
3	Reset	Used to reset settings.
4	J1	Used to set the settings for Normal and Reduced modes respectively.
5	J2	Used to set the settings for Normal and Reduced modes respectively.
6	J3	Used to set the settings for Normal and Reduced modes respectively.
7	J4 (inactive for P series models)	Used to set the settings for Normal and Reduced modes respectively.
8	J5	Used to set the settings for Normal and Reduced modes respectively.

	Items	Description
9	J6	Used to set the settings for Normal and Reduced modes respectively.
10	Save	Used to save the applicable setting.



	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Joint Angle	Large classification of robot limits.
3	Reset	Used to reset settings.
4	J1	Used to set the settings for Normal and Reduced modes respectively.
5	J2	Used to set the settings for Normal and Reduced modes respectively.

	Items	Description
6	J3	Used to set the settings for Normal and Reduced modes respectively.
7	J4 (inactive for P series models)	Used to set the settings for Normal and Reduced modes respectively.
8	J5	Used to set the settings for Normal and Reduced modes respectively.
9	J6	Used to set the settings for Normal and Reduced modes respectively.
10	Save	Used to save the applicable setting.


Safety I/O

This function is used to input/output safety-related signals to the redundant terminals. If any of the safety input/output signals are detected to have a different redundant signal, it determines an open circuit or hardware failure and stops the robot in STO stop mode.

• To set the Safety I/O, select **Robot Parameters > Safety Settings > Safety I/O**.

For more information, refer to Safety Signal I/O(p. 33).


Input



	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Input/Output	Either Input/Output can be selected to be set.

	Items	Description
3	Signal Setting	Options set for each port. The options that can be set are as follows:
		Not Used Emergence Stop (L) Emergence Stop - No Loopback (L) Protective Stop (L) Protective Stop - STO (L) Protective Stop - SS1 (L) Protective Stop - SS2 (L) Protective Stop - SS2 (L) Protective Stop (L) - Auto Reset & Resume (R) Interlock Reset (R) Reduced Speed Activation (L) 3-Pos Enable Switch (H) Handguiding Enable Switch (H) Remote Control Enable (H) Safety Zone Dynamic Enable (L) HGC End & Task Resume (R)
4	Select whether to ignore the signal depending on the robot state	If you select the 'Protective Stop' signal, you can set whether to ignore the selected signal in the 'MANUAL, RECOVERY, HGC' robot states.
5	Set deceleration rate	You can set the deceleration rate. It can be from 0 to 100.
6	Save	This button allows you to save the setting you entered.

Output



	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Input/Output	Either Input/Output can be selected to be set.

	Items	Description
3	Signal Setting	Options set for each port. The options that can be set are as follows:
		Not Used Emergence Stop (L) Emergence Stop - No Loopback (L) Safe Torque Off (L) Safe Operating Stop (L) Abnormal (L)
		Normal Speed (L) Reduced Speed (L) Auto Mode (L) Manual Mode (L)
		Remote Control Mode (L) Standalone Zone (L) Collaborative Zone (L) High Priority Zone (L)
		Tool Orientation Limit Zone (L) Designated Zone (L)
4	Save	This button allows you to save the setting you entered.

Safety Stop Modes Settings

Learn the types of safety stops and how to engage/disengage safety stop.

Types of Safety Stops

The stop modes provided to ensure user safety are as follows:

- STO (Safe Torque Off): Stops Servo Off (motor power is immediately turned off)
- SS1 (Safe Stop 1): Servo Off after maximum deceleration stop
- SS2 (Safe Stop 2): Standby after maximum deceleration stop (pause)
- RS1: Upon collision, complies to the direction opposite of the collision and then enters standby (can only be set in Collision Detection/TCP Force Limit Violation)

Doosan Robotics robots have two types of safety stop functions. Emergency Stop is used for general emergency situations, and the robot can resume operation with Servo On after releasing the emergency stop. In case of Protective Stop, the robot can resume operation by resolving the cause of Protective Stop and releasing the stop.

- Emergency Stop: It sets the stop mode when the Emergency Stop button of the teach pendant or an additionally installed external device is activated
 - It activates when the Emergency Stop switch of the teach pendant or the one connected to the TBSFT EM terminal is pressed.


- Only STO or SS1 can be selected.
- Protective Stop: It sets the stop mode when the externally connected protective equipment is activated
 - It activates when the protective equipment connected to the TBSFT PR terminal is activated.

For more information on the Safety Stop functions, refer to Safety Functions(p. 22).

How to engage/disengage Safety Stop

Press the Emergency Stop button on the teach pendant or activate the safety device connected to the Safety I/O to activate emergency stop. Safety devices can be connected to Emergency Stop or Protective Stop through **Robot Parameters > Safety Settings > Safety I/O** functions of the teach pendant screen.

- For more information about connecting a safety device to Safety I/O, refer to Connect Controller I/O(p. 112).
- For information on how to set the safety stop function for this connection in the program, refer to Safety Signal I/O(p. 33).



	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Reset	A message providing information necessary for setting.
3	Reset	A button to reset the settings.

	Items	Description
4	Emergency Stop	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO SS1
5	Protective Stop	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: SS1 SS2
6	Joint Angle Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO SS1 SS2
7	Joint Speed Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO (Except for H/P Series) SS1 SS2
8	Joint Torque Limit Violation	Only STO is available.
9	Collision Detection	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO (Except for H/P Series) SS1 SS2 RS1

	Items	Description
10	TCP Robot Position Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO SS1 SS2
11	TCP Orientation Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO (Except for H/P Series) SS1 SS2
12	TCP Speed Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menu includes the following: STO (Except for H/P Series) SS1 SS2
13	TCP Force Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO (Except for H/P Series) SS1 SS2
14	Momentum Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO (Except for H/P Series) SS1 SS2
15	Mechanical Limit Violation	A Safety Stop can be selected to be used for the corresponding item. The drop-down menus include: STO (Except for H/P Series) SS1 SS2

	Items	Description
16	Save	This button allows you to save the setting values.




The following pop-up appears on the information message:



Safety Zone


Safety Zone settings screen




	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Choose Whether to Enable	This button allows you to apply/unapply the created Safety Zone.
3	Zone Name	The name given by the user when creating the Safety Zone
4	Zone Type	 Safety Zone types (each type has different parameters to set) Space Limit Collaborative Zone Crushing Prevention Zone Collision Sensitivity Reduction Zone Tool Orientation Limit Zone Custom Zone

	Items	Description
5	Zone shape	Safety Zone shapes Cuboid Cylinder Sphere Tilted Cuboid Multi-plane Box
6	Edit	 This button allows the settings of the created Safety Zone to be edited. Pressing this button brings up a pop-up that allows the Safety Zone to be edited.
7	Delete	This button allows the safe zone to be deleted.
8	Add	 This button allows the safe zone to be added. This button brings up a pop-up that allows the safe zone to be added.
9	Save	This button allows any changes to the settings in relation to the Safety Zone to be saved.

Sphere







	Items	Description
1	Shape Type	The desired Shape type can be selected from this drop-down.
2	Shape Image	This is the area where the image of the selected type is seen.
3	Coordinates	Either Base or World coordinates can be selected from this drop-down.
4	Radius	This is where the radius value is entered.

	Items	Description
5	Center Position	The center value can be set in these fields for each of the X-, Y-, and Z-axes.
6	Auto Calculation	This button allows the Auto Measure option to be enabled.
7	Auto Calculation Image	This area is where the image required for Auto Measure is seen. This appears when the Auto Measure option is enabled.
8	Point 1	Each field is where the value for Point 1 is entered.
9	Point 2	Each field is where the value for Point 2 is entered.
10	Auto Calculate	This button allows the Auto Calculate to be executed.
11	Space Expansion	This field is where the Space Expansion can be set.
12	Cancel	This button allows the setting to be canceled.
13	Confirm	This button allows you to confirm the setting.

Cylinder






- 212 -

	Items	Description
1	Shape Type	The desired Shape type can be selected from this drop-down.
2	Shape Image	This is the area where the image of the selected type is seen.
3	Coordinates	Either Base or World coordinates can be selected from this drop-down.
4	Radius	This is where the radius value is entered.
5	Upper	This field is where the upper value is entered.
6	Lower	This field is where the lower value is entered.
7	Center Position	The center value can be set in these fields for each of the X- and Y-axes.
8	Auto Calculate	This button allows the Auto Measure option to be enabled.
9	Auto Calculate Image	This area is where the image required for Auto Measure is seen. This appears when the Auto Measure option is enabled.
10	Upper	This field is where the upper value is entered.
11	Lower	This field is where the lower value is entered.
12	Origin	This field is where the origin value is entered.
13	Radius	This field is where the radius value is entered.
14	Auto Calculate	This button allows the Auto Calculate to be executed.
15	Space Expansion	This field is where the Space Expansion can be set.
16	Cancel	This button allows the setting to be canceled.
17	Confirm	This button allows you to confirm the setting.

Cuboid





	Items	Description
1	Shape Type	The desired Shape type can be selected from this drop-down.
2	Shape Image	This is the area where the image of the selected type is seen.
3	Coordinates	Either Base or World coordinates can be selected from this drop-down.
4	Point 1	Each field is where the value for Point 1 is entered.
5	Point 2	Each field is where the value for Point 2 is entered.

	Items	Description
6	Space Expansion	This field is where the Space Expansion can be set.
7	Cancel	This button allows the setting to be canceled.
8	Confirm	This button allows you to confirm the setting.

Tilted Cuboid


4 Points






	Items	Description
1	input method	You can choose the input method you want.
2	Space Image	This is the area where the image of the selected type is seen.
3	Coordinates	Either Base or World coordinates can be selected from this drop-down.
4	Point 1	Each field is where the value for Point 1 is entered.
5	Point 2	Each field is where the value for Point 2 is entered.
6	Point 3	Each field is where the value for Point 3 is entered.
7	Point 4	Each field is where the value for Point 4 is entered.
8	Space Expansion	This field is where the Space Expansion can be set.
9	Cancel	This button allows the setting to be canceled.
10	Confirm	This button allows you to confirm the setting.

3 Points & Height







М	en	u
---	----	---

	Items	Description
1	input method	You can choose the input method you want.
2	Space Image	This is the area where the image of the selected type is seen.
3	Coordinates	Either Base or World coordinates can be selected from this drop-down.
4	Point 1	Each field is where the value for Point 1 is entered.
5	Point 2	Each field is where the value for Point 2 is entered.
6	Point 3	Each field is where the value for Point 3 is entered.
7	size settings	Enter the Length, Width, and Height values.
8	offset settings	Enter an offset value.
9	Actual Point 1	You can check the Actual Point 1 value calculated based on the 3 point, size, and offset information.
10	Actual Point 2	You can check the Actual Point 2 value calculated based on the 3 point, size, and offset information.

	Items	Description
11	Actual Point 3	You can check the Actual Point 3 value calculated based on the 3 point, size, and offset information.
12	Actual Point 4	You can check the Actual Point 4 value calculated based on the 3 point, size, and offset information.
13	Space Expansion	This field is where the Space Expansion can be set.
14	Cancel	This button allows the setting to be canceled.
15	Confirm	This button allows you to confirm the setting.

Multi-plane Box





Menu

	Items	Description
1	Shape Type	The desired Shape type can be selected from this drop-down.
2	Shape Image	This is the area where the image of the selected type is seen.
3	Coordinates	Either Base or World coordinates can be selected from this drop-down.
4	Upper	This field is where the upper value is entered.
5	Lower	This field is where the lower value is entered.

	Items	Description
6	Plane Start X, Y	This field is where the start point of the plane is entered.
7	Pane End X,Y	This field is where the end point of the plane is entered.
8	Add New Plane	Clicking this button adds a new plane.
9	Selection Point	Each field is where the Selection Point values are entered.
10	Space Expansion	This field is where the Space Expansion can be set.
11	Cancel	This button allows the setting to be canceled.
12	Confirm	This button allows you to confirm the setting.

Space Limit and Shape of Zones

Overview of Space Limit and Zone settings.

For more information on Space Limits and Zones, see the PART 1. Safety Manual (p. 9), which includes the following topics.


- Space Limit(p. 41)
- Zone(p. 40)

Overview of Space Limit and Shape of Zones

How to set the shape of the **Space Limit/Zone** is as follows.

Items	Description
Cuboid	 The shape of the Space Limit/Zone is created as a cuboid. Enter the lower endpoint (Point 1) and upper endpoint (Point 2) of the cuboid and tap the Save Pose button.
	포인트 2 포인트 1

Items Description Tilted Cuboid The shape of the **Space Limit** /**Zone** is created as a tilted cuboid. **Setting by 4 Points** • Enter the reference point (point 1), x-axis end point (point 2), y-axis end point (point 3), and z-axis end point (point 4) of the tilted cuboid and tap the Save Pose • 3 lines (Point 1-Point 2, Point 1-Point 3, Point 1-Point 4) must cross each other at a right angle. (a deviation of +/- 5 degrees is acceptable) • If you use constrained motion functions such as "Plane Constraint" and "Axis Constraint" in the Cockpit using Point 1 as the reference point, the points for point 2, point 3, and point 4are more easily found. 포인트 3 포인트 4 포인트 1 포인트 2 **Setting by 3 Points and Height** • Enter the reference point (**Point 1**), the point on the x-axis (**Point 2**), and the point on the xy-plane (Point 3). • The location of the point on the xy-plane(Point 3) determines the direction of the y-axis, which is perpendicular to the line formed by the reference point (point 1) and the point on the x-axis (point 2) and located on the xy-plane. • Once the reference point, x-axis direction, and y-axis direction are determined, the z-axis direction is determined by the right-hand rule. • After the reference point and three axis directions are determined, the size of the tilted cuboid can be specified by setting the length, width, and height. • Tilted cuboid can be moved parallel (parallel translation) by setting the x, y, and z offset. After reaching the endpoint(vertex) of the tilted cuboid by pressing "move to" beside Actual Point 1, then pressing the "move to" beside Actual Point 2, Actual Point 3, or Actual Point 4, Robot TCP will move it along the edge of the tilted cuboid as far as it can reach. The position and direction setting of the tilted cuboid can be verified this way.



Items	Description
Sphere	The shape of the Space Limit/Zone is created as a sphere. • To configure the radius, enter the positions of the center point and endpoint of the sphere, and to configure the diameter, enter two endpoints of the sphere, then tap the Save Pose button.

Space Limit and Settings of Zones

Common


- Effective Area can be selected as either Interior/Exterior.
- Shape Type can be selected as Sphere, Cylinder, Cuboid, Tilted Cuboid, or Multi-plane Box. For more
 information, see (3.4.0-en_US) Overview of Space Limit and Zone settings.

Space Limit Setting

Space Limit is a function that sets a virtual fence in the outermost area of the robot. You can operate the robot without setting a space limit, but it is recommended to set a space limit for safe use.

You can set it by selecting 'Space Limit' in Robot Parameters > Safety Zone > Add > the top left of the popup.

- You can select one of the Robot & Tool Shape/TCP for the Interested Object.
- The robot must be within the space limit area set to be set normally.



0

Note


Depending on how you set it, the default value of **Space Expansion** exists.

- Tool shape setting, when selecting 'TCP' for inspection, TCP margin value 0mm
- Tool shape setting, when selecting 'Robot & Tool Shape' for inspection, TCP margin value 0mm
- Tool shape not set, when selecting 'TCP' for inspection, TCP margin value 0mm
- Tool shape not set, when selecting 'Robot & Tool Shape' for inspection, TCP margin value 60mm

Setting the custom zone

Custom Zone is the most flexible safety zone where you can freely set safety parameters. You can configure all settings such as robot limits, safe stop mode, joint speed and angle limits to suit your needs.

You can set it by selecting 'Custom Zone' in Robot Parameters > Safety Zone > Add > pop-up top left.



Note

If TCP is in a position where multiple areas overlap, the following rules apply individually for each safety feature

1. Normal Mode

- If no zones are set to **high priority zones**, **the most restricted** safety limit value of the overlapping zones will be the inspection reference value.
- If there is one zone set as **a high priority zone**, the limit value for that zone is the inspection reference value.
- If there are more than two zones set as **high priority zones**, **the most relaxed** safety limit value of the zones will be the inspection criteria.

2. Reduce Mode


- If no zones are set to **high priority zones**, **the most restricted** safety limit value of the overlapping zones will be the inspection reference value.
- If there is one zone set to **a high priority zone**, **the override option** for that zone determines the inspection reference value.

- If the override option is not checked, the most limited safety limit value between the high priority zone and the Global-Reduced Limit will be the inspection reference value.
- If **the override option** is checked, **the high priority zone** is the check reference value.
- If there are more than one zone set to **a high priority zone**, **the override option** for that zone determines the inspection reference value.
 - If the override option is not checked for any of the high priority zones, the
 highest priority zone for which the override option is not checked and the
 most limited safety limit value of the Global-Reduced Limit will be the
 inspection reference value.
 - If the **override option** for all **high priority zones** is **checked**, **the most relaxed** safety limit value among **high priority zones** will be the inspection criteria.

Setting the Collaborative Zone

The Collaborative Zone is a zone designed to work safely with robots. It provides robot limits such as deceleration rates required for close-range work, and safe stop mode settings.


You can set it by selecting 'Collaborative Zone' in Robot Parameters > Safety Zone > Add > Popup's top left.



Setting the Crushing Prevention Zone

The Crushing Prevention Zone is a zone to prevent crushing hazards that may occur between the robot and other objects. In this zone, when the collision and external force limit is violated, the safety stop mode is fixed to RS1 (Reflex Stop) and the collision sensitivity is set to 100%, so that when a collision is detected, the robot reacts as sensitively as possible to external force and then safely stops through floating reaction.


You can set it by selecting 'Crushing Prevention Zone' in Robot Parameters > Safety Zone > Add > Popup's upper left.



Setting the Collision Sensitivity Reduction Zone

Collision Sensitivity Reduction Zone is a zone that adjusts the collision detection sensitivity of the robot when working with different materials or surfaces. It provides force and collision sensitivity settings.


You can set it by selecting 'Collision Sensitivity Reduction Zone' in Robot Parameters > Safety Zone > Add > Top left of the popup.



Setting the Tool Orientation Limit Zone

Tool Orientation Limit Zone is a zone that limits the orientation of the TCP. It ensures that the TCP faces a specific direction and prevents it from facing an unsafe direction by defining the direction and angle margin.

You can set it by selecting 'Tool Orientation Limit Zone' in Robot Parameters > Safe Zone > Add > Top left of the popup.




Nudge Settings

If the robot is stopped by Safety Stop Mode SS2 or RS1 within a Collaborative Zone, the Interrupted state can be reset and task can be resumed with Nudge input. Nudge option can be enabled on user defined sections.

• To set up a nudge, select **Robot Parameters > Nudge** item.

For more information, refer to Nudge(p. 40).



Menu

	Items	Description
1	Lock toggle button	Used to lock the set value. The safety password is required for modifying the set value.
2	Nudge activation button	You can choose whether to use nudges.
3	Force Input	This field is where the desired Force value is entered.
4	Delay Time	This field is where the delay time is set.
5	Save	This button allows you to save the value you set.

6.7.4 Safety setting Review


If the robot data setting value has changed on the Robot Parameter module, the changed setting values can be stored through the Safety Setting Review pop-up.

The Safety Setting Review pop-up can be opened by clicking on the Robot Parameters file information entry in the Header, or within the Robot Parameters module.

Full Settings Review Pop-up

Displays information about the currently applied parameter file at once.


If the settings in the menu are inconsistent with the settings applied to the bottom, a red dot is displayed on the left side of the item.




When a Safety Setting Review pop-up is generated through the Header, Sync with Robot, Apply buttons are displayed if there is information that does not match the settings applied to the lower part of the menu.


When selecting the Sync with Robot button, apply the parameter settings of the controller to the current parameter file.

When you select the Apply button, apply the settings in the current parameter file to the controller.






If you have entered the Safety Setting Review pop-up through the Header and no changes are made, only the Close button is displayed.




The single setup review pop-up within the parameter module is as follows.




6.8 Remote Control Module

The Remote Control module enables remote control to be executed for tasks that you have already created.

in Operator authority, you can start Remote Control Mode, but you cannot modify the IO settings. IO settings can only be changed with Administrator authority.





Menu

	Items	Description
1	Warning	This will show the necessary precautions when using the module.
2	Mandatory Settings	This is a mandatory setting for remote control. You can set modules and tasks and set safe input signals.
3	Advanced Settings	This allows for advanced settings for remote control. You can set each port for the task to start/pause/stop/resume/servo on. If remote control is set to run automatically after rebooting, it will run as soon as Dart-Platform reboots.
4	Start Remote Control	This button allows you to start remote control after all settings have been completed.

6.8.1 Configuration Items

Mandatory Settings

In Mandatory Settings, you must configure the items essential for running remote control.

These settings must be completed to enable the Remote Control function.



• Select Module and Task

Select the module that supports remote control, and specify the task to control within that module.

• Safety Input Signal

Configure the Remote Control Enable signal.

You can specify this in the Safety I/O tab of the **Robot Parameter** module.

Advanced Settings

In Advanced Settings, you can additionally configure optional features necessary for remote control operation. These settings are optional, and if they are not configured, the basic Remote Control function will still be available.

• Start remote control automatically when rebooting



When the toggle button is set to ON, the system will automatically enter the Remote Control Mode screen after the robot is rebooted.

Advanced Signal Settings

All of the following signals are optional.



General Precautions

- These are not mandatory items.
- The same port and signal cannot be assigned redundantly.

• Safety Input Signal



Configure the Interlock Reset signal for initializing connected devices.

This operates identically to the Interlock Reset setting under **Safety I/O > Interlock Reset** in the **Robot Parameter** module.

• Safety Output Signals



You can assign output ports for STO, SOS, and Emergency Stop signals.

If STO, SOS, or Emergency Stop are already configured in the Safety Output Signals section of the Robot Parameter module, those settings will apply.



For detailed information on each signal, please refer to the Safety Signal I/O(p. 33) section.

• Normal Output Signals



You can assign output ports for STO, SOS, and Task Operating signals.

If the same signals are already configured in the General Output Signals section of the **Robot Parameter** module, those settings will apply.

• Control Input Signals



You can assign input ports for Start, Stop, Pause, Resume, and Servo On commands. Press the Reset button to clear the control input signal configuration.

• Power On/Off



You can configure input ports for Power On/Off.



1 The description displayed next to each signal port indicates the operating condition of that signal.

• Rising Edge

The input signal is activated when it rises.

For example, the Task Start signal is triggered when the input rises from 0V to 24V. When retrying, you must first return the signal to 0V before raising it again.

• Low Level

The Stop signal takes priority over the Start signal.

For example, if the Stop signal is at a low level, the Task Start signal will be ignored, and a **Remote IO signal ignored** message will be displayed.

6.8.2 Remote Control Mode Operation Steps


1. Create a program

You must create a program to control remotely in advance.

- Create a task in the Task Editor module.
- Save the task when the creation is complete.

2. Mandatory Settings

In the **Remote Control** module, you must configure the following required items:



- Select Modules and Tasks
 - Select the module and task to execute from the list.
- Specify Remote Control Enable signals
 - In the Safety I/O menu of the Robot Parameter module, select the *Remote Control Enable* signal and assign the port to use.



Remote control mode cannot be executed if required settings are not completed.

3. Advanced Settings (Optional)

If necessary, you can specify advanced settings.


If not configured, this feature remains disabled and has no impact on remote control operation.

• Automatically start on reboot



• When this option is enabled, the system will automatically enter the remote control screen when the robot power is turned on.

• Safety Output Signals




• Assign output ports for STO (Safe Torque Off) and SOS (Safely Operating Stop) signals.



For more information on each signal, please refer to the Safety Signal I/O(p. 33).

• Control Input Signals



• Set the digital input port for Start, Stop, Pause, Resume commands.


4. Entering remote control mode

Once the setup is complete, you can enter Remote Control Mode.

• In the Remote Control Module screen, click the **Start Remote Control** button.

5. Execute Remote Control

Execute the designated program remotely and monitor its status.




For example, if you want to execute a designated task on the robot after entering Remote Control mode, myou can first activate the servo by sending a Servo On (rising edge) signal to the assigned port, then send a Task Start (rising edge) signal to run the task selected in the required settings.

These signals are optional, so the robot can enter Remote Control mode without them. However, to use these optional functions within the mode, you must assign the necessary ports and apply the corresponding signals correctly.

6.8.3 Remote Control Mode

When starting remote control, you can navigate to the Remote Control Mode screen.


Dashboard



Menu

	Items	Description
1	Input Signal	Among the safety input signal items set in the safety I/O, the remote control Enable signal is received and displayed.
2	Total Time	Displays the time when the task was executed.
3	Cycle Count	Displays the number of repetitions of the task.
4	Cycle Time	Displays the one-cycle time of the task.
5	Collision Sensitivity	 Displays the collision sensitivity value. If inside the zone, displays the impact sensitivity value set in that zone. If outside the Zone, displays the crash sensitivity value set in the robot limit.
6	Tool Center Point	Displays the tool center point specified in the task.

	Items	Description
7	Tool Weight	Displays the tool weight specified in the task.
8	Tool Shape	Displays the tool shape specified in the task.
9	Signal Input/Output	Displays the respective signal input/output values.
10	Log	Displays system log information.
11	Speed	You can set the speed of the task.
12	TCP Force	Displays the force applied to TCP in real time.
13	Variable	Displays the variable values used by the running task.






	Items	Description
1	Controller Digital Input	Displays the controller digital input settings.
2	Safety Input	Displays the controller safety input settings.
3	Controller Digital Output	Displays the controller digital output settings.
4	Flange Digital Input	Displays the flange digital input settings.
5	Flange Digital Output	Displays the flange digital output settings.
6	Controller Analog Input	Displays the controller analog input settings.

	Items	Description
7	Controller Analog Output	Displays the controller analog output settings.
8	Flange Analog Input	Displays the flange analog input settings.


Log

Displays system log information.




Variable

Displays the variable values used by the running task.




6.9 Task Editor Module



Menu


	Items	Description
1	Edit Command Tool (CTR)	 Copy: Copies a command. Cut: Cuts a command. Paste: Pastes a copied or cut command. Delete: Deletes a command. Row up: Moves a command up by a line. Row down: Moves a command down by a line. Suppress: Annotates a command to exclude the corresponding command from execution during task execution.
2	Task List	Displays the task order and a list of commands added from the Command tab. Once the task is created, the Global Variables, Main Sub, and End Main Sub commands are automatically added.
		The list includes the following functions:
		 Multi Select: Allows you to select multiple commands. Task Name: Allows you to edit the name. Save: Allows you to save the created Task. View More: Allows more functions related to the task to be performed. * For more information about the View More button, see the section below. Undo: Allows you to cancel the very last action executed. Redo: Allows you to redo a canceled action.
3	Command	Displays a list of commands to add to the task list. Once a command is selected, it is added to the Task List.
4	Property	In this section, you can view and modify the settings of commands added to the Task List.
5	Monitoring	In this section, you can simulate and further configure the commands added to the Task List.

View More is organized as follows:



Menu

	Items	Description
1	About	Provides more information about the task.
2	New File	Creates a new file.
3	Open	Opens a task that already exists.
4	Import	Import task file from external source.
5	Save	Saves the current task.
6	Save as	Saves the current task with a different name.
7	Export	Exports the current task.
8	Close	Closes the task.
9	Delete	You can delete a task.



	Items	Description
12	About_Recently Modified	This is where the date of the last modification is seen.
13	About_Last played Parameter	This is where the very last parameter executed is seen.


Note

- Global Variables: The global variable and global pose of the task program can be entered in the **Properties** tab of Global Variables, and predefined global variables and global poses can be used in the property screen of the command added in the task list.
- Main Sub, End Main Sub: The commands you select are added to the bottom of Main Sub, and are executed in order from top to bottom, from the commands listed at the bottom of Main Sub to the commands listed at the top of End Main Sub.
- When monitoring is performed with a variable registered in the Variable tab, the value change frequency may be too fast to display the value on the screen.
- System variables can be registered without any limit on the number starting from software version V2.8.
- If there are too many system variables registered, there may be long loading times for task execution.
- Excessive use of TP_LOG or SET commands within loops may cause CPU overload.

6.9.1 Overview of Robot Motion Properties of the Task Editor

It is the property screen of the standard motions, MoveJ and MoveL commands. Other motions also have similar properties.

• If motion is created with minimum settings, only the pose information (5 in the figure below) needs to be entered.




2	Coordinates	 MoveJ: None MoveL: Calculates the entered pose information based on the coordinates (BASE/WORLD/TOOL/USER) 	
3	Select movement type	 Absolute movement MoveJ: Each joint moves to the target angle MoveL: Performs absolute movement by the target value based on the origin of the selected coordinates Relative movement MoveJ: Each joint performs relative movement by the target angle from the current angle MoveL: Performs relative movement by set value based on the current point (relative movement based on the selected coordinates) 	
4	Select variables	Pose information registered as variables can be selected	
5	Position information	 Pose information is entered MoveJ: Angle of each axis ([J1, J2, J3, J4, J5, J6]) MoveL: Position and rotation from coordinates ([X, Y, Z, A, B, C]) 	
6	Speed setting	1. Global: Uses the speed designated as global in the property of MainSub 2. Local: Each speed is designated 3. Separate: • MoveJ: Each joint speed is designated separately • MoveL: None 4. Time: Movement speed of the motion is set as time Caution • When considering the maximum payload condition in the payload diagram for each model, it is recommended to set the acceleration value to the same speed or less. (Speed:Acceleration Ratio = 1:1) • If a high acceleration is set, the robot may vibrate during acceleration/deceleration.	

7	TCP Speed Clamping	In the property of MainSub, Use Global TCP Speed Clamping for Joint Motion	
		TCP Speed Clamping Enable Disable When the TCP Speed Clamping feature is enabled, if the task's linear speed exceeds the global speed limit in the Move J and Move JX commands, the global TCP speed is automatically applied. However, safety speed and local speed limits always take precedence over the global speed limit.	
8	Operation mode	 Sync: The motion command in progress is done and the next command is executed Async: The next command is done simultaneously when the motion command begins Radius: The async function is activated in the radius section before the motion command reaches its target point 	
9	Blending mode	The option used to determine whether to ignore or overwrite the preceding motion according to the blending mode of the following motion when the radius is set as an option of the preceding motion	

Operating mode

Sync

You can move to the next command with Sync when the command in progress is completed. It is set as default, and used in general situations.




Async

Async starts the next command simultaneously when the motion command begins. It is used to smoothly connect different motions, and it is also used when signal output is turned on/off simultaneously when the motion begins.



Radius

Radius option activates the async function in the radius section before the motion command reaches its target point. With this option, it is possible to smoothly connect to the next motion command without stopping the current motion command. The radius is set to 0 mm as default.



Caution

Radius option has following characteristics and limits:


- Radius function can only be used in sync mode.
- Conditions and calculations can be performed in the async section within the radius.
- Radius cannot exceed 1/2 of the total distance between the current and target location before the motion is executed.
 - ex. If the movement distance is 100 mm, the maximum radius available is 50 mm.
- Motion commands which cannot apply Blending between motions are as follows: Blending is already applied in these commands, so applying radius to these commands and executing them causes errors. Utilizing commands, such as WaitMotion and StopMotion, can help avoid errors.
 - MoveSX, MoveSJ, MovePeriodic, MoveSpiral, MoveB

Blending mode

It is the option used to determine whether to ignore or overwrite the preceding motion according to the blending mode of the following motion when the radius is set as an option of the preceding motion.

Duplicate

Duplicate is a mode that maintains the preceding motion to allow the following motion to overlap with the preceding motion.



Override

Override is a mode in which following motion is performed by ignoring and overriding the preceding motion.




6.9.2 Overview of the Basic Concepts behind the Task Editor Move Command

Doosan Robotics robots offer 9 motions. Robot movement is controlled by standard motions, MoveJ and MoveL, and 7 motions derived from these two motions.

Types of Robot Motion

	Types of Robot Motion		
	Motion	Feature	
1	MoveJ	Each joint of the robot moves from the current angle to the target angle and stops simultaneously • Enter the target joint angle: Joint1, Joint2, Joint3, Joint4, Joint5, Joint6 Joint 3 Joint 4 Pose 1	
2	MoveL	Robot moves to the target point while maintaining the robot TCP straight • Enter target position and rotation values: X, Y, Z, RZ, RY, Rx Pose 1	
3	MoveSJ	 Robot moves throughout all angles set by the robot Joint spline motion movement As it is a robot joint movement, the path cannot be estimated 	


4	MoveSX	Robot TCP moves throughout all points
		Task spline motion movement
5	MoveJX	The robot pose is designated as the robot TCP moves to the target point • MoveJ motion movement to the target point (X, Y, Z, RZ, RY, RX) • As it is a robot joint movement, the path cannot be estimated Joint 3 Joint 4 Pose 1
6	MoveC	Robot TCP moves to target point while maintaining an arc Pose 1 TCP
7	MoveB	Robot moves to the final target point through a section consisting of continuous straight lines and arcs Pose 1 Pose 2 Pose 3 TCP



MoveJ&MoveL

Before using robot motion, it is critical to understand the standard motions MoveJ and MoveL.

- J in MoveJ refers to joints. In this motion, each joint moves to the target angle and stops simultaneously.
- L in MoveL refers to linear. In this motion, the TCP on the robot end moves to the target pose (position and angle) with linear motion.



	Туре	MoveJ	MoveL
1	Move Method	 All joints of the robot move from the current angle to the target angle and stop simultaneously 	TCP on the robot end moves to the selected coordinates with linear motion
2	Advanta ge	 Fast movement speed Not influenced by a robot singularity 	 As TCP path maintains a straight line, the movement path of the robot can be estimated As target point is indicated using position and rotation (X, Y, Z, RZ, RY, RX), the approximate robot end point can be estimated
3	Disadva ntage	 As all axes rotate to the target angle simultaneously, movement path cannot be estimated As target angle is indicated with the angle of each axis, it is difficult to estimate the robot end point and robot pose 	 Motion speed is relatively slower than MoveJ Influenced by a robot singularity
4	 As it is not influenced by a robot singularity, it is used to avoid singularities It is ideal in moving long distances 		It is ideal in avoiding objects and fine movement

6.9.3 Overview of the Concept of Compliance/Force Control of the Task Editor Command


Force Control and Compliance Control are functions that control the force of the robot. Also, with the addition of motion commands, the force can be controlled at the same time as the motion is made. Compliance Control and Force Control have the following differences, respectively.

1. Compliance Control

- In the case of Compliance Control, the robot complies to the external force at the end TCP of the robot and when the external force is removed, a force is generated to move the robot back to where it should be.
- This approach can be utilized when a robot is moving in a straight line on a bumpy surface and you want to ensure that the robot moves without causing damage to itself or the surface. This can also be utilized to prevent unexpected collisions near workpieces.


2. Force control

- In the case of Force Control, the force is applied to the TCP at the end of the robot. Acceleration is generated in the direction in which the force is generated, causing the robot to simultaneously move in the direction of the force in addition to the direction of motion.
- When the robot comes into contact with an object, the force is applied to the object until the set force and the object's repulsive force are in equilibrium
- This approach can be utilized when a robot is moving in a straight line on a bumpy surface and you want to ensure that a constant force is applied to a surface. This can also be utilized for tasks that require the robot to push with a constant force, i.e., polishing work.



Compliance and Force Commands are executed based on the current coordinates. The default coordinate of a task is the Base coordinates, and the coordinates can be changed with the Set command


- 1. Fig. 1 is the operating direction when force/compliance control in the +Z direction is applied on the base coordinates.
- 2. Fig. 2 is the operating direction when force/compliance control in the +Z direction is applied on the tool coordinates.



Compliance Control

Compliance control is the function that complies to external force according to the set stiffness when force is applied on the TCOP at the end of the robot. It balances forces at the target point, and it is a control method that generates repelling force if displacement occurs away from the balancing point. During compliance control, the robot end bounces like a spring.

- 1. If collision is made when motion control is used alone, it is possible that the collided object may get damaged.
 - Doosan Robotics robots stop safely when a collision occurs, but depending on the user setting, such as Safety Limits > Collision Sensitivity, the following situations may occur.
- 2. If compliance control is set to on during motion control, the robot will move while complying to the collided object.



If F is external force, K is stiffness and X is distance, the following formulas are true.

- F = K * X
- K = F / X
- X = F / K

Based on the above formulas, if the stiffness of compliance control is set to 1000N/m and if the robot moves 1 mm, the external force generated is 1N.


• F=1000 N/m*0.001 m=1 N (0.001 m=1 mm)



Note

On the Property of Compliance Command, the following values can be set:

- 1. Mode
 - On: Enables compliance control
 - Change: If compliance mode is set to On, it changes to stiffness
 - Off: Disables compliance control
- 2. Stiffness Range
 - M/H Series: Translation(0~20000N/m), Rotation(0~1000Nm/rad)
 - A Series: Translation(0~10000N/m), Rotation(0~300Nm/rad)
 - Lower stiffness values will respond to external force more gently and will require more time to return to the target point
- 3. Setting Time
 - It is the time required for the current stiffness value to reach the set stiffness value (0-1s)






Caution

- Tool weight and TCP (Tool Center Point) must be accurately set. Inaccurate tool weight can cause the robot to detect the tool weight as external force, and setting the Compliance Command On will generate position error.
- Tension of the dress pack may generate external torque on the robot. Therefore, take caution when installing the dress pack.
- Compliance cannot be turned on or off while async motion or blending motion is being executed.
- During Compliance Command on, only linear motion is allowed. Joint motions, such as MoveJ and MoveSJ, are not allowed.
- During Compliance Command On, Tool Weight or TCP cannot be changed.
- During Compliance Command on, it is possible to not accurately reach the target point due to compliance of the torque generated during motion execution. Therefore, it is recommended to turn on compliance control near the target point. Or, it is possible to minimize position error by setting a large stiffness value.

Force Control

Force Control is a function that applies force in the force control direction until the set force and repelling force are balanced

- It moves the robot in the set force direction, and if contact with an object is made, it maintains the entered force (N)
- It is capable of motion control in a direction different from the force direction while applying a constant force
- The minimum setting is +/- 10N, and it can be fine-tuned with a resolution of 0.2N
- Force Control is unavailable in singularity zone
- n general, Compliance Control is used in conjunction with force control so that force control complies to external force





Note

From the property of Force Command, the following values can be set.

- 1. Mode
 - On: Enables Force Control
 - Off: Disables Force Control
- 2. Desired Force Range
 - X, Y, Z: 10 (each robot's maximum) N
 - A, B, C: 5 (each robot's maximum) Nm
 - For more information about maximum force, refer to Upper/Lower Threshold Range and Default Value of Safety Parameters.(p. 60)
- 3. Target Direction
 - It moves to the selected target value of each direction.
 - Multiple selections can be made.


- Force control can only be executed with direction setting after force setting.
- If one of the multiple selected directions reaches the target force, it will continue to move until the target value is reached for the other direction.

4. Relative Mode

- If this mode is enabled, it calibrates the external force applied on the robot to 0 to improve the force control accuracy.
 - i. When relative mode is disabled, the actual force applying on the target is equal to the sum of the set force and external force.
 - ii. When relative mode is enabled, the actual force applying on the target is equal to the set force.
- During force control, deviation can occur depending on the pose or external force.
- During force control, it is possible not to reach the exact target point. Therefore, it is recommended to enable force control near the target point.

5. Setting Time

• It is the time required for the current force value to reach the set force value (0-1s)



Thread Command

Threads can be created and executed in the task editor.



Note

The constraints for Threads are as follows:

- A Thread name cannot start with a number and can only contain lowercase letters, numbers, and underscores. The name must not exceed 30 characters or be duplicated with another Thread name.
- In the task editor screen, when you click the Thread command, both the Thread command and the end Thread command will be added to the task list panel. A maximum of four Threads is allowed per task.
- The following commands cannot be configured alone and must be implemented within conditional statements:
 - Move, Move L, Move J, Move SX, Move SJ, Move C, Move B, Move Spiral, Move Periodic, Move JX
 - Define, Set, Sub, Thread, Break, Weight Measure
 - Force Control Commands (Compliance, Force)
 - Signal Commands (Add Signal, Set Signal, Get Signal, Delete Signal)
 - Advanced Commands (Hand guide, Nudge)
 - User Commands

6.9.4 Try Compliance command samples


Caution

Before trying the sample, make sure to read and follow Precautions(p. 11). For more information, refer to PART 1. Safety Manual(p. 9).




Note

- If there is an external torque above the threshold when enabling or disabling compliance control, the robot stops the program due to the JTS (Joint Torque Sensor) error.
- Stiffness change can be executed regardless of the external torque size.
- During compliance control, joint motions, such as MoveJ command, cannot be executed.




- 1. Change the servo state to On.
- 2. Change the operation mode to Manual.


3. Select the Robot Parameters module from the bottom menu. In this example, the Collision Sensitivity is set to 95% to explain the reason for lowering the Collision Sensitivity when using compliance control.




- 4. Select Robot Limits from Safety Settings.
- 5. Enable the parameter editing state.
- 6. If a password input window appears, enter the Safety Password (default safety password: admin).
- 7. Click the Confirm button.
- 8. Modify the Collision Sensitivity to 95%.
- 9. Click the Save button to save the settings.




10. After reviewing the changes, click the Apply button.




11. Select the Task Editor module from the bottom menu.




- 12. Rename the Task to Task_demo_compliance_ctrl.
- 13. Save the updated Task name.




14. Add the MoveJ command. This command will be used to move the robot to the starting position for compliance control.




- 15. Add two Compliance commands. These commands will be used to activate and deactivate compliance control.
- 16. Insert a Wait command between the Compliance commands. This wait command will be used to maintain compliance control.




- 17. Select the MoveJ command on line 3.
- 18. Choose the Property tab.
- 19. Modify the target position of MoveJ to (0, 0, 90, 0, 90, 0) deg. Depending on the robot's installation space, the angle of the J1 can be adjusted if necessary.




- 20. Select the Compliance command on line 4.
- 21. In the Property tab, set the Mode as follows: Mode On activates compliance control.
 - Mode: On
- 22. Set the Stiffness as follows: Lower the stiffness in the X and Y directions to make the robot respond more softly in those directions.
 - X:200 N/m
 - Y:200 N/m
 - Z:3000 N/m (default)
 - Rx, Ry, Rz: 200 Nm/rad (default)




- 23. Select the Wait command on line 5.
- 24. Set the Wait Time as follows.
 - Wait Time: 100 sec




- 25. Select the Compliance command on line 6.
- 26. In the Property tab, set the Mode as follows: Mode Off deactivates compliance control.
 - Mode: Off
- 27. Change the operation mode to Auto. The Property tab will automatically switch to the Monitoring tab.




28. Click the Run button. The robot will move to the starting position, initiate compliance control, and remain stationary for 100 seconds. During this time, gently push the robot's end effector toward the robot's body. The robot will stop with a collision error(or TCP Force Limit error). In the safety stop state caused by the collision, the robot's LED will display a yellow color.




- 29. Click the Reset button on the safety stop warning window. The task program will resume operation.
- 30. Click the Stop button to terminate the program.




31. To resolve collision issues, the Collision Sensitivity in the safety settings should be lowered. (If there is a TCP Force Limit issue, the TCP Force parameter should be increased.) Select the Robot Parameters module from the bottom menu. Alternatively, you can select the Robot Parameters module tab in the top left corner, which works the same.




32. In Auto mode, accessing the Robot Parameters module will trigger a notification window. Click the Confirm button to switch to Manual mode.




- 33. Select Robot Limits from Safety Settings.
- 34. Enable the parameter editing state. If a password input window appears, refer to steps 6–7.
- 35. Modify the Collision Sensitivity to 50%.
- 36. Click the Save button to save the settings. If the Robot Parameters Review window appears, review the modifications and click the Apply button.



- 37. Select the Task Editor module tab.
- 38. Switch to Auto mode to execute the Task Program.





39. Click the Run button. During the wait time, gently push the robot's end effector toward the robot's body. The robot will move due to the pushing force, and once you release your hand, it will return to its original position.

6.9.5 Try force command samples




Caution


Before trying the sample, make sure to read and follow Precautions(p. 11). For more information, refer to PART 1. Safety Manual(p. 9).




This sample requires the Task Writer file created in Try Compliance command samples(p. 270)




- 1. Change the Servo state to On.
- 2. Switch the operation Mode to Manual.
- 3. Select the Task Editor module from the bottom menu.




4. Click the File button.




5. Click the Open button.




- 6. Select the Task_demo_compliance_ctrl file created in Try Compliance command samples(p. 270).
- 7. Click the Open File button.



- 8. Rename the file to Task_demo_force_ctrl.
- 9. Click the Save button to save the file name.




- 10. Select the Property tab.
- 11. Choose the Compliance command on the 4th line.




12. Set the Stiffness to its default values as follows.

a. X, Y, Z: 3000 N/m (default)


b. Rx, Ry, Rz: 200 Nm/rad (default)




- 13. Select the Command tab.
- 14. Add a Force command to the 5th and 7th lines. These commands will be used to activate and deactivate Force Control.




- 15. Select the Force command on the 5th line.
- 16. Go to the Property tab.
- 17. Set the Mode as follows: Mode On activates force control.
 - Mode: On
- 18. Set the Desired Force as follows.
 - a. X: 0 N (default)
 - b. Y: 0 N (default)
 - c. Z:-10 N
 - d. Rx, Ry, Rz: 0 Nm/rad (default)
- 19. In the Target Direction, check only the z-axis.




- 20. In the Task List, select the Force command on line 7.
- 21. Set the Mode as follows: Mode Off deactivates force control.
 - Mode: Off
- 22. Switch the operation Mode to Auto. The Property tab will automatically switch to the Monitoring tab.




- 23. Click the Run button. In the Wait state, the robot operates as follows:
 - a. A force of -10N is applied at the robot's end effector, causing the robot to slowly move in the -Z direction.
 - b. Apply a counteracting force in the +Z direction, opposing the robot's movement. When the force applied by the robot and the opposing force are balanced, the robot will appear to hold its position as if stationary.
 - c. If a force greater than +10N is applied to the robot, it will move in the direction of the applied force.




- 24. During operation, you can monitor the real-time TCP Force in the TCP Force section of the Monitoring tab. If no force is applied to the robot's end effector, the TCP Force values should all be 0, but you may notice error components being displayed. Below is an additional explanation to address this issue.
- 25. Click the Stop button to terminate the Task.
- 26. Switch the operation Mode to Manual for Task modification.
- 27. Select the Command tab.




- 28. Add a Wait command to line 4 of the Task List.
- 29. Add a Custom Code command to line 5 of the Task List.




- 30. Select the Wait command on line 4.
- 31. Select the Property tab.
- 32. Set the Wait Time as follows.
 - Wait Time: 3 sec.



- 33. Select the Custom Code command on line 5.
- 34. Choose Single Line and add the following DRL command: This command resets the external force sensor values to remove any errors.
 - set_externl_force_reset()
- 35. Switch the operation Mode to Auto. The Property tab will automatically switch to the Monitoring tab.
- 36. Click the Run button.



37. In the Monitoring tab, check the TCP Force values. You will notice that the error has been reduced compared to before using the set_external_force_reset() command.




6.9.6 Overview of Sub/Call Sub

Sub is an abbreviation for subroutine. A subroutine refers to a process that minimizes the number of steps in a program by calling necessary parts when two or more duplicate parts are present.

- Doosan Robotics robots provide a CallSub command to call Sub commands and the corresponding Sub paragraph.
- The Sub command functions as defined in Python.

Note

- Sub paragraph must be added in MainSub, the start of a Main paragraph, and EndMainSub, the end of a Main paragraph.
- In addition to repetition, the Sub command is also used to simplify a Main paragraph. Utilizing a
 Sub command will allow intuitive identification of what task of a Main paragraph is being
 performed at the moment.
- Utilizing a Sub command allows Sub paragraph unit testing.




The sample where a Sub command is used to execute grip and release motions of a robot gripper consists of the following.

- 1. Lines of the Main paragraph execute the task program in sequential order starting from the first line.
- 2. Move to Sub(A) called by Call Sub.
 - Sample
 - Program: Call the Grip subroutine.
 - Robot: No motion
- 3. Sub(A) is executed. All Sub paragraph lines are executed in sequential order, returns to the Main paragraph, and executes the next line.
 - Sample
 - Program: Execute the Grip subroutine lines in sequential order. Use the Set command to set Output [1] as ON and Output [2] as OFF.
 - Robot: The robot gripper executes Grip motion.
- 4. Move to Sub(B) called by Call Sub.
 - Sample
 - Program: Call the Release subroutine.
 - Robot: No motion
- 5. Sub(B) is executed. All Sub paragraph lines are executed in sequential order, returns to the Main paragraph, and executes the next line.
 - Sample
 - Program: Execute the Grip subroutine lines in sequential order. Use the Set command to set Output [1] as OFF and Output [2] as ON.

• Robot: The robot gripper executes Release motion.


Add Sub command

- 1. In the Task Editor module, under the Flow Control section of the right-hand Command menu, add a Sub command.
- 2. Enter the subroutine name.



Add CallSub command

- 1. In the Task Editor module, under the Flow Control section of the right-hand Command menu, add a Call Sub command.
- 2. Select the subroutine name registered with Sub command.






• If the number of lines increases in the task program, it may become difficult to find subroutines. In such case, touch the Go to selected Subroutine in the Property of CallSub command to move the focus to the corresponding Sub command line.

6.9.7 SubTask/Call SubTask

Doosan Robotics provides SubTask commands and also provides CallSubTask commands to call SubTask statements.


Add SubTask command

- 1. In the Command tab, find and click the SubTask command under the Flow Control group.
- 2. In the Property tab, enter the name of the SubTask.
- 3. Select a previously created Task.



Add CallSubTask command

- 1. In the Command tab, find and click the CallSubTask command under the Flow Control group.
- 2. In the Property tab, select the name of the SubTask.



Call SubTask using CustomCode

You can call SubTask using CustomCode command instead of CallSubTask command.

- 1. When the SubTask name is "sub_task_a"
- 2. Enter the following in the CustomCode property:

Backward Compatibility

• For versions below Dart-Platform 3.4, enter as follows:

```
sub_task_a()
```

6.9.8 Commands

In the Task Editor, you can create a task program using Move Commands, Flow Control, Signal Commands, Other Commands, Force Control Commands, and Advanced Commands.

Move Commands

These are commands used to adjust or change the robot's pose.

Move	Move to a saved waypoint position using the selected motion type. (ex. Move J, Move L)	
Move J	Used to move the robot to the target joint coordinates.	
Move L	Used to move the robot along a line towards the target work space coordinate.	
Move C	Used to move the robot along an arc composed of a current point, via point and target point.	
Move B	Used to move the robot along a line and arc connecting multiple via points and target points within the workspace.	
Move SX	Used to move the robot along a curved line connecting multiple via points and target points within the workspace.	
Move SJ	Used to move the robot along a curved line connecting multiple via points and target points expressed as a joint coordinate.	
Move JX	Used to move the robot to the target workspace coordinate and joint form. This does not move along a straight line.	
Move Spiral	Used to move the robot along a path extending to the outer side from the center of a spiral.	
Move Periodic	Used to move the robot along a path repeated periodically.	
Stop Motion	This is used to stop task execution.	
Wait Motion	This is used to temporarily stop the robot after the previous motion command is complete.	

Flow Control

These can control the task flow through task standby, repeat, executing commands included in the task and conditions.

If	This is used to branch according to a specific condition during task execution	
Else If	This is used to branch according to a specific condition during task execution.	
Repeat	This is used to repeat the task command.	
Continue	This is used to return to the first command of a repetition statement (Repeat).	
Sub	This is used to define a thread within the task.	
Call Sub	This is used to execute the defined thread.	
Sub Task	This is used to temporarily stop task execution.	
Call Sub Task	This is used to receive user input and save it in a variable during task execution.	
Break	This is used to exit the repeat execution command (Repeat).	
Exit	This is used to end task execution.	
Wait	This is used to control the Function button.	
User Input	 This is used to branch according to a specific condition during task execution. Messages are limited to within 256 bytes. It is recommended that the text be concise. For long text, some content is omitted with an ellipsis (). Formatting code such as newline (\n) or carriage return (\r) is not allowed. 	
Thread	This is used to end thread execution.	
Run Thread	This is a command to define a thread within the task.	
Kill Thread	This is a command to execute a defined subtask.	
Folder	This is a command to create folder for grouping multiple commands.	

Signal Commands

These can control signalling during task execution.

Add Signal	Add a signal. • Modbus TCP • Modbus RTU • FOCAS • TCP Client • TCP Server • Serial
Get Signal	Get signal values. Disital I/O Analog I/O Industrial Ethernet Modbus TCP Modbus RTU FOCAS TCP Client TCP Server Serial
Set Signal	Set the value of a signal. Digital I/O Analog I/O Industrial Ethernet Modbus TCP Modbus RTU TCP Client TCP Server Serial
Delete Signal	Delete a signal.

Other Commands

There are commands that weigh the item and receive user input.



Note

- Repeated usage of specific commands regarding the screen UI may result in reduced system performance, less responsive screen UI, and abnormal operation of the program.
- It is not recommended to perform commands such as Set and Comment over 50 times per second.

Comment	 This is used to save the user-designated information in a log during task execution. Messages are limited to within 256 bytes. It is recommended that the text be concise. For long text, some content is omitted with an ellipsis (). Formatting code such as newline (\n) or carriage return (\r) is not allowed. 	
Custom Code	This is used to insert and execute a DRL code during task execution.	
Define	This is used to define a variable during task execution.	
Popup	 This is used to display a popup screen during task execution. Messages are limited to within 256 bytes. It is recommended that the text be concise. For long text, some content is omitted with an ellipsis (). Formatting code such as newline (\n) or carriage return (\r) is not allowed. 	
Set	This is used to execute various settings during task execution.	
Weight Measure	This is used to measure the weight during task execution and save it in a variable. This is not supported for the A and E models.	
Global Variables	This is used to add Global Variable.	

Force Control Commands

The force of the robot can be controlled during task execution.

Compliance	This is used to control Compliance during task execution.
Force	This is used to control force during task execution.

Advanced Commands

There is a command to execute Hand-guiding.

Hand Guide	This is used to execute direct teaching during task execution.	
Nudge	This is used to delay task execution until Nudge (applying force to the robot) input. This is not supported for the A and E models.	

6.9.9 Debug Player

1. Run All Mode




Function Description

This mode executes all commands sequentially to review the program flow.

How to Use

- 1. When you click the Play button, all commands will be executed.
- 2. If a **Skip Point** is set, the program will skip that point during execution.
- 3. If a **Break Point** is set, the program will run up to that point and pause.

2. Run Selected Mode



Function Description


This mode allows you to execute only the selected commands, and optionally pause after each line if needed.

How to Use


- 1. Select the desired lines using the checkboxes.
- 2. Set the line-by-line execution mode, then click the Run button.
 - Off: Only the selected commands will be executed.
 - On: The selected commands will be executed one line at a time, and the program will pause after each line.

6.9.10 Function of Operator Intervention


If a problem occurs while the robot is operating or a user issues a command, the robot stops operating and displays a pop-up message allowing the operator to intervene and resolve the situation. After the user resolves the problem, the task continues on the program line where the problem occurred.



- Power Off (H) DI 10 Not Used Request Intervention (F) DI 11 Not Used DI 12 Not Used DI 13 Not Used DI 14 DI 16 Not Used SI 3 Not Used Not Used
- Classic Welding module Analog Welding setting Communication Setting Input (If any of the following signals [Arc Active/Gas Off/Wire Stick/Machine Error] are enabled.)



- The "Move along the path button" and the "Step Move button (-10,-5,-1,+1,+5,+10)" perform the same action. However, the former moves forward or backward from the reference position by a manually entered Offset, while the latter targets a point forward or backward by a preset Step Offset. After completing an action using the above buttons, pressing an additional button will move the current position by the Offset.
- The "Use Handguiding button" is activated only when a Collaborative Zone is set, and the robot state changes to the Handguiding state, which allows direct teaching within the Zone. After that, you can activate direct teaching by pressing the button on the back of the cockpit or the Teaching pendant.
- In handguiding mode, the "Use Handguiding button" changes to the "End Handguiding button".
- When you press the "End Handguiding button", the handguiding state ends. At this time, for safety reasons, the current robot position, angle, and the values of the stop point (the time when the first pop-up occurs) are compared to generate a pop-up. If a pop-up with the following contents occurs, you must teach again directly to correct the robot's position and posture and try again.
 - If the straight-line distance between the current TCP position and the TCP at the stop position differs by more than 20 cm
 - If the difference between the current Joint Angle and the Joint Angle at the stop point differs by more than 1~3 axes (10 degrees) / 4~5 axes (30 degrees) / 6 axes (60 degrees)
- This feature is supported only during MoveL / MoveC / MoveB operations.
- You can use the Normal Output function to signal that a popup has occurred. The signal will remain active while the popup is occurring, and will be deactivated when the popup ends.
 - Robot Parameters module Normal I/O Output Operator Intervention (L)



Here is the usage scenario:

- 1. Receive a digital input signal from the user or a connected device while the program is running.
- 2. The robot pauses and an operator intervention pop-up appears.
- 3. (If using direct teaching) Press the Use Handguiding button, then press the button on the back of the cockpit or teaching pendant to activate direct teaching. After the direct teaching operation is complete, press the End Handguiding button.
- 4. Press the Move along the path button to move the robot along the path.
- 5. After moving the robot as much as desired, press the Resume button to resume the robot's task and close the pop-up.

6.9.11 Signal Commands

Add Signal

Function

A command that creates a new signal connection. It establishes communication connections with external devices.

Usage

- 1. Signal Type Selection: Choose the communication protocol to use
 - Modbus TCP/RTU
 - FOCAS
 - TCP Client/Server
 - Serial Communication
- 2. Setting Method Selection:

- **Default**: Direct configuration
- Module: Select pre-configured values from Device module
- 3. Connection Name Setting: Specify a unique connection name
 - No duplicates allowed
- 4. Communication Settings:
 - **Default Mode**: Direct input of device-specific detailed settings
 - Module Mode: Select pre-configured values

Precautions

- Connection names must be unique within the project
- Verify that IP addresses and ports are correct
- Ensure the target device supports the selected protocol

Get Signal (Input/Read)

Function

A command that reads data from external devices.

Usage

- 1. Signal Type Selection: Choose the communication protocol to use
 - Digital I/O
 - Analog I/O
 - Industrial Ethernet
 - Modbus TCP/RTU
 - FOCAS
 - TCP Client/Server
 - Serial Communication
- 2. Type-specific Settings:
 - Digital I/O: Port number selection
 - Analog I/O: Port number selection, type selection
 - Industrial Ethernet: Data type, address type, address setting
 - Other Protocols: Connection name selection (connections created by Add Signal)
- 3. Variable Selection: Select variable to store the read data

Set Signal (Output/Write)

Function

A command that transmits (outputs) data to external devices.

Usage

- 1. Signal Type Selection: Choose the communication protocol to use
 - Digital I/O
 - Analog I/O
 - Industrial Ethernet
 - Modbus TCP/RTU
 - TCP Client/Server
 - Serial Communication
- 2. Type-specific Settings:
 - **Digital I/O**: Port number selection
 - Analog I/O: Port number selection, type selection
 - Industrial Ethernet: Data type, address setting
 - Other Protocols: Connection name selection (connections created by Add Signal)
- 3. Value Setting: Input the value to transmit

Delete Signal

Function

A command that deletes existing signal connections.

Usage

• Connection Name Selection: Select the connection name to delete

Supported Protocols

Protocol	Description	Main Usage	
Digital I/O	Digital Input/Output Switches, Relays		
Analog I/O	Analog Input/Output	Sensors, Actuators	
Ethernet/IP	Industrial Ethernet	Allen-Bradley PLC	
Modbus TCP	Ethernet-based Modbus PLC, Industrial Equipment		
Modbus RTU	Serial-based Modbus Sensors, Instruments		
TCP Client/Server	General TCP Communication	eral TCP Communication Custom Equipment	

Protocol	Description	Main Usage
Serial	Serial Communication	Legacy Equipment
FOCAS	FANUC CNC	CNC Machines

Troubleshooting

Common Issues

- 1. Connection Failure
 - Check network settings
 - Check firewall settings
 - Check equipment power status
- 2. Data Read/Write Failure
 - Check address range
 - Check data type matching
- 3. Performance Degradation
 - Adjust polling cycle
 - Remove unnecessary connections
 - Check network bandwidth

Device Module Integration Example

Signal Commands can be configured to integrate with various device modules.

Supported Device Modules

• **Digital I/O**: Digital input/output signal control



• Industrial Ethernet: Industrial Ethernet communication



• Modbus TCP: Modbus TCP protocol communication



ModbusTCP_Master

DoosanRobotics

• Modbus RTU: Modbus RTU protocol communication



ModbusRTU_Master

DoosanRobotics

• FOCAS: FANUC CNC equipment integration



Focas_Master

DoosanRobotics

• TCP Client: TCP client communication



TCPClient

DoosanRobotics

• TCP Server: TCP server communication



TCPServer

DoosanRobotics

• Serial: Serial port communication



Serial

DoosanRobotics

This section explains the integration method using TCP Client and TCP Server modules.

1. Installing Device Modules

- Launch DART-Platform and run the Store module.
- Search for TCPServer and install the module.



TCPServer

DoosanRobotics

Search for TCPClient and install the module.



2. Configuring Device Modules

TCPServer Module Configuration

- Run the installed TCPServer module.
- Enter an arbitrary server port number. (e.g., 9999)
- Click the connect button to verify the connection works properly.
- Keep the connection active without disconnecting.

TCPClient Module Configuration

- Run the installed TCPClient module.
- Enter the server IP address (127.0.0.1) and port number (9999).
- Click the connect button to verify the connection works properly.
- Click the add write signal button.
- Enter the write signal name and value. (e.g., Output / 123)
- After configuration is complete, disconnect using the disconnect button.

3. Using Signal Commands

Task Creation

- Run the TaskEditor module.
- Click the new file button in TaskEditor.

Adding Add Signal

- Click the Add Signal button in the commands tab.
- Configure the following in the properties tab:
 - Signal Type: TCP ClientSetting Method: Module
 - Module: Select TCPClient module
 - Device: Select server connection information
 - **Connection Name**: Enter an arbitrary name (e.g., Comm_test)

Adding Set Signal

- Click the Set Signal button in the commands tab.
- Configure the following in the properties tab:
 - Signal Type: TCP Client

- Setting Method: Module
- Module: Select TCPClient module
- Connection Name: Select the name set in Add Signal
- Action: Select the write signal entered in TCPClient (e.g., Output)

4. Verifying Operation

Task Execution

- Click the play button to execute the task.
- Verify that the task starts normally.

Verifying Integration in TCPServer Module

- Check the data in the input signal area of the TCPServer module.
- Verify that the data (123) configured in the TCPClient module has been received.
- Validate that data transmission was successful.

5. Troubleshooting

Connection Failure

- Verify that the TCPServer module is running normally.
- Check that the port number is configured correctly.
- Inspect the network connection status.
- Verify that the firewall allows the specified port.

Signal Transmission Failure

- Verify that Signal Commands configuration is correct.
- Validate that data types and values are accurate.
- Inspect that the connection status between modules is maintained.


Important Notes

- Module execution order must be followed for proper integration.
- TCPServer must be running first for TCPClient to connect.
- Ensure the specified port is not blocked by firewall settings.
- Verify all modules are in normal status before executing Signal Commands.
- When testing, start with simple data and gradually progress to more complex data transmission.

6.10 Status Module


The Status module is a module that can monitor the controller, the input/output of the flange, and the communication register.

6.10.1 Status Module Screen layout



6.10.2 I/O Overview

I/O Overview Screen Layout



	Items	Description
9	Refresh	Reset the settings to default values.

Controller I/O

Controller Digital Input



- 1. Check the port number of the device connected to the controller.
- 2. The following is displayed depending on the digital input status of the corresponding number.
 - If the digital signal is a high signal, the icon is displayed in light green.
 - If the digital signal is a low signal, the icon is displayed in gray.



• The same is true when the digital input is set as a safety input, the icon is displayed in blue when the digital signal is high, and gray when it is low.

Safety Input



- 1. Check the port number of the device connected to the controller.
- 2. The following is displayed depending on the digital input status of the corresponding number.
 - If the digital signal is a high signal, the icon is displayed in light green.
 - If the digital signal is a low signal, the icon is displayed in gray.


Controller Digital Output



- 1. Check the port number of the device connected to the controller or flange.
- 2. Click the On/Off icon corresponding to the port number to activate or deactivate digital output.
 - When the **On** icon is pressed, the icon changes to light green and the corresponding port is enabled.
 - When the **Off** icon is pressed, the icon changes to light green and the corresponding port is disabled.

Controller Analog Input

Controller Analog Input




- 1. Click the drop-down list on the Controller Analog Input to select the item to check.
- 2. Check the analog input information of the selected item displayed on the screen.



• The analog input value cannot set the input value in the status window.


Controller Analog Output

Controller Analog Output



- 1. Click the drop-down list on the Controller Analog Output to select the item to check.
 - Analog output information of the selected item is displayed on the right side of the drop-down list.
 - The default value for analog output signal type is voltage.
- 2. Change the analog output value.

Flange I/O Port Setting



Flange Digital Input

- 1. Check the port number of the device connected to the flange.
- 2. The following is displayed depending on the digital input status of the corresponding number.
 - If the digital signal is a high signal, the icon is displayed in light green.
 - If the digital signal is a low signal, the icon is displayed in gray.



If the digital signal is High even when the digital input is set as the safety input, the icon is displayed in blue, and if it is Low, it is displayed in gray.

Flange Digital Output

- 1. Check the port number of the device connected to the flange.
- 2. Press the On/Off icon corresponding to the port number to activate or deactivate digital output.
 - When the **On** icon is pressed, the icon changes to light green and the corresponding port is enabled.
 - When the **Off** icon is pressed, the icon changes to light green and the corresponding port is disabled.

Flange Analog Input


- 1. Press the drop-down list on the flange analog input of the controller to select the item to check.
- 2. Check the flange analog input information of the selected item displayed on the screen.



The flange analog input value cannot set the input value in the status window.

6.10.3 Slave Monitoring

Slave Monitoring Screen Layout



	Items	Description
5	Add monitoring data	Add monitoring data. • Up to 1,000 entries can be added.
6	Reorder	A button to change the order of data. • Hold and drag the button to rearrange the data order.
7	Check Box	Select the data to be removed.
8	Data setting	Configure the group, address, description, and display method for the monitoring data. For Modbus Group: Select whether it is a Holding Register or Coil. Address: Enter the GPR Address to be monitored. Value: Choose the output type for the monitored value and verify it. Description: Add a description to the monitoring data that has been added. For Ethernet IP and Profinet Group: Select the GPR group. For Ethernet IP, the selectable mode changes according to the adapter type set in the PLC mode in the Setting module. For Profinet, the menu is fixed based on Monitoring & GPR. Address: Enter the GPR Address for monitoring. Value: Check the monitoring values. Description: Add a description to the monitoring data that has been added.
9	Start/Stop Monitoring	 This button allows starting or stopping the monitoring process. When monitoring starts, all fields except Slave Type, Search Box, and Description are disabled. Monitoring will end if the Stop Monitoring button is clicked, navigation to I/O Overview occurs, or the status module is closed. Monitoring cannot be started if there is no monitoring data for any Slave Type or if invalid data exists due to changes in the Ethernet IP's Adapter Type.

6.11 Logs module

With this module, logs can be managed by any criteria and dates.



There is r.c. data.





	Items	Description
1	Section for Search	Allows you to search by any criteria.
2	Date Filter	Allows you to view logs for a period of up to a month.
3	Category	Allows you to view logs by selecting a category. The categories are: • All • Control System • Control Algorithm • Inverter • Safety Controller • Modbus Communication • System Message
4	Level	This is where you can select the type of log.
5	Error	If checked, error logs are seen.

	Items	Description
6	Warning	If checked, warning logs are seen.
7	Information	If checked, information logs are seen.
8	Comment	If checked, comment logs are seen.
9	Filter Reset	This button allows you to initialize the selected log type.
10	Code or Keyword	This field is where you search for the desired code or keyword.
11	Search	This button allows you to search for what you need.
12	Log Table header	Header of the log table.
13	Log time	The time of each log is seen.
14	Category	The category of each log is seen.
15	Code	The code of each log is seen.
16	Log Message	Log messages are seen.
17	Clear	This button allows you to delete the log.

6.12 Store Module

Tapping the Store module redirects you to the Dr.Dart-Store link.






Menu

	Items	Description
1	Search	This field is where you search for any module.

	Items	Description
2	Menu Bar	The categorization is based on the features of the module.
3	Trending	This is the Home screen, where the currently popular modules are seen.
4	FAQs	This is where you can find the frequently asked questions regarding the Store.
5	Account	If you are not logged in, go to the login screen. If you are logged in, tap to go to the user's account and manage account settings and module uploads/downloads.



- AdmittanceControl
- ImpedanceControl

You can download the modules below from the User Module > Device section of the Store.

- Focas Master
- Digital IO TEST
- ModbusTCP Master
- ModbusRTU Master
- TCP Client
- TCP Server
- Serial
- IndustrialEthernet GPR Test

6.12.1 Activate or deactivate modules


After purchasing a paid module through Dr. Dart-Store, it must go through an activation process when executing the module.

In the case of a paid module, it cannot be executed in the inactive state, and when the module is deleted or refunded, the module must be in the inactive state.


Activation

When online:

If you are logged in to Dr. Dart-Store, it will be automatically activated if the paid module information you are trying to run matches the store login ID. If you are not logged in to the store or if your credentials do not match, a log-in pop-up will occur.




You can also activate it from the Installed Module List menu of the Setting module using the option button of the module you want to activate.



When offline:


It can be activated from the Installed Module List menu of the Setting module by using the option button on the module you wish to activate. The module activation code must be issued and authenticated online by Dr. Dart-Store.



Deactivation


When online:

You can deactivate it using the option button of the module you want to deactivate in the Installed Module List menu of the Setting module. The paid module information that you want to deactivate and the store login ID must match when this operation is executed. If you are not logged in to the store or if your credentials do not match, a log-in pop-up will occur.




When offline:


You can disable the option button to deactivate the module to deactivate the module menu to disable the option button. If you receive module deactivation code, the module is immediately disabled.



You must copy the corresponding deactivation code and switch it from online to deactivated on the Store via Dr. Dart-Store.



6.13 Settings Module



Menu


	Items	Description
1	List	Displays the list of all menus in the setting.
2	Current location	The menu currently located is displayed in blue.
3	Lock	This function requires an administrator password to be used.

6.13.1 System Information

The following system information is available in the **System Settings** > **System Information** menu.

- DART-Platform version
 - Platform Version: Current version of DART-Platform
 - Platform SDK Version: SDK version currently used by DART-Platform
- Running time
 - Controller Run Time: Controller Running Time


- Total Task Play Time: Total Task Running Time
- Total Task Play Count: Total Task Running Count
- See Terms & Policy: Terms & Policy of current DART-Platform



6.13.2 Setting language


To set the language of the program UI, follow these steps:

- 1. Tap the Settings Module button on the main menu and select System Settings > Language & Format.
- 2. Select the language you want to set from the Language list, and then tap the Save button..



6.13.3 Password settings and changes

Setting and disabling Password Lock.



When changing various settings after robot installation, the process can be troublesome as the system constantly requests the password to be entered.

In this case, enter the password in **Setting > Safety Password**. If the system requests the password when the password is not changed, enter the following password.

• admin

Touch the Password Lock toggle switch to disable the Password Lock function. Then all password lock functions will be disabled until the controller is rebooted.





Caution


Once the administrator finishes setting up the system, the password lock function must be enabled again before the user starts operating the system.



Changing Safety Password


You can change your safety password to a new one.

This function is only available unless a Safety Password is set.



Changing Supervisor Password

You can manage the supervisor password used when changing from Operator level to Supervisor level.




The default supervisor password is admin.

6.13.4 Configure in the Network section

In the Network section, you can set it up in relation to the controller and IDE connection.

Controller


For the **controller** settings, you can choose either a fixed address or DHCP.



IDE Connection


In the IDE Connection tab, you can select the IP to connect with Dr.Dart-IDE.

User can select a connectable IP from the list or enter it directly.



PLC

This menu allows you to view and configure the EtherNet/IP and PROFINET network settings of the controller, including communication methods and data configuration.






• The settings will not be saved until you press the **Save button** at the bottom.

• If you are using industrial communications, use a static address.

6.13.5 Setting the Robot

Setting the Robot Information




Menu

	Items	Description
1	Controller Serial Number	This is where the serial number of the controller is seen.
2	Copy Controller Serial Number	This button allows you to copy the serial number.
3	Robot Serial Number	This is where the serial number of the robot is seen.
4	Robot Model	This is where the robot model name is seen.

Robot Idle Servo Off

If the robot is idle for a certain amount of time, the robot is automatically set to the Safety Off state. The default value is 5 minutes, but the time can be changed to a time the user prefers.




Menu

	Items	Description
1	Enable Idle Servo Off	This button allows you to enable idle servo off.
2	Servo Off Setting	This field is where you set the idle servo off in minutes.
3	Save	This button allows you to save the changed settings.

Friction Calibration

This menu is only accessible for E and A series robots.



Menu


	Items	Description
1	Joint Check Box	Select the Joint to Auto Measure.
2	Current	Displays the current robot posture.
3	Start Position	Enter the posture at which the joint will start when performing Auto Measure. Unselected axes also require input.
4	Range	Enter the range in which the axis will move. Only checked axes allow input.
5	Result	Displays results for Auto measure.
6	Save	Measured results are applied to subordinates.

6.13.6 Robot Update and Restore

Update

Robot Update > Update menu provides the ability to update the system using update files.


• Upload the desired update file in the update area. Once the upload is complete, an Update button will appear, and you can perform the update through that button.




Menu

	Items	Description
1	Current Version Info	Shows current application/system/OS version information.
2	Update	You can download the update file manually.


• When you start the update, a package inspection will be performed. Once the package inspection is complete, the update screen will be displayed as shown below.



• Please read the details about precautions and consent information before performing an update.



• If the update fails, a rollback will be performed. If the rollback fails, the screen below will be displayed, and you can perform the rollback again by clicking the 'Restart to Rollback' button.



System Restore

The **Robot Update** > **System Restore** menu provides the ability to restore the system based on the update information.

• Select the desired restore point from the backup list, and then click the Restore button.




- Administrator mode required
- Manual Mode Status
- Status connected to actual controller



Caution


- If you have a paid module installed, it is recommended to disable it.
- Do not change control during the restore process.
- If you exit the program during the restore process, the current version is retained.
- Performing a factory reset will delete your restore points.



Menu

	Items	Description
1	Current Version Info	Shows current application/system/OS version information.
2	Backup List	It shows a list of restore versions that can be backed up. Items on the list are created when updated using the update function.
3	Restore	When you select the restore version list, the restore button becomes activated.


• Before performing Restore & Restart, check the details of cautions and consent information.



• If the restore fails, you will see the following screen. To proceed with the rollback, click the 'Restart to Rollback' button.




• If the rollback operation fails, you will see the following screen, and you can try the rollback again or select a different version to perform the restoration.



6.13.7 Managing Data

List of installed modules

This menu is where you can view and manage the installed modules.




Menu

	Items	Description
1	Category	On the module list, you can select the type of module or status category you want to view, as well as search for them.
2	Install from File	This button allows you to add your files to install the module.
3	Module Name	The names of the installed modules are seen.
4	Module Ver.	The versions of the installed modules are seen.
5	SDK Ver.	The SDK versions of the installed modules are seen.

	Items	Description
6	Installed Date	The dates each module was installed are seen.
7	Activation	Whether each is enabled is seen.
8	3 dot button	If not a required module, an optional button (three dots) is provided. When you tap three points, the following menu appears.
		Delete Delete Deactivate: Disables the enabled module. Delete: Deletes the enabled module.

Export log

In this menu, you can export Dr.Dart-Platform, Controller, OTA, and OS logs.




Menu

	Items	Description
1	Select log period	You can select the period of logs to be exported.
2	Select log type	Check the objects you want to export.
3	Export log button	Activated when there is more than one selected log.


Export & Import Data

This menu allows you to export and import data from your Dart-platform.




Menu

	Items	Description
1	Export Data	After selecting the corresponding radio button, the export button will be activated when you select the data to export on the right.
2	Import Data	When you select the corresponding radio button, the Import button becomes activated.
3	Data to Export	You can select the data to export.



When the Import radio button is selected, the data selection screen on the right is disabled.

Factory Reset




The Factory Reset function can be used to delete all user data and logs saved on the robot. Once the factory reset is in progress, the database, log files, Workcell Items and task files are deleted.


- 1. Tap the **Settings Module** button on the main menu and select **Factory Reset**.
- 2. **To delete all data, tap the Reset button.** To selectively delete log files, tap the **Clear** button.
- 3. Once the factory reset is complete, a restart of the system is required.

6.13.8 Notification Position Settings

You can change the location of notification messages that occur on the platform.



It can resolve the problem of other elements being obscured by notification messages.



6.13.9 Module update

In the **Data Management** → **Installed Module List** menu, the update button is activated if the version of the module installed on the platform is lower than the one deployed on the Dr.Dart-Store. The button allows the user to update the module to the latest version.




Note

Module updates are in Supervisor privileges and manual mode and require login with a Store account.



Caution

If the Internet is not connected, the Update button is not displayed



If you update a paid module, you can only update the module if the account where you installed the module is the same as the Store account that you logged in for the update.



If the module cannot be updated because the previously installed account and the logged-in account are different, delete the previously installed module and install the latest module from the purchased account.

6.14 Jog Plus Module


The user can select a manual movement method from the Jog tab.

- Jog: It moves the robot joint or TCP to the joint axis or coordinate axis the user selected
- Move: It moves the robot joint or TCP to the target point the user entered

Robot movement consists of two types.

- 1. Joint Motion: It moves each joint linearly with a rotating motion
- 2. Task Motion: It moves the end linearly to the target point

The following is the method how to move the robot using joint motion from the jog screen:




- 1. Select the Joint tab.
- 2. Select the axis to move. For example, You can select J1.
- 3. Press the +/- button to move the robot. The robot moves while the +/- button is pressed, and the current location is displayed on the screen in real-time.



For the P series model, J4 is disabled.

The following is the method how to move the robot using task motion on the jog screen:



1. Select the base coordinates. The robot can be moved according to the BASE coordinates or the TOOL coordinates.

- 2. Select the direction to move. For example, X-axis can be selected.
- 3. Press the +/- button to move the robot. The robot moves while the +/- button is pressed, and the current location is displayed on the screen in real-time.

For more information about jog movement, move and align, refer to Jog Panel (p. 365), and Move Panel (p. 370) respectively.



Note

If the toggle switch of the actual mode on the top left of the Jog screen is turned off, the robot moves only on the virtual screen on the left of the Jog screen. The actual robot moves if the actual mode toggle switch is turned on.

With the Jog Plus module, the user can explore the entire work space in manual mode or set the Operation Space as the robot operation space. The movement angle of each axis can be limited according to the selected operation space and joint angle limit of the safety setting.

To use the Jog Plus function, tap the **Jog Plus** Module on the main menu.

- The Jog function cannot be used during **Servo Off**.
- The robot is operated manually in the **Jog Plus** screen, so the robot only moves when the Jog button is pressed.
- It is possible to move the robot based on the current position on the Jog Plus tab screen.
- The robot can be moved by configuring the target angle/coordinates on the **Move** tab screen.
- It is possible to configure the reference coordinates on the **Jog Plus** tab screen and **Move** tab screen as a joint or task.



If the robot cannot be navigated due to being located in a space other than the operation space of the Jog Plus mode, set the robot operation space to "None" to allow the robot to be navigated.



Note

This module is not available in Auto mode. Tapping the toggle button in the bottom right makes it available in Manual mode.



Cannot Access this Feature




This feature is not available in auto mode.

To access this feature, change the robot status to manual mode.

Close Module

Using Job Plus (Jog+) allows you to use the jog feature simultaneously while performing different work. This can be utilized when manual control is required to move the robot to the target point during teaching.

6.14.1 Jog Panel




Menu

	Items	Description
1	Select panel type	You can choose the location of the move button.
2	3D Simulation	This is the 3D viewer, where you can see how the robot looks.
3	Simulator Alignment	You can utilize this section to steer the simulator.
4	Use Increment	This button allows you to enable angle or position increments.
5	Angle Increment	This section is where the angle increment on the selected axis is set.
6	Position Increment	This section is where the position increment on the selected axis is set.


	Items	Description
7	Collision	This field is where you set the Robot Collision.
8	Force Monitoring	This section is where you set the forces in the X, Y, and Z axes based on Base, Tool, World, Reference and among others.
9	Select reference coordinate system	Select the reference coordinate system to be used for the task coordinates in Figure 11. You can choose Base, World, or User coordinates.
10	Joint panel	You can select the joint axis to jog.
11	Task panel	You can select the task axis to jog.
12	Copy Pose J button	This button allows you to copy Pose J.
13	Copy Pose X button	This button allows you to copy Pose X.
14	Move - Button	You can have the robot move in the - direction based on each axis. At this time, you can figure out the direction of the - and + on the 3D simulation on the left-hand side.
15	Move + Button	You can have the robot move in the + direction based on each axis. At this time, you can figure out the direction of the - and + on the 3D simulation on the left-hand side.

Execute based on Robot Joint




To adjust the angle based on the robot joint, follow these steps:

- 1. Select the axis (J1-J6) to adjust the angle on the Joint Panel.
- 2. Press and hold the Direction Buttons ($\frac{1}{100}$, $\frac{1}{100}$) to adjust the angle of the corresponding axis.




Executing based on Robot Base



To move the robot based on its base coordinates, follow these steps:

- 1. Select the **Base** as a reference coordinate system.
- 2. In the **task panel**, select the axis (X~RX) for which you want to adjust the angle.
- 3. Press and hold the Direction button (+,-) to move the corresponding axis.

Executing based on World Coordinates



To move the robot based on World Coordinates, follow these steps:


- 1. Select the **World** as a reference coordinate system.
- 2. In the **task panel**, select the axis (X~RX) for which you want to adjust the angle.
- 3. Press and hold the Direction button (+,-) to move the corresponding axis.

Executing based on Robot Tool



To move the robot based on the robot tool, follow these steps:


- 1. Select the **tool** as a reference coordinate system.
 - 2. In the **task panel**, select the axis (X~RX) for which you want to adjust the angle.
 - 3. Press and hold the Direction button (+,-) to move the corresponding axis.



1 Note

- Safety area does not apply in virtual mode.
- Rx, Ry and Rz are executed according to TCP (tool center position).
- For P Series models, J4 and Rx are disabled.

6.14.2 Move Panel




Menu

	Items	Description
16	Select reference coordinate system	Select the reference coordinate system to be used for the task coordinates in Figure 18. You can choose Base, World, or User coordinates.
17	Joint Posture	Displays the current robot posture and the target joint posture.
18	Task Posture	Displays the current robot posture and the target task posture that fit the selected reference coordinate system.
19	Paste Joint Posture	Paste the posture value copied to the clipboard into the joint posture panel.
20	Paste Task Posture	Paste the posture value copied to the clipboard into the task posture panel.


	Items	Description
21	Joint Move button	This button causes the robot to move to the target joint posture.
22	Task Move button	This button causes the robot to move to the target task posture.

Setting Angle to Move



To move the robot at a specific angle, follow these steps:


- 1. Select the **Move** tab.
- 2. Enter the target angle of the robot joint. (J4 is disabled for P series models)
- 3. Enable the Real Mode.
- 4. Tap and hold the **Move to Corresponding Joint Pose** button to adjust the robot joint angle.



Setting Base Reference Coordinates to Move

To move the robot based on its base coordinates, follow these steps:

- 1. Select the Move tab and Reference Coordinates.
- 2. Select the display coordinate as the base.
- 3. Tap and hold the **Move to Corresponding Task Pose** button to move to the set coordinates.



Setting World Coordinates Reference Coordinates to move

To move the robot based on World Coordinates, follow these steps:

- 1. Select the Move tab and Reference Coordinates.
- 2. Select World as the display coordinates and select the World tab.
- 3. Configure the pose to move with reference to the World Coordinates.
- 4. Tap and hold the **Move to Corresponding Task Pose** button to move to the set coordinates.


Reference Coordinates World O Tool J1 0.00 ° 0.00 ° Х 0.000 m 0.000 mm 0.00 ° J2 0.00 ° 207.900 m 0.000 mm J3 0.00 ° 0.00 ° 2424.300 m 0.000 mm Z 0.00 ° 0.00 ° 0.00 ° 0.00 ° J5 0.00 ° 0.00 ° 0.00 ° 0.00 ° Ry 0.00 ° 0.00 ° 0.00 ° 0.00° J6 Rx Paste Joint Pose Paste Task Position Project Pose

Setting Coordinates to Move Based on the Tool

To move the robot based on the tool coordinates, follow these steps:

- 1. **Select the Move** tab and select the **Tool** tab.
- 2. Configure the pose to move with reference to the tool.
- 3. Tap and hold the Move to Corresponding Task Pose button to move to the set coordinates.

6.14.3 Align Panel



Function Overview

This function aligns the Z-axis of the robot arm's flange with the Z-axis direction of the robot's base coordinate system.

Purpose

By aligning the flange in the specified direction, tools attached to the robot—such as grippers or welding torches—can maintain correct orientation. This ensures consistent posture during operation and enables accurate task execution.

Operation

- 1. Select the desired alignment direction: Forward (+Z) or Reverse (-Z).
- 2. Based on the selected direction, the flange is rotated so that its Z-axis aligns with the upward or downward Z-axis of the base coordinate system.

7 Appendix

7.1 Appendix. System specifications

7.1.1 Manipulator Specifications

P Series

P3020

Classification	Items	Specifications	
Performance	Axis Structure	5	
	Payload	30 kg	
	Max. Radius	1900 mm	
	TCP Speed	Over 1m/s	
	Repeatability	± 0.1mm	
Joint movement	J1 Range / Speed	±360° / 100°/s	
	J2 Range / Speed	±125° / 80°/s	
	J3 Range / Speed	±160° / 80°/s	
	J4 Range / Speed	-	
	J5 Range / Speed	±360° / 200°/s	
	J6 Range / Speed	±360°/360°/s	
Operating Environment	Operating Temperature	0 °C to 45 °C (273 K to 318 K)	
	Storage Temperature	-5 °C to 50 °C (268 K to 323 K)	
	Humidity	20 % to 80 %	

Weight	83 kg
Mounting	Only Floor
IP Rating	IP 54
Noise	< 65 dB

7.1.2 Controller Specifications

CS-11P (AC Controller)

Items	Specifications
Weight	21.7 kg
Dimensions	606 X 306.9 X 446 mm
Material	Zinc Plated Steel
Protection Rating	IP54
Interfaces	RS232/RS422/RS485, TCP/IP (*RS232/RS422/RS485: USB to Serial converter not included)
Industrial Network	ModbusTCP (Master/Slave), ModbusRTU (Master), PROFINET IO (Device), EtherNet/IP (Adapter) (*In case of using a gateway, other communication types can be supported)
NC Interface	FANUC - FOCAS
I/O Port – Digital I/O	16/16
I/O Port – Analog I/O	2/2
I/O Port - OSSD I/O	2/2
I/O power supply	DC 24V
Rated supply voltage	100-240 VAC 47-63 Hz
Cable Length	6 m (option: 3 m)

7.1.3 Teach pendant

TP-02

Items	Specifications
Weight	0.8 kg
Dimensions	264 x 218 x 69 mm
Protection Rating	IP40
Screen Size	10.1 inch
Cable Length	Cs-11/cs-11P: 4.5 m (option: 2.5 m) Cs-12/cs-12P: 2.5 m (option: 4.5 m)

7.2 Appendix. P-Series Handling Guide



Caution

- Doosan Robotics does not assume responsibility for any damages that occurs during the use of lifting equipment.
- If the robot is transported by packaging it with packaging materials, store the robot in a dry location. If the robot is stored in a location with high humidity, condensation may occur, resulting in robot
- When relocating the robot, carefully consider the weight and have a suitable number of people hold the link and base of the robot.
- When relocating the controller, hold the handle on the side of the box.
- When transporting the robot or controller, make sure to maintain the proper posture. Failure to do so may result in back injury or other physical injuries.
- When transporting the robot using lifting equipment, make sure to observe all related national and regional regulations.
- Doosan Robotics does not assume responsibility for any damages or losses that occur during transportation, so make sure to transport the robot safely according to the user manual.

7.2.1 Quick Guide

Thank you for choosing this Doosan Robotics product.

This guide provides the minimum amount of information required for three handling methods for relocation and installation of the P-Series robot safely. Make sure to follow the instructions in this guide when handling the robot

- If the robot needs to be relocated, be sure to use the packaging materials provided with the initial delivery. For this purpose, store the packaging materials and fillings in a dry, cool location.
- Industrial robot's must be installed with careful consideration given to the inspection standards defined by the Regulations and Safety Inspection of the Occupational Safety and Health Standard Announcement (if the robot is subject to inspection).
- The robot can be transported using a crane, lift or hand lift, and when using a crane to lift the robot, be sure to comply with regulations of the area or country of jurisdiction.
- Utilize the packing posture for robot installation and relocation.
- Make sure whether all standard and additional (optional) components are included, and contact the sales agent if there are any problems.
- The packaging materials and bolts are designed specifically for the relocation of the robot. Do not use them for any purposes other than relocating the robot.
- When relocating the robot, do not apply force to the exterior of the robot. Failure to comply with these instructions may result in injuries.
- Remove the packaging materials and bolts after installation. Make sure to store the packaging materials and bolts in case the robot needs to be relocated.
- Before relocation, make sure that the bolts and packaging materials are secure.

1. When a crane (hoist) is used


- Use a spin-resistant cable capable of handling the weight of the robot.
- Two types of wire ropes must be used, and the lengths of each wire rope must be 1,500mm and 2,500mm, respectively.

Items	Minimum Capacity
Crane	1,000 kg
Wire Rope (EA)	500 kg

1.1 When securing a rope to a robot frame,

- Please use the included rope after properly installing it between axes 1 and 2, and axis 3, depending on its length. (Refer to Figure below)
- Before disassembling the robot fixing bolts, apply appropriate tension to the installed ropes to prevent the robot from falling over immediately after disassembling the fixing bolts.

Wire Rope Length	Device Location	
1,500 mm	Between Axes 1 and 2	
1,000 mm	Axis 3	




Warning

- For the safety of the user, both types of wire ropes included must be used, and failure to follow the instructions may result in unexpected safety accidents.
- If you use a rope other than the included rope, be sure to follow the lengths provided.
- When the robot is hoisted, the robot may tilt depending on environmental factors such as the wire rope installation status, robot posture, and optional attachment status, so be careful.
- Do not walk under the robot body when lifting.



Note

In the case of P Series, 4 M8 Taps are applied to the base to facilitate handling so that the work can be easily done, so please use them when working.



7.3 Appendix. Doosan Robot Allowable Torque

Caution


- The values below are the maximum allowable torque values for each joint and should not be used in excess of that value.
- It is recommended to operate within a range smaller than the values below when operating a robot.
- When a collision exceeding the allowable torque is detected while using the E-Series, slight misalignment may occur. If misalignment occurs, please perform Mastering based on the Home imprint for each axis.

Allowable Max. Torque [Nm]

P-Series

Axis	1	2	3	4	5	6
P3020	430	800	460	-	65	45

7.4 Appendix. IP Protection Cube module Installation guide



7.5 Appendix. DART Platform Installation Environment (recommended)

1 Windows OS: Windows 10 Enterprise (64bit)

1. CPU: Intel Core i5-6500 (@3.2GHz) or higher

2. Memory: 8GB

2 Mac OS: Ventura 13

1. CPU: Apple M1 or higher

2. Memory: 8GB

3 Android OS: Android 13

1. CPU: Snapdragon 665 / MediaTek Helio G88 (@2.0GHz) or higher

2. Memory: 8GB

3. Screen resolution: 1280 x 800